


# Reference Manual



KONGSBERG

## Seafloor Information System SIS

EM 1002



**Rev. A**



# ***Seafloor Information System*** ***SIS***

## ***Reference Manual for EM 1002***

Release 3.6

## Document history

Document number: 337745		
Rev. A	August 2009	Reference Manual for SIS with EM 1002. Applies to SIS version 3.6.

## Copyright

*The information contained in this document remains the sole property of Kongsberg Maritime AS. No part of this document may be copied or reproduced in any form or by any means, and the information contained within it is not to be communicated to a third party, without the prior written consent of Kongsberg Maritime AS.*

## Disclaimer

*Kongsberg Maritime AS endeavours to ensure that all information in this document is correct and fairly stated, but does not accept liability for any errors or omissions.*

## Warning

*The equipment to which this manual applies must only be used for the purpose for which it was designed. Improper use or maintenance may cause damage to the equipment and/or injury to personnel. The user must be familiar with the contents of the appropriate manuals before attempting to operate or work on the equipment.*

*Kongsberg Maritime disclaims any responsibility for damage or injury caused by improper installation, use or maintenance of the equipment.*

---

### Kongsberg Maritime AS

Strandpromenaden 50  
P.O.Box 111  
N-3191 Horten,  
Norway

Telephone: +47 33 02 38 00  
Telefax: +47 33 04 47 53  
**www.kongsberg.com**  
subsea@kongsberg.com



KONGSBERG

# Table of contents

<b>1</b>	<b>ABOUT THIS MANUAL .....</b>	<b>11</b>
<b>2</b>	<b>SIS SYSTEM DESCRIPTION .....</b>	<b>12</b>
2.1	Introduction .....	12
2.2	SIS system information .....	13
2.3	SIS licences .....	13
2.4	SIS system overview .....	15
2.5	SIS operational principles .....	17
2.6	SIS as a controller .....	18
<b>3</b>	<b>GRAPHICAL USER INTERFACE .....</b>	<b>21</b>
3.1	The application window .....	21
3.2	SIS frames .....	22
3.3	Toolbars .....	29
3.3.1	Main toolbar .....	29
3.3.2	Frame toolbars .....	31
3.3.3	Echo sounder – Not started list .....	32
3.3.4	Current echo sounder .....	33
3.3.5	Line counter toolbar set .....	34
3.4	View menu .....	35
3.4.1	Manage windows .....	35
3.4.2	Icons .....	37
3.4.3	C-MAP detail level .....	37
3.4.4	Colour palette .....	38
3.4.5	Status bar .....	39
3.5	Keyboard and mouse operations .....	40
3.6	Hotkeys .....	43
3.7	Common display buttons .....	43
3.7.1	Annotation colours button .....	44
3.7.2	Dynamic colours button .....	45
3.7.3	Print button .....	46
3.7.4	Zoom and view buttons .....	47
3.7.5	Scale buttons .....	49
<b>4</b>	<b>WINDOWS AND VIEWS .....</b>	<b>51</b>
4.1	Geographical view .....	52
4.2	Beam intensity view .....	56
4.3	Colour coded depth view .....	57
4.4	Cross track view .....	58
4.5	Seabed image view .....	60
4.6	Numerical display .....	62

4.7	Message service view .....	62
4.8	Helmsman display view .....	63
4.9	Time series view .....	65
4.10	Waterfall view .....	66
4.11	Water column view .....	67
4.12	Sound velocity profile view .....	70
4.13	Scope display .....	72
4.14	Stave display .....	73
4.15	PU sensor status view .....	77
4.16	New survey window .....	79
4.17	Survey administration window .....	81
4.18	Planning module window .....	82
4.19	Installation parameters window .....	83
4.20	Runtime parameters window .....	84
4.21	Runtime parameters mini view .....	85
4.22	Sensor layout view .....	87
4.23	Calibration view .....	88
<b>5</b>	<b>THE MENU SYSTEM .....</b>	<b>91</b>
5.1	Main menu .....	91
5.2	File menu .....	91
5.3	View menu .....	92
5.4	Tools menu .....	93
5.4.1	Custom menu .....	94
5.5	Help menu .....	95
<b>6</b>	<b>OPERATIONAL PROCEDURES .....</b>	<b>96</b>
6.1	Detecting the echo sounder on the network .....	98
6.2	Normal operational sequence .....	99
6.3	Start SIS .....	100
6.4	Enter survey and operator parameters, set projection .....	101
6.4.1	Set survey parameters .....	102
6.4.2	Start a new survey .....	105
6.4.3	Define a projection and datum transformation .....	107
6.5	Check installation and runtime parameters .....	110
6.5.1	Installation parameters .....	111
6.5.2	Runtime parameters .....	116
6.5.3	External sensors .....	119
6.6	Enter a sound velocity profile .....	123
6.7	Start the echo sounder .....	134
6.8	Import a Neptune grid to SIS .....	135
6.9	Start pinging .....	136

6.10	Check sensor input .....	136
6.11	Check echo sounder main functions .....	137
6.12	Geographical frame settings .....	138
6.13	Start and stop logging .....	141
6.14	Perform a system calibration .....	143
6.14.1	How to determine calibration values using SIS Calibration frame .....	153
6.14.2	How to determine calibration values using SeaCal automatic calibration .....	156
6.15	Plan a survey .....	159
6.16	Run the survey .....	163
6.17	Export data .....	166
6.18	Remote Helmsman Display .....	166
6.19	Exporting survey results .....	167
6.20	Exit SIS .....	168
<b>7</b>	<b>PARAMETER REFERENCES .....</b>	<b>169</b>
7.1	Frame toolbars parameters .....	169
7.1.1	Geographical – Display options .....	170
7.1.2	Geographical – Show depth under cursor .....	181
7.1.3	Geographical – Grid shading .....	181
7.1.4	Geographical – 2D or 3D .....	181
7.1.5	Geographical – Inspection mode .....	181
7.1.6	Geographical – Compass button .....	182
7.1.7	Geographical – KSGPL edit mode .....	182
7.1.8	Geographical – Planning edit mode .....	182
7.1.9	Geographical – Calibration edit mode .....	182
7.1.10	Geographical – Follow ship .....	183
7.1.11	Geographical – Load background data .....	183
7.1.12	Geographical – C-MAP manipulation mode .....	183
7.1.13	Geographical – Information field .....	183
7.1.14	Geographical – Level of Detail .....	183
7.1.15	Beam intensity – Show/hide .....	185
7.1.16	Colour coded depth – Show/hide .....	186
7.1.17	Cross track – Display options .....	186
7.1.18	Seabed image – Show/hide .....	189
7.1.19	Helmsman display – Show/hide .....	191
7.1.20	Time series – Show/hide .....	193
7.1.21	Time series – Clear plot .....	194
7.1.22	Waterfall – Show/hide .....	195
7.1.23	Water column – Show/hide .....	196
7.1.24	Water column – Logging .....	199
7.1.25	Sound velocity profile – Show/hide .....	200
7.1.26	Scope display – Show/hide .....	200

7.1.27	Stave display – Show/hide.....	201
7.1.28	Planning – Jobs.....	202
7.1.29	Planning – Remote.....	202
7.1.30	Planning – Object .....	203
7.1.31	Sensor layout – Show/hide .....	210
7.2	Calibration parameters .....	213
7.2.1	Seacal auto calibration .....	214
7.3	Survey parameters .....	216
7.3.1	Basic parameters.....	216
7.3.2	Storage options .....	219
7.3.3	Background data .....	220
7.3.4	Projection parameters.....	222
7.3.5	GridEngine parameters.....	222
7.3.6	User handling .....	224
7.3.7	CUBE parameters .....	225
7.4	Installation parameters .....	226
7.4.1	PU communication – Input setup .....	226
7.4.2	PU communication – Output setup.....	230
7.4.3	PU communication – Clock setup .....	232
7.4.4	Sensor setup – Settings.....	233
7.4.5	Sensor setup – Locations.....	237
7.4.6	Angular Offsets for EM 1002 .....	238
7.4.7	System parameters for EM 1002 .....	239
7.4.8	BIST – Built-In Self Test.....	240
7.5	Runtime parameters.....	243
7.5.1	Sounder main for EM 1002 .....	243
7.5.2	Sound speed for EM 1002 .....	246
7.5.3	Filter and gains for EM 1002 .....	250
7.5.4	Data cleaning.....	253
7.5.5	Javad and Trimble.....	261
7.5.6	ATH Logging .....	261
7.5.7	Simulator for EM 1002 .....	263
7.5.8	Survey Information .....	265
7.6	SIS parameters – Set parameters .....	266
7.6.1	Ship parameters .....	267
7.6.2	Error model parameters .....	268
7.6.3	Advanced display options.....	269
7.6.4	APOS .....	270
7.6.5	Positions .....	271
7.6.6	Turn parameters.....	272
7.6.7	Password.....	273
7.6.8	Display .....	273
7.6.9	Logging .....	274

7.6.10	Autopilot.....	276
7.6.11	Sound speed .....	276
7.6.12	Network license.....	277
7.7	File menu parameters .....	278
7.7.1	Import/Export.....	278
7.7.2	Export xyz file .....	286
7.7.3	Remove survey.....	287
7.7.4	Save settings.....	287
7.7.5	Save settings as.....	287
7.7.6	Delete settings .....	288
7.7.7	Set startup settings .....	288
7.7.8	Export PU parameters .....	289
7.7.9	Import PU parameters .....	290
7.7.10	Export user settings.....	291
7.7.11	Import user settings.....	292
7.7.12	Create CUBE grid.....	292
7.7.13	Quit .....	293
7.8	Tools menu parameters.....	295
7.8.1	External sensors.....	295
7.8.2	Instrument combinations .....	302
7.8.3	Remove instruments.....	303
7.8.4	C-MAP – Licence administration.....	304
7.8.5	AutoCalib Wizard.....	305
7.8.6	SeaCal results.....	306
7.8.7	Extract IFF .....	306
7.8.8	Configure.....	307
7.9	Projection and datum parameters .....	308
7.10	Help menu dialogs.....	314
7.10.1	Help.....	315
7.10.2	Build info.....	315
7.10.3	OpenGL settings.....	315
7.10.4	About SIS.....	316
<b>8</b>	<b>SIS UTILITIES .....</b>	<b>317</b>
8.1	SVP Editor.....	318
8.2	SVP Effects .....	324
8.2.1	User interface .....	324
8.2.2	What you see.....	326
8.3	SmartTalk (SVP) .....	327
8.3.1	What it does .....	327
8.3.2	How it works.....	327
8.3.3	Configure instrument.....	328
8.3.4	Download data .....	329

8.3.5	View data .....	329
8.4	SVP Logger .....	332
8.4.1	Running the program .....	332
8.4.2	Using the program .....	333
8.5	SeaCal .....	335
8.5.1	What it does .....	335
8.5.2	Calibration parameters .....	336
8.5.3	Design of the calibration lines .....	337
8.5.4	How to run SeaCal .....	339
8.5.5	Resolution .....	340
8.5.6	Maximum number of iterations .....	340
8.5.7	More on the field calibration method .....	340
8.5.8	Bibliography .....	342
8.6	SIS Objects .....	344
8.6.1	How to use SIS Objects .....	344
8.6.2	Configuration of SIS Objects .....	348
8.6.3	Technical references .....	352
8.6.4	File formats .....	353
8.7	C-MAP CM-93/3 .....	354
8.7.1	What it does .....	354
8.7.2	Specification of minimum performance .....	354
8.7.3	C-MAP S-57 Verifier and CM-93/3 Compiler .....	354
8.7.4	The C-MAP Cartographic Service .....	356
8.8	Global event marker .....	359
8.9	PU simulator and playback .....	361
8.10	Create terrain models from ASCII files .....	363
8.11	KSGPL .....	365
8.11.1	Overview .....	365
8.11.2	KSGPL language reference .....	365
8.11.3	KSGPL output from the Geographical window .....	368
8.12	How to use SIS on an AUV/ROV .....	371
8.13	CUBE .....	375
8.13.1	About the implementation of CUBE in SIS .....	375
8.13.2	User interface differences when CUBE is used .....	379
<b>9</b>	<b>TECHNICAL REFERENCES .....</b>	<b>383</b>
9.1	SIS architecture .....	384
9.1.1	SIS processes .....	384
9.1.2	Main GUI (Graphical User Interface) .....	384
9.1.3	CCU (Central Command Unit) .....	386
9.1.4	DDS (Data Distribution System) .....	386
9.1.5	HDDS (Handle Data Distribution System) .....	386
9.1.6	GridEngine .....	387

9.1.7	SISDB .....	388
9.2	Real time data cleaning .....	389
9.3	The vessel coordinate system .....	393
9.4	Timing .....	395
9.4.1	Introduction.....	395
9.4.2	Internal clock.....	395
9.4.3	Time stamping.....	396
9.4.4	Time difference PU-ZDA and PU-POS indications .....	397
9.5	Sound speed formulas .....	399
9.6	Implementation of absorption coefficients .....	401
9.6.1	Overview .....	401
9.6.2	Salinity based absorption coefficient profiles .....	401
9.6.3	CTD based absorption coefficient profiles.....	403
9.6.4	Mode of operation .....	404
9.7	Artefacts causing errors and variations in the sea floor depth detections .....	407
9.7.1	Introduction.....	407
9.7.2	Sea bottom penetration.....	407
9.8	The absorption coefficient equation .....	410
9.9	Projections .....	411
9.9.1	Scope.....	411
9.9.2	Programming a projection .....	411
9.9.3	Using PROJ.4.....	412
9.10	Geoid .....	414
9.11	Tide.....	417
9.12	Javad and Trimble details.....	419
9.12.1	Raw GPS data logging module .....	419
9.12.2	Mean Sea level module .....	421
9.12.3	Real time tide module .....	421
9.12.4	RStoUDP .....	423
9.13	Dead reckoning and position jump filter .....	424
9.13.1	Dead Reckoning .....	424
9.13.2	Position jumps.....	424
<b>10</b>	<b>DATAGRAM AND FILE FORMATS.....</b>	<b>426</b>
10.1	Export formats.....	427
10.2	Survey plan file format .....	430
10.3	Handling of SSP datagrams.....	431
10.3.1	Overview .....	431
10.3.2	Usage.....	432
10.4	Sound speed profile format.....	434
10.5	Sound speed and density profile format .....	437
10.6	External datagram (C+T) format.....	439

10.7	Changing behaviour of notification messages.....	440
10.8	Request datagrams from an echo sounder.....	442
10.9	Request datagrams – manual set-up .....	444
10.10	Data distribution .....	450
10.11	Remote datagrams .....	451
10.12	Notification of SIS pinging and logging activity.....	453
10.13	Difference in log file formats .....	456
10.14	Barometer input.....	457
10.14.1	Preparations for use .....	457
10.14.2	Barometer input format .....	457
<b>11</b>	<b>INDEX.....</b>	<b>459</b>

# 1 ABOUT THIS MANUAL

## **The purpose of this manual**

The purpose of this reference manual is to provide the descriptions, procedures and detailed parameter explanations required to allow for safe and efficient use of SIS, as well as a thorough understanding of the system parameters and adjustments.

## **Software version**

This manual complies to SIS software version 3.6.

## **Reference documentation**

- SIS operation manual
- SIS installation note
- Operator manual for relevant multibeam echo sounder system

## **Support**

Support Hydrography/Naval: [km.hs@kongsberg.com](mailto:km.hs@kongsberg.com)

24 hrs support telephone: +47 99 20 38 01

All Kongsberg Maritime products (24 hours): +47 815 35 355

E-mail: [km.support@kongsberg.com](mailto:km.support@kongsberg.com)

## 2 SIS SYSTEM DESCRIPTION

### 2.1 Introduction

The Seafloor Information System (SIS) is a real time software designed to be the user interface and real time data processing system for hydrographic instruments produced by Kongsberg Maritime AS.


SIS is included on all deliveries of multibeam echo sounders from Kongsberg Maritime. Single beam echo sounder (EA 400/600) software from version 2.4.0.0 can be controlled by SIS. SIS will automatically detect their presence on the network and allow you to start/stop pinging and logging from them. Data can be stored as EA data, as SIS survey data, or both. The depths from the EA will be displayed in the Geographical window. SIS can also log data from earlier versions single beam echo sounders, other systems supplying output data on NMEA format as well as from standalone navigation systems.

SIS operates under Windows operating system, and is compatible with the HWS Work Station hardware. One or two display screens can be used, or up to four if a second video card is installed.

The design of SIS is based on more than 50 years of hydrographic experience with echo sounders, sonars and underwater positioning for civilian and military use. Kongsberg Maritime is today a part of the Kongsberg Group, a world wide organisation supplying advanced instrumentation for civilian, research and military maritime communities.

The Kongsberg Maritime echo sounders are complete systems. All necessary sensor interfaces, data displays for quality control and sensor calibration, seabed visualization, and data logging are standard parts of the systems, as is integrated seabed acoustical imaging capability (sidescan).

*Figure 1 Instrument interface*



## 2.2 SIS system information

Operating systems supported:

- Windows XP™

Hardware supported:

- HWS
- 1 or 2 displays, optional 4 displays if a second video card is installed

License control:

- By dongle connected to USB port

Options/versions:

- Basic/Instrument control
- Multibeam echo sounder support
- Real time data cleaning
- Water column imaging
- SIS Objects

## 2.3 SIS licences

The SIS software is subject to license control. Licensing of SIS is controlled by a HASP dongle. This dongle is programmed according to what SIS version has been purchased.


The control part of SIS is unlicensed. This version gives access to the following applications:

- Installation and runtime parameters
- Start/stop logging
- Survey administration
- New survey
- Messages, Beam intensity, Cross track, Time series, Seabed image, Numerical display and Water column windows

An unlicensed version of SIS will also work as an interface to third party software.

The figure below shows the principle drawing of the hardware setup with the SIS software package, integrated with single beam or multibeam echo sounder systems.

Figure 2 Principle drawing, hardware setup with SIS



## 2.4 SIS system overview

The main task of SIS is to be a logical and user friendly interface for the surveyor, providing required functionality for running a survey efficiently.

The main features of SIS are:

- Control of both single- and multibeam echo sounders
- Real Time Data Cleaning module. This module processes first a set of pings from the current line, but also does area based processing where all previous data from the same area is processed together.
- Geo-referenced high resolution seabed image mosaic can be viewed in the Geographical view
- Real time terrain models are built from the cleaned dataset
- 3D displays using OpenGL
- GeoTiff files and C-MAP background maps can be used as underlay for the survey
- Import of xyz data from other sources (such as Neptune) can be used as background maps
- 3D terrain models made from S-57 files can be used as background data.

### Basic version/instrument control

With this you can select which instrument to operate, switch the instrument on or off, change setup and operating parameters, record/export data, and you have access to graphic windows for simple quality checking of the data produced. Sound velocity at the transducer and sound velocity profile is interfaced and handled.

Instrument control also includes activation of instrument hardware testing, and reporting of error situations and system messages.

The Geographical window can be displayed in 2D or in 3D. In 2D mode it will typically include a background map (DXF, GeoTiff, C-MAP and KSGPL formats supported), planned survey lines, a vessel symbol, and a raw (limited) or gridded (unlimited) representation of sounding data which has been collected. There is functionality for defining and editing survey lines, and for selection of information content.

Geo-referenced high resolution seabed image mosaic can be viewed in the Geographical view

The geographical window can be zoomed and panned, it can also follow the vessel position automatically.

The real time gridding which takes place for the sounding data, updates a multiple resolution grid, and the display resolution is adjusted automatically to fit the map scale. In this way you can view large areas efficiently, and you can zoom in to a smaller area and view the data with high resolution.

Grid models based upon previous surveys can be imported for comparison purposes.

In 3D mode, the seafloor surface can be viewed from different angles/resolutions, the light source can be shifted, and you can rotate the surface in order to obtain the best view.

The survey results can be sent to printer with full plotter resolution.

Screen dumps or just one display window can be copied to a graphic printer.

### **Multibeam echo sounder support**

Licensed multibeam support gives access to:

- More QA views for the multibeam data
- System calibration
- Visualisation of high resolution seabed backscatter data
- Visualisation of seabed imagery data in the Geographical view
- Plotting of survey results with full plotter resolution
- Support for remote Helmsman Display, connected via Ethernet

### **Single beam echo sounder support**

EA single beam echo sounders, from version 2.4.0.0 and onwards, have the ability to be entered into a SIS operational mode. This will enable the EA echo sounder to be integrated in the SIS topside environment for control, display and data logging purposes.

For configuration of the single beam echo sounder systems the relevant operator's manual must be consulted.

### **Real time data cleaning**

SIS includes efficient algorithms for automatic flagging of soundings which are recommended to be eliminated from the survey results. The soundings are not physically removed from the data set, so it is possible to reverse the decisions and apply a completely new data cleaning during post processing. However, for the majority of user needs, the real time data cleaning will be sufficient, and further processing is either not necessary or at least reduced substantially.

The real time data cleaning uses area based algorithms which considers all points in an area, both from current and previous survey lines. A best fit curved surface is created through the survey points providing a very good real time terrain model for data cleaning.

### **Water column imaging**

Some multibeam echo sounders, depending on model and purchased options, have built-in support for imaging of acoustic reflectors also in the water column. Such reflectors are for example fish or other biomass, but can also be submerged buoys or moorings.

## **2.5 SIS operational principles**

### **Note**

---

*The SIS software is used by single beam or multibeam echo sounders. When you run a survey, you can log data from more than one system at a time. This implies that not all information herein will be relevant for all systems. This is further explained in the following.*

---

SIS is operated in *Online* or *Offline* mode.

- The *Online* mode is used during the survey. The application is used to control the (multibeam) echo sounder, to store the data, and to present various views of the data for quality assurance.
- The *Offline* mode is used after the survey has been completed, and the data is stored on disk. The application is used to view the results of the survey.

The standard SIS application will generate full documentation of the survey results, and provide output for survey statistics, contour charts, illuminated plots etc. For some purposes this may be sufficient, but normally additional SIS post-processing packages available are used for data cleaning, image processing and final chart production.

Some parameters need starting values depending on type of operation and water depth.

You may start SIS by loading a predefined set of parameters, stored in a database, and then modify some of the individual parameters observing the effect on the displayed data. The modified parameters, including all the remaining parameters, can then be stored as a user specified set-up.

All parameters, as well as all the survey information, are stored in a database. The raw data is stored to disk.

You may wish to optimize system performance by adjusting parameters in the system. When the results are as desired, the current parameters set may be stored in the database for later retrieval.

The operators are assumed to have reasonable detailed knowledge about Windows XP operating system and some familiarity in using them.

### **System interaction**

All interactions between operator and the system take place through the windows system on the Operator Station. The following input tools are used:

- Keyboard
- Pointing device (by default an optical mouse with scroll wheel)

Navigating in the menus, tabs and dialogue boxes is done with the pointing device. The keyboard is used for entering numerical and character strings into the parameter fields.

### **Survey handling**

Every echo sounder logs data to a survey. If no survey is defined, data will be logged to a predefined “fallback” survey.

Note

---

***We strongly advise you to define your own default surveys.** A default survey contains information about where to store the raw and processed data on the disks, what projection to use, coastlines to display etc.*

---

When you create a new survey, you can use a default survey as a template for the new survey. This may save a lot of parameter definitions, and make life a lot easier for the surveyor.

### **Related operational procedures**

- *How to configure your survey* on page 101

## **2.6 SIS as a controller**

This manual also describes the use of SIS as an interface between Kongsberg Maritime’s multibeam echo sounders and third party data acquisition software packages. The two third party software packages that has been tested and verified by Kongsberg are at this moment Hypack ® and Qinsy ®. When SIS is working as a controller, the full SIS functionality is not needed.

An unlicensed version of SIS will work as a controller. The purpose of this is as follows:

- Provide installation parameters needed by the Processing Unit in real-time
- Provide runtime parameters (ping rate, coverage etc.)
- Operation and activation of the echo sounder
- Export of echo sounder datagrams to the third party software package
- Data logging in Kongsberg format

The data logging above is only provided for testing and debug in case of equipment problems.

In the case of using SIS as a controller all installation settings have to be set correctly inside the controller. In addition, position, gyro and attitude must be interfaced to the processing unit.

When SIS operates as a controller, the following will not be a part of the controller and have to be handled by the third party software:

- Installation parameters to calculate the correct depths (not needed by the sounder in real-time)
- Calibration
- Quality control of the data
- Data logging for daily operation
- Data cleaning and post-processing
- Creation of digital terrain models (DTM), charts, printouts etc.

The installation values needed in the controller will only be the one needed by the echo sounder itself to export quality data to third party software. Example: If the echo sounder is roll stabilized, it needs roll data, correct installation angles for motion sensor and sonar head.

### **Hypack ®**

The Hypack software package will treat the echo sounder as a separate sensor and provide the drivers for interfacing. The motion data needed for correction of the echo sounder data is read from the network (provided by the sounder) together with the range data. The position is interfaced and logged by Hypack in a standard way (read from serial line).

#### **Note**

*The motion data provided by the echo sounder is moved from it's initial position to the location of the echo sounder. This is done inside the echo sounder Processing Unit.*

---

### **Qinsy ®**

Qinsy read the echo sounder range datagrams from the network and all other sensors are interfaced by Qinsy directly. In other words, position and attitude data is interfaced to a serial line directly on the Qinsy PC. To provide correct timing of depths and attitude data the Qinsy PC and the Processing Unit need to be synchronized. This is done by connecting a 1PPS cable from the position system to the echo sounder Processing Unit as well as to the Qinsy PC itself. In addition ZDA clock datagrams has to be provided to the two units. If the echo sounder is roll stabilized then roll data has to be sent to the Processing Unit.

### **Important**

---

For detailed information on the setup of software from Hypack or Qinsy, refer to the manufacturer's documentation.

---

### **Note**

---

*Data logged in the Kongsberg format has been time tagged in the Processing Unit of the echo sounder. This means that the time tagging is accurate and reliable. If other logging systems are used, the time tagging of the data is the responsibility of that logging software if they bypass these files.*

---

## 3 GRAPHICAL USER INTERFACE

This section contains description of the graphical user interfaces and the parameters related to setting up the appearance of SIS.


### 3.1 The application window

All interactions with SIS take place via a windows based interface on the Operator Station.

When you launch SIS, the application window opens containing several frames that can be set up. Available options will depend on what instrument you are using.

The SIS application window appears below. A description of its parts follows.

Figure 3 The SIS application window



#### Description of the SIS application window

- A** Frame settings
- B** Active grid
- C** Rescan button
- D** Sonar systems detected, but not started.
- E** Current sonar system
- F** Status lamps for current sonar system
- G** Water Column Logging (WCL) status button

- H** Raw data logging status
- I** Pinging status
- J** Line counter
- K** Line number
- L** Time to line shift
- M** Current survey name
- N** Main menu
- O** Main toolbar
- P** Frame toolbar
- Q** Available frames
- R** Status bar

SIS defines a screen layout with up to seven simultaneous display windows (or frames). The boundaries between the frames can be shifted so that the frame sizes are adjusted to the user needs, but the system will make sure that no display frame is ever hidden behind another one. The information contents of each display frame can be changed according to the needs.

SIS has many windows, but there are always seven frames. You can choose from a list of windows for each frame, and you can save and read your own set up.

The frames are designed so that they will never overlap. This makes it impossible to hide one window behind another. You can change the size of the frames by moving the slide-bars. The four frames on the left are separated by three slide-bars which can be moved up and down, and the two frames in the middle are also separated with a slide-bar. There is also a slide-bar to the left of the four frames, and there is a slide-bar at the frame to the right.

The menu bar at the top contains common actions such as save/read settings, exit etc.

The next menu bar contains basic controls for all echo sounders. There are drop-down lists for surveys and survey settings, and for detected echo sounders and the echo sounder currently being operated. There are also control buttons to rescan for echo sounders, start/stop logging or pinging and line counting. Status lamps indicates hardware status for multibeam echo sounders.

In addition to the seven frames in the SIS main layout, up to five additional SIS frame can be opened in separate “tear-off” windows by from the **Manage Windows** menu. See *Manage windows* on page 35 for details

## 3.2 SIS frames

The various windows available in SIS are:

- Beam intensity
- Calibration
- Colour coded depth
- Cross track
- Geographical
- Helmsman Display
- Installation parameters
- Message service
- New survey
- Numerical display
- Planning module
- PU sensor status
- Runtime parameters
- Runtime Parameters Mini
- Scope display
- Seabed image
- Sensor Layout
- Sound velocity profile
- Stave display
- Survey administration
- Time series
- Waterfall
- Water column
- Empty frame

Note

---


*Only a selection are available for single beam echo sounders and GPS equipment.*

---

For detailed description of each of the available frames, please see

- *Windows and views* on page 51
- *Frame toolbars parameters* on page 169

Figure 4 Example of SIS frame setup



## Geographical

The **Geographical** window is used to display all geographical data such as:

- C-MAP background maps
- DXF-files
- Terrain models generated from ASCII xyz-files
- Terrain models from surveys
- Geographical net (geographic and projection net)
- Other kinds of background data from ASCII-files
- Depth difference in each grid cell
- Number of points inside each grid cell
- Display of seabed imagery data generated by the GridEngine

It is possible to display several terrain models at the same time, both the terrain model that is being generated by the current survey and terrain models generated from previous surveys. If the data is in ASCII xyz-files, a terrain model can be generated and displayed as background data.

The **Geographical** window uses OpenGL for smooth rendering. This means that all views are 3D enabled and can be rotated in any direction.

SIS uses projection coordinates to display the data. The projection is set from the **New survey** or **Survey administration** frames. You can define your own projection or choose from a wide range of predefined projections. A 7-parameter datum transformation is also available.

The **Geographical** window can display a lot of different information. You can select from a long list of features what to display.

Note that the terrain model can be display with various depth values:

- Z – the distance from the surface to the seafloor
- Zt – tide corrected depth using a tide file
- Zv – tide corrected depth based on GPS observations and a geoid model
- Zg – the distance from the sea floor to the geoid
- Zr – the distance from the sea floor to the ellipsoid

For each grid cell you can choose if you want to see the minimum, median or maximum depth.

Note

---

*SIS calculates the median depth, not the mean depth for each cell. The mean depth is an artificial depth which has not been observed, whilst the median is a real, quality controlled observed depth.*

---

## **Beam intensity**

The **Beam intensity** window shows the signal strength for each beam. Blue means amplitude detection and red is phase detection. Green indicates the quality for each measurement.

## **Cross track**

The **Cross track** window shows the depth from each beam. The x-axis can either be meters or beams. Blue is amplitude detection and red is phase detection.

## **Seabed image**

The **Seabed image** window logs seabed image data. The resolution in across direction depends upon the size of the window, the width of the swath and the resolution of the sonar. In the across

direction a grid will be created to give the highest possible resolution in the window, and then each and every ping is stacked on top of each other.

### **Numerical display**

The **Numerical display** window shows a list of current value of 36 different parameters. The parameters to show can be selected from a comprehensive list of available parameters.

Some of the parameters will give indication if the value exceed given limits by changing the background to yellow (warning) or red (error). This makes it possible to easily discover if there is a problem with some parts of the equipment. All exceptions are logged by **Message service**.

### **Message service**

All messages from SIS are stored in the SIS database, SISDB. You can open the **Message service** window to see all messages that have been generated, and when they arrived. It is possible to mask certain types of messages and write these to a file. You can also choose a time frame to display the messages from.

### **Helmsman Display**

The **Helmsman Display** window is usually used together with the **Planning module**.

When you have selected a planned line for surveying, the Helmsman Display window will show guidance information to the helmsman, such as position, depth, speed, course, cross track distance from planned line (XTE), etc.

There is also a history of XTE and a graphic presentation of the XTE and you can choose which of these parameters to display.

### **Colour coded depth**

The **Colour coded depth** window shows the depth from each beam. The y-axis is always time and the x-axis is always beam number.

### **New survey**

In the **New survey** window parameters defining a new surveys are created, including survey name, projection, background data, storage location, etc.

### **Survey administration**

In the **Survey administration** window you can define survey parameters, such as projection, background data to display and where to store the survey data on disk. Normally, the default set-up can be used.

## Planning module

The Geographical window can be set in Planning mode. From the **Planning module** survey lines can be created, survey areas can be defined and filled with parallel lines etc. You can save the planned lines to a planned job, and read a planned job from disk.

## Time series

The **Time series** window is used to display different kinds of time series. Normally heave, roll and pitch from the active sensor is displayed. The following can also be displayed:

- Depths and backscatter from four beams selected by the user
- Depth below the water surface for the most vertical beam
- Depth and backscatter of the centre beam
- Single beam and multibeam depths for comparison
- Height
- Heave, roll and pitch from active and/or inactive motion sensor

## Waterfall

The **Waterfall** window is fully implemented with 3D capabilities. You can zoom, pan and rotate freely in 3D, and the z-axis can be exaggerated to see small objects better.

## Water column

The **Water column** window shows a graphical representation of the beam formed data for the entire water column for each beam. This window is only available for echo sounders with water column capabilities.

## Sound velocity profile

SIS uses the depths generated in the Processing Unit. This means that the depths have already been corrected for sound speed profile. The current sound speed profile used by the Processing Unit is shown in the **Sound velocity profile** window.

## Scope display

The **Scope display** window can be used to investigate the receiver echo data. It is mainly used for test purposes. The data is not logged. This window is available for multibeam echo sounders.

## Stave display

The **Stave display** window shows a graphical representation of the signal level of all of the receiver elements (i.e. staves). This can be helpful for debug and for performance checks (display of

interference signals, air bubbles, saturation, etc.) The data is not logged. This window is available for multibeam echo sounders with stave display capabilities.

### **Installation parameters**

The **Installation parameters** window is used to set fixed installation parameters, including communication parameters to external sensors, installation offset angles and locations, calibration results, etc. These parameters are normally set only once. The parameters can not be modified during operation.

Built In Self Tests (BIST) are run from here.

### **Runtime parameters**

The **Runtime parameter** window contains parameters that can be changed during operation, including mode of operation, sound speed profile and filter settings.

In addition you may set the parameters employed by the Real Time Data Cleaning module.

### **Calibration**

In the **Calibration** window you will be presented to a cross-section of the data from the selected survey lines. The Geographical window must be set in calibration mode (C), the survey lines to use (at least two) for the calibration must be selected and a corridor along or across these survey lines must be defined. Then the pitch, roll, heading and time offsets can be altered to visually see the impact on the data in the defined corridor.

When new offsets are obtained these must be entered into the installation parameters.

### **PU sensor status**

The **PU sensor status** window shows how the PU's input sensors are set up. If any signal is missing, this is indicated by changed colour.

### **Runtime parameters Mini**

The **Runtime parameters Mini** window is a subset of the Runtime parameters menu with the most common altered parameters in a small window.

### **Sensor layout**

The **Sensor layout** window, display all defined sensors position in a 3D display.

---

**Note**


---

*This window is important to open because it will tell you if the installation parameters are entered correctly.*

---

**Related topics**

- *Manage windows* on page 35
- *Windows and views* on page 51

**Parameter references**

- *Frame toolbars parameters* on page 169


## 3.3 Toolbars

SIS has two types of toolbars. The Main toolbar is common for all frames. Each frame also has its own individual toolbar.

### 3.3.1 Main toolbar

The **Main toolbar** is located just below the **Main menu**. It contains several buttons and combo boxes.

Figure 5 Main toolbar



- A Settings:** You can select different display settings from this combo box. Choose between standard settings or create your own by selecting **Save Settings As...** in the **File** menu.
- B Active survey:** Select the active survey. All surveys are listed, both the surveys you log on and the ones imported. You can only calibrate the active survey.
- C Rescan:** Press the **Rescan** button, and the program will scan for available echo sounders on the network. If for some reason contact with the echo sounder is lost, it is not necessary to shut down and restart SIS.
- D Echo sounders - not started:** This combo box displays all the echo sounders SIS has detected on the network at start-up time or when doing a rescan. All multibeam echo sounders announce themselves on the network when they are active, and SIS will detect them automatically. Select the echo sounder you want to start from this list.

**E Current echo sounder:** This combo box displays which echo sounder is currently being operated. You must choose one at the time when setting the installation and runtime parameters for the echo sounder. Select the echo sounder you want to change parameters for from this list.

**F Status lamps:** These lamps are for multibeam echo sounders only and applies to current echo sounder.

- **Lamp 1:** PU/TRU status (Processing Unit/Transceiver Unit)
- **Lamp 2:** BSP status (Beamforming and Signal Processing)
- **Lamp 3:** SH status (Sonar Head)

While logging, the lamps will be continuously updated.

Green	Orange	Red	Grey
OK	Warning	Error	Connected hardware is not in use

**G WCol:** The **WCol** button shows if logging of **Water Column** data is *On* or *Off*. This button can not be clicked, it shows the logging status. The *On/Off* control is located in the **Water Column frame's show/hide menu**.

This button is always displayed, but is only active for echo sounders with water column capabilities (e.g. EM 710 and EM 3002).

**H Pinging:** Press this button to start and stop pinging. Start pinging to activate the echo sounder (i.e. sending sound into the water). The colour of the button is green while pinging and red when pinging is off.

The text in the button reflects the current status.

**I Logging:** Press this button to start and stop logging. Start logging to write data to disk. The colour of the button is green while logging and red when logging is off.

The text in the button reflects the current status.

Note \_\_\_\_\_

*If pinging is Off when logging is turned On, pinging will automatically be turned On. If logging is On and pinging is turned Off logging will automatically be turned Off.*

---

**J The Line cnt button** is used to create a new line without stopping the logging and then starting it again. The line count is incremented by one when button is pressed.

**K Line counter:** The text field displays the line count for the currently selected echo sounder. The line count is cyclic between 1 and 9999. It is possible to enter a line number manually.

If logging is *Off* the line count is for the next line started. If logging is *On* the count is for the current line.

**L Remaining time:** This field shows the remaining time to log in the current line, i.e. the time before a new line is started. The time unit is in minutes. (When 1 minute is displayed this indicates less than 1 minute logging remaining.)

**M Current survey:** This combo box displays the current survey name. You can select all surveys for the current echo sounder from this combo box. When selecting another survey, SIS will change to that survey and start logging to that survey when this is enabled.

This combo box is disabled when SIS is logging.

### Related topics

- *Frame toolbars* on page 31
- *Echo sounder – Not started list* on page 32
- *Current echo sounder* on page 33
- *Line counter toolbar set* on page 34

### 3.3.2 Frame toolbars

All frames have their own toolbar. On these toolbars there can be several buttons or just the Frames button. The most frequent buttons are:

- **Frames:** Press this button to select the content you want in that specific window frame.
- **Show/hide:** Press this button to open the **Show/hide** dialogue box.
- **Annotation colours:** Press this button to open the **Annotation colours** dialogue box.
- **Dynamic colours:** Press this button to open the **Dynamic colours** dialogue box. The dialogue box will only be launched if at least one or more surveys are loaded.

*Figure 6 Example of a frame toolbar*




The most common buttons are described in *Common display buttons* on page 43.

Special buttons for each frame are described in *Windows and views* on page 51

### 3.3.3 Echo sounder – Not started list

The **Not started** list will be displayed in a combo box found in the main toolbar.



The list contains all non-started echo sounders detected by SIS on the network. The list is linked to the autostart mechanism.

The combo box will only be displayed in two cases:

- 1 When echo sounders are detected by the system for the first time.
- 2 When the detected echo sounders differs from the set of echo sounders started in the previous SIS session. That is, if echo sounders have been added or removed from the network, and the autostart mechanism therefore is not activated.

In any other circumstance the autostart mechanism will start the echo sounders automatically and the combo box will be empty and not visible.

#### Note

---

*The Autostart of the echo sounder can be disabled/enabled under **Display** found by selecting **Tools**→**Custom...**→**Set parameters**.*

---

When you select an echo sounder from the list, you start the echo sounder and it will disappear from the list.

#### Note

---

*If for any reason an echo sounder fails during start (BIST, Built-In Self Test, 99 failure) the echo sounder will remain in the list and the combo box will still be visible. The reason for this is to allow you to correct the problem and try a rescan.*

---

If the licensing allows for only one started echo sounder, the combo box will be removed as soon as the start has been performed with a positive result.

If the licensing allows for several started echo sounders, the combo box will be removed only when the list is empty, i.e. when all echo sounders has been started.

### Related operational procedures


- *How to start pinging* on page 136
- *How to start the echo sounder* on page 134

### Parameter references

- *Display* on page 273

### 3.3.4 Current echo sounder

**Current echo sounder** gives you a list of the all echo sounders and other instruments that are connected to the SIS software. Only the current echo sounder is visible in the text field. Press the arrow to see the entire list or click in the text field.



Select an echo sounder from the list. This echo sounder is now available for configuration. Each echo sounder is identified by name and serial number and all displayed frames will be updated to show the information from this unit, if applicable. Only one echo sounder can be selected as current at any given instance, i.e. you can configure only one echo sounder at a time and you can see data (for example beam intensity, cross track, numerical data, etc.) only from this current unit.

### Related operational procedures

- *How to start pinging* on page 136
- *How to start the echo sounder* on page 134
- *How to interface a singlebeam echo sounder in SIS* on page 134
- *How to start and stop logging – Alternative 1* on page 141
- *How to start and stop logging – Alternative 2* on page 142
- *How to save data* on page 142


If you want to add instruments without a PU (Processing Unit/Rack) to the list, use the **External sensors** and **Instrument combinations** found on the **Tools** menu.

If you want to remove instruments without a PU (Processing Unit/Rack) from the list, use the **Remove instruments** found on the **Tools** menu.

### Parameter references

- *External sensors* on page 295
- *Instrument combinations* on page 302
- *Remove instruments* on page 303

### 3.3.5 Line counter toolbar set



The **Line counter** button and **Line counter** text field are found in the toolbar.

The Line counter textfield displays the line number for the currently selected echo sounder. The count is cyclic between 1 and 9999.

When the **Line counter** is pressed, the line count is incremented by one for all active, logging echo sounders and not only for current echo sounder.

#### Note

---

*If current echo sounder is not logging, nothing happens when the line counter button is pressed.*

---

The line count for an echo sounder can also be incremented by three other mechanisms in addition to using the line counter button:

- 1 The line count is incremented each time logging stops showing the next line to be logged. Only the count for the handled (current) echo sounder is affected.
- 2 To avoid very large log files (.all-files) the counter for all active echo sounders are incremented automatically every 30 minutes. This can be configured from the Main menu; **Tools**→**Custom...**→**Set parameters**. This, however, only happens when the counter has not been incremented by other means within the last 30 minutes, i.e. by pressing the line counter button or by stopping and starting logging.
- 3 The line counter may be manually edited, when not logging. The edited value is for the next logged line.

#### Note

---

*If several echo sounders are used and the line count initially is the same for all, it's important to notice that the counts may deviate after a while. This is due to the above described behaviour.*

---

### Related operational procedures

- *How to start the echo sounder* on page 134
- *How to start and stop logging – Alternative 1* on page 141
- *How to start and stop logging – Alternative 2* on page 142
- *How to save data* on page 142


## 3.4 View menu

The **View** drop-down menu gives you the following choices:

- *Manage windows* on page 35
- *Icons* on page 37
- *C-MAP detail level* on page 37
- *Colour palette* on page 38
- *Status bar* on page 39

### 3.4.1 Manage windows

**Manage Windows** is accessed from the **View** menu.




**Message Windows** may be used to define the active SIS frames. Seven frames are displayed in the SIS application window.

The contents of the frames can also be set using the **Frame** buttons in upper right corner of each frame. However, if you have to change the content of more than one frame, it may be faster to use this procedure instead of using the **Frame** button.

Choose the content of the frame(s) by selecting from the combo-boxes.

Remember to save your new settings. This is done with the **Save Settings** or the **Save Settings As...** from the **File** menu.

The frames are designated from #1 to #7 as shown below.




## Separate tear-off windows

It is possible to open any additional SIS frame in separate "tear-off" windows. Two new controls have been added to the bottom of the Manage Windows dialog box; a push button to open a new tear-off window and a combo box to select the frame for the new tear-off window.

- 1 Select the content of the tear-off window by selecting from the combo-box at the bottom of the Manage Windows dialog
- 2 Press the New button to apply selection

The SIS display may as an example appear as shown in figure below.



If the selected frame is already open in another window, the frame will be moved to the new tear-off window, and the other window will be emptied.

It is possible to have multiple tear-off windows open at the same time, a maximum of five tear-off windows are allowed. However, it is important to note that each open frame requires some processing power, so overloading the system by opening too many windows at the same time is possible. It is recommended to the CPU load. If the CPU load remains near 100% for any length of time, you may have to close one or more of the tear-off windows. Frames with high CPU load include the Geographical, Water Column, Stave Display, Seabed Image and (to a lesser degree) the Waterfall frame.

---

**Note**

*Parameters for size, location, and frame settings of the tear-off windows are not saved when settings are saved (File->Save Settings).*

*Screen capture of the tear-off windows are not stored by pressing ctrl+s. Only the SIS mainframe is captured by ctrl+s.*

---

### 3.4.2 Icons

The **Icons** menu is accessed from the **View** drop-down menu.

Choose between:

- **Small Icons:** This will make all the frame toolbar buttons smaller
- **Large Icons:** This will make all the frame toolbar buttons larger

### 3.4.3 C-MAP detail level

The **C-MAP detail level** is accessed from the **View** menu.

To specify the detail level of the C-MAP background, choose between the following display levels with increasing levels of details:

- Basic
- Standard
- Full

### Related topics

- *C-MAP – Licence administration* on page 304
- *Geographical – C-MAP manipulation mode* on page 183
- *C-MAP CM-93/3* on page 354

### 3.4.4 Colour palette

The **Colour palette** is accessed from the **View** menu.

Depending on light conditions where the SIS display is located the colours of may be changed to best adapt to the conditions.

Choose between the following colour palettes:


- **Day:** Bright day
- **Day Blackback:** Day with black background
- **Day Whiteback:** Day with white background
- **Dusk:** Dusk – less brightness to adapt to night vision
- **Night:** Night – lesser brightness to adapt to night vision

### Windows PaletteController

Each of above palettes use a colour scheme of 64 colours with different RGB value for each palette. If used together with **PaletteController**, all Windows colours can be set as well.

**PaletteController** is an additional SIS program found in the installation's **bin** directory. **PaletteController** can be used to set the Windows colours globally on your computer according to the colour palettes defined by SIS.

For **PaletteController** to take effect you must ensure that the **Windows Display Properties**→**Appearance** is set to **Windows Classic style** for Windows XP and to **Windows Choice** for other Windows platforms.




#### Note

*PaletteController is available for the Windows platform only*

### 3.4.5 Status bar

The **Status bar** is accessed from the **View** menu.

By selecting **Status bar** from the view menu you will be given the choice to display current value of four essential transducer parameters in a status bar at the bottom of the SIS display. By ticking the check box for each parameter, current parameter value will be continuously updated in the Status bar.



The following parameters can be displayed:

- Mode – current ping mode
- Depth – current depth
- Across – swath width in metres on the bottom
- Sound speed at transducer depth

## 3.5 Keyboard and mouse operations

In SIS there are different combinations of mouse and keyboard operations used to change the view or give quick access to selected functions. The combination of mouse and keyboard operation varies slightly depending on the frame you are working in. The keyboard and mouse operations for panning, rotating and zooming for each frame these functions applies to are presented in this section.

To understand how to rotate the grid, it may be helpful to visualize a “virtual trackball” in the centre of the view. To rotate the grid, click and drag the mouse as if you were trying to rotate this “virtual trackball”. For example, if you click the mouse in the centre of the view (i.e. the centre of the virtual trackball) and drag straight up or down, the virtual trackball will rotate about it’s horizontal axis (i.e. the x-axis). This results in the grid rotating purely about the x-axis.

If you click the mouse in the centre of the view and drag straight to the left or right, the virtual trackball will rotate about it’s vertical axis (i.e. the y-axis). This results in the grid rotating purely about the y-axis.

If you click the mouse at the edge of the view, and then drag the mouse, the virtual trackball will rotate about an axis perpendicular to the plane of the view (i.e. the z-axis). This results in the grid rotating purely about the z-axis.

### Keyboard and mouse in the Geographical view

Operation	Keyboard and mouse operation
Zoom to region	Left mouse button  Press left mouse button, drag the mouse to a new area and release the mouse button.
Pan	Right mouse button  Right click in the grid, hold down and move the view.
Zoom	Scroll the mouse wheel  To zoom in or out on the geographical view, scroll the wheel forward to zoom in, or backward to zoom out.
Rotate	Shift key + Right mouse button  To rotate the grid, hold down the Shift key, right click and drag the mouse.
Display high res. seabed image	Left mouse button + Shift key  Mark the area to display as seabed image by using left mouse button to mark first corner, then press the Shift key, then drag the mouse to desired end corner. Release buttons.

---

**Note**


---

*3D must be enabled to rotate the geographical grid.*

---

**Keyboard and mouse in the Planning module view**

Use the Ctrl key and the mouse to carry out any editing or manipulation of planned lines.

Operation	Keyboard and mouse operation
Accept or Cancel	Ctrl + Right mouse button  Use the Ctrl key while clicking the right mouse button to open the Confirm changes dialogue. Use left mouse button to accept or cancel as required.
Select a line or a polygon	Ctrl + Left mouse button  Selecting a line or a polygon is carried out by holding the Ctrl key down while clicking on the object to be selected. Objects already selected will be deselected.
Deselecting multiple objects	Ctrl + Right mouse button  Deselecting multiple objects can be carried out by holding the Ctrl key down while clicking on the right mouse button. This will open the Selected objects dialogue, where you can choose to deselect all selected lines, polygons or both.

**Keyboard and mouse in the Sound velocity profile view**

Operation	Keyboard and mouse operation
Zoom to a region	Left mouse button  Press left mouse button, drag the mouse to a new area and release the mouse button. Press the Zoom Reset Button to return the display to the original state.
Zoom	Ctrl key + Scroll the mouse wheel  To zoom in or out on the view, hold the ctrl key while scrolling the wheel forward to zoom in, or backward to zoom out. Press the Zoom Reset Button to return the display to the original state.
Pan	Alt key + Scroll the mouse wheel  To pan up or down along the profile, hold the Alt key while scrolling the wheel forward to pan down, or backward to pan up. Note that you can only use the pan functionality if you have zoomed the view.

### Keyboard and mouse in the Waterfall view


Operation	Keyboard and mouse operation
Pan	Right mouse button  To pan the waterfall grid, right click in the grid, hold down and move the view.
Zoom	Scroll the mouse wheel  To zoom in or out on the waterfall view, scroll the wheel forward to zoom in, or backward to zoom out.
Rotate	Shift key + Right mouse button  To rotate the grid, hold down the Shift key, right click and drag the mouse.

### Keyboard and mouse in the Sensor layout view

Operation	Keyboard and mouse operation
Pan	Right mouse button  To pan the waterfall grid, right click in the grid, hold down and move the view.
Zoom	Scroll the mouse wheel  To zoom in or out on the waterfall view, scroll the wheel forward to zoom in, or backward to zoom out.
Rotate	Shift key + Right mouse button  To rotate the grid, hold down the Shift key, right click and drag the mouse.

### Keyboard and mouse in the Calibration view

In Calibration mode the Geographical window has the following additional keyboard and mouse functionality:

To	Operation
Select a line	Ctrl + Left mouse button  To select a line, hold down the Ctrl key and left click on the line.
Open Calibration Action Quick Menu	Ctrl + Right mouse button  To open the Calibration Action Quick Menu, hold down the Ctrl key, right click in the view.
	
Select corridor	Ctrl + Left mouse button  Set the end points of the corridor by holding the Ctrl key down while clicking left mouse button on each end point.

## 3.6 Hotkeys

The following functional hotkeys are defined in SIS

Key	Function
F2	Toggles logging on/off
F5	New line
F10	Toggle pinging on/off
F4	Toggle grid shading on/off
F8	Toggle depth under cursor on/off
Ctrl-S	Screendump of the application window saved as bmp file

You may redefine the hotkeys used for toggling logging and pinging on/off and for selecting new line. This is done from **Tools→Custom...→Set parameters→Logging**.

## 3.7 Common display buttons


Each SIS frame holds a toolbar with command buttons for parameter and display settings applicable to that frame.

The display buttons holds the same functionality independent of what frame it applies to. The common display buttons are described in this section.

### Common display buttons


- *Annotation colours button* on page 44
- *Dynamic colours button* on page 45
- *Print button* on page 46
- *Zoom and view buttons* on page 47
- *Scale buttons* on page 49

### 3.7.1 Annotation colours button




**Display Colours:** You can change the colours of the various elements displayed by double-clicking in the check box(es). The **Colour Dialog** window will appear. New colours can be selected in a number of different ways (using the eye dropper tool, entering the RGB colour code, using predefined colours etc.).

Select the new colour and click **Accept** to apply. **Cancel** if you do not want to change the colour.



### 3.7.2 Dynamic colours button



- **Colour map:** Select which objects to set the dynamic colours to.
- **Colour wheel:** Set the colour representation of the dynamic colours. Drag the arrow to set the start and stop limits.
- **Direction:** Set the direction of the arrow (CW or CCW).
- **Overflow:** Choose an overflow strategy for the colours – only valid when fixed scaling is selected.
  - Clamp - lock to the limits
  - Wrap - restart when reaching a limit
  - Cut - do not show data outside the limits

- **Intensity:** Set the intensity of the colours in the colour map. This can be used to dim the colour map for low light conditions.
- **Scaling:** Select automatic or fixed scaling.
- **Data Range:** Manually set the range (max/min) for the selected objects. The total range is automatically found from the data.
- **Single Colour Ranges:** Click in the **Enable** check box to set a range of data values to a single colour. For each set of depth ranges a different colour can be chosen. Double-click in the right check box to open the **Colour Dialog** window.

#### Note

---


*The available settings varies slightly depending on what SIS frame the **Dynamic colour** button applies to.*

---

### 3.7.3 Print button



Press the **Print** button to print the view. The **Print Setup** dialog will open.



The following options are available:

- **Destination:** Select if you want to send the print to a postscript printer or to a file. Files are saved in postscript format (\*.ps).
- **Orientation:** Select page orientation.
- **Paper Size:** Select paper size.
- **Viewport:** Select **Current Area** to print current view.

Select **Keep Scale** to send a larger area to the printer set by the **Zoom to region** dialogue. When selecting **Keep Scale** the centre of the view will correspond to the centre of the printout.

- **Scaling:** Select **Optimize to Media** to print view with it's actual scale.

Select **Best Nice Value** to print the view with rounded scale values.

- **Annotation:** Show the scale on the printout or not.

Note

*Only postscript printers or plotters can be used.*

---

### 3.7.4 Zoom and view buttons

#### Zoom functionality

- in
- out
- to given region
- by mouse
- to ship
- to world
- reset zoom
- reset view
- pause

#### Zoom in



When you press the **Zoom in** button, the magnification of the view will increase.

#### Zoom out



When you press the **Zoom out** button, the magnification of the view will decrease.

#### Zoom to given region



Any user-defined region can be zoomed up to fill the display view. To define the region, perform the following:

- 1 Press the **Zoom to given region** button.  
A **Zoom to region** dialogue box will appear.
- 2 Fill in the desired scale and the centre coordinates.

### Zoom to world



When you press the **Zoom to world** button, the **Geographical window** will zoom out to an area covering all loaded survey data. Note that if the data areas are small and widely spread out the data may become invisible.

### Zoom to ship



When you press the **Zoom to ship** button, the **Geographical window** will zoom to wherever the ship is located in the world. This button will be disabled if no vessel is present.

### Zooming using the mouse

In addition to using the zoom buttons above you can also:

- Zoom in or out on the data by using the mouse wheel
- Zoom in on a specific region by pressing the left mouse button, drag the mouse to a new location and then release the mouse button

### Zoom Reset button



Reset the display after a zoom operation. This button is only active if the display has been zoomed. Clicking on this button will reset the start and stop ranges and the start and stop range modes.

### Reset View Button



Reset pan, zoom and rotation to default values.

### Pause button



Pause or continue the display of data. While paused, the display is visible, but not updated.

### 3.7.5 Scale buttons

#### Scale functionality

- auto scale
- auto scale once
- fixed scale

#### Auto Scale button



Set the **Start Range Mode** and the **Stop Range Mode** of both the depth and across axes to Auto.

When the **Start Range** is set to **Auto**, the start range of each axis is automatically set to the minimum value in the data set each time data is received. When the **Stop Range** is set to **Auto**, the stop range of each axis is automatically set to the maximum value in the data set each time data is received.

This button provides a quick and convenient way to set both the start and stop ranges to Auto.

Pressing this button is equivalent to opening the **Show/Hide** dialogue and selecting **Start Range**→→**Auto** and **Stop Range**→→**Auto** for both the depth and across axes.

#### Auto Scale Once button



Set the **Start Range Mode** and the **Stop Range Mode** (of both the depth and across axes) based on the values of the current data set, then lock to this range setting for the remaining of the data.

The fixed start and stop range values in the **Show/Hide** dialogue will be updated with the new values. This is a quick and convenient way to change to Fixed range mode and simultaneously update the fixed start and stop ranges with values appropriate for the current water column data.

#### Note

---

*Pressing this button will update the Fixed start range value and the Fixed stop range value in the Show/Hide dialogue.*

---

### Fixed Scale button



Set the **Start Range Mode** and the **Stop Range Mode** of both the depth and across axes to Fixed. The start and stop ranges will be set to the values that were last entered in the respective **Start/Stop Range** text boxes in the **Show/Hide** dialogue.

This button provides a quick and convenient way to set the start and stop ranges of both axes to **Fixed**.

Pressing this button is equivalent to opening the **Show/Hide** dialogue and selecting **Start Range**→→**Fixed** and **Stop Range**→→**Fixed**.

Note that this is not equivalent to clicking on the **Auto Scale Once** button because the Fixed Start/Stop Range values in the **Show/Hide** dialogue are not updated in this case.

## 4 WINDOWS AND VIEWS

This chapter describes the various windows shown by SIS.

Seven frames can be displayed at the same time. The content of each and every frame is defined from the **View→Manage Windows** menu or by using the **Frames** button.

When the wanted frame configuration has been set up you may save the frame configuration for later retrieval. The frame configuration is saved from the main menu, **File→Save settings**.

### Monitoring Windows

- *Geographical view* on page 52
- *Beam intensity view* on page 56
- *Colour coded depth view* on page 57
- *Cross track view* on page 58
- *Seabed image view* on page 60
- *Numerical display* on page 62
- *Message service view* on page 62
- *Helmsman display view* on page 63
- *Time series view* on page 65
- *Waterfall view* on page 66
- *Water column view* on page 67
- *Sound velocity profile view* on page 70
- *Scope display* on page 72
- *Stave display* on page 73
- *PU sensor status view* on page 77

### Survey administration windows

- *New survey window* on page 79
- *Survey administration window* on page 81
- *Planning module window* on page 82

### Parameter setup windows

- *Installation parameters window* on page 83
- *Runtime parameters window* on page 84
- *Runtime parameters mini view* on page 85
- *Sensor layout view* on page 87

### Calibration window


- *Calibration view* on page 88

# 4.1 Geographical view

The **Geographical** window is either accessed through **View→Manage Windows** or by selecting it from the **Frames** button.

## Purpose

The main purpose of the **Geographical** window is to show geographical data like surveys, shiptracks, coverage, planned lines and so on. The window consists of a geographical region with a toolbar on top. It can also be referred to as main window. This window is valid for all instruments.


















## Toolbar buttons



Figure 7 Toolbar example



The toolbar of the **Geographical** window holds the following buttons (from left to right):

Click this button	To
	Enter the geographical display options
	Set annotation colours
	Set dynamic colours

Click this button	To
	Print the view
	Show depth under cursor
	Toggle grid shading on/off
	Toggle between 2D or 3D
	Enter inspection mode
	Use the position and distance measure
	Enter KSGPL edit mode (when selected)
	Enter planning edit mode (when selected)
	Enter calibration edit mode (when selected)
	Follow ship
	Zoom to ship
	Zoom to world
	Zoom to given region
	Zoom in
	Zoom out

Click this button	To
	Load background data
	Enter C-Map manipulation mode (when selected)

#### Note

*There can only be one edit button activated at a time.*

---

### Modeless operation


- To open the **Options** menu as a modal dialogue, left click the **Option** button.
- To open the **Options** menu as a modeless dialogue, hold down the CTRL key and left click the **Option** button. In this mode, you can continue to use the SIS user interface while the dialogue is open.
- To open the **Options** menu as a modeless dialogue that always remains on top of other windows, hold down the CTRL+SHIFT keys and left click the **Option** button. In this mode, you can continue to use the SIS user interface while the dialogue is open and the dialogue will always remain on top of the SIS user interface.

#### Note

*The “modeless” operation of the Options menu is not fully implemented. If a parameter is changed via the SIS user interface while the dialog is open, the dialog will not be updated to reflect the change. For example, if you use the 'S' toolbar button toggle grid shading while the dialog is open, the grid shading setting of the Options dialog will retain its current setting. The next time you apply settings from the dialog the grid shading will be toggled back to its original setting. Although the modeless operation is not fully implemented, it has been included in this release because it is still a useful feature, because most of the actions you can perform via the SIS user interface do not affect the dialogue settings.*

---

## Quick menu



The **Geographical window** have a quick menu accessed by clicking on the right mouse button inside the view. The following features can be accessed from this menu:

- **Menubar**
  - Annotation colours
  - Dynamic colours
  - Options
  - Print
- **Icons**
  - Small icons
  - Large icons
- **Frames**
  - Empty
  - All available display frames
- **Activate/Deactivate** - toggle between Activate/Deactivate depending on the current mode of the **Geographical window**

## Related operational procedures

- *How to display realtime depths* on page 138
- *How to display a smooth surface* on page 140
- *How to look for artifacts* on page 140
- *How to display seabed imagery data in the Geographical view* on page 138

## Parameter references

- *Geographical – Display options* on page 170
- *Geographical – Show depth under cursor* on page 181
- *Geographical – Grid shading* on page 181
- *Geographical – 2D or 3D* on page 181
- *Geographical – Inspection mode* on page 181
- *Geographical – Compass button* on page 182
- *Geographical – KSGPL edit mode* on page 182
- *Geographical – Planning edit mode* on page 182
- *Geographical – Calibration edit mode* on page 182
- *Geographical – Follow ship* on page 183
- *Geographical – Load background data* on page 183

- *Geographical – C-MAP manipulation mode* on page 183
- *Geographical – Information field* on page 183

### Related topics

- *Keyboard and mouse in the Geographical view* on page 40


## 4.2 Beam intensity view

The **Beam intensity** window is either accessed through **View→Manage Windows** or by selecting it from the **Frames** button.

### Purpose

The **Beam intensity** view gives a graphical presentation of the beam intensity and signal quality factors.

This window applies to multibeam echo sounders.



The window contains scales along the left and right vertical axes, giving the signal strength in dB values on left side and the quality measure for the data on right side. The beam numbers are shown along the horizontal axis. This number depends on the echo sounder model.

The window presents two types of bars, either red or blue, for each individual beam. The bar colour shows what type of bottom detection used for each beam; blue for amplitude detection and red for phase detection.



The value of each bar is the backscatter signal strength of the bottom presented in dB. The values are corrected for system parameters, but not for any dependence upon angle of incidence.

Normally the backscatter signal strength will be highest straight down, typically -15 dB, and lowest in the outer beams, typically -35 dB. The signal strength depends on bottom material type and roughness ( $\pm 15$  dB or more).

The green bar shows a data quality measure for each beam. Small values (on a scale from 0 to 64 or 128) convey good data quality.

### Toolbar buttons

The toolbar of the **Beam intensity** window holds the following buttons (from left to right):

Click this button	To
	Enter the beam intensity view's show/hide options
	Set annotation colours

### Related operational procedures

- *How to verify echo sounder main functions* on page 138

### Parameter references

- *Beam intensity – Show/hide* on page 185


## 4.3 Colour coded depth view

The **Colour coded depth** window is either accessed through **View→Manage Windows** or by selecting it from the **Frames** button.

### Purpose



The **Colour coded depth** window shows the depth per beam shown by colour codes. A history buffer of varying size is used. The size of the history buffer depends on the size of the display. One vertical screen unit (pixel) is used per ping. Increasing the vertical size of the display area increases the number of vertical screen units, thus increasing the history buffer size.

The **Colour coded depth** window applies to multibeam echo sounders.



**Toolbar button**

The toolbar of the **Colour coded depth** window holds the following buttons (from left to right):

Click this button	To
	Enter the colour coded depth show/hide options
	Set dynamic colours

**Parameter references**


- *Colour coded depth – Show/hide* on page 186

**4.4 Cross track view**

The **Colour coded depth** window is either accessed through **View→Manage Windows** or by selecting it from the **Frames** button.

**Purpose**

The **cross track** window shows the measured depths in all beams from the last ping. This window applies to the multibeam echo sounders.





The display contains a depth scale along the left-hand (vertical) axis and beam numbers or metres along the horizontal axis.

Different colours are used to show if a beam has a valid bottom detection, and if so what type of detection has been used. Red is used to show beams with phase detection, blue is used to show beams with amplitude detection. Beams without any detection are not shown.

### Toolbar buttons

The toolbar of the **Cross track** window holds the following buttons (from left to right):

Click this button	To
	Enter the cross track display options
	Set annotation colours

### Modeless operation

- To open the **Options** menu as a modal dialogue, left click the **Option** button.
- To open the **Options** menu as a modeless dialogue, hold down the CTRL key and left click the **Option** button. In this mode, you can continue to use the SIS user interface while the dialogue is open.
- To open the **Options** menu as a modeless dialogue that always remains on top of other windows, hold down the CTRL+SHIFT keys and left click the **Option** button. In this

mode, you can continue to use the SIS user interface while the dialogue is open and the dialogue will always remain on top of the SIS user interface.

#### Note

---

*The “modeless” operation of the Options menu is not fully implemented. If a parameter is changed via the SIS user interface while the dialog is open, the dialog will not be updated to reflect the change. For example, if you use the 'S' toolbar button toggle grid shading while the dialog is open, the grid shading setting of the Options dialog will retain its current setting. The next time you apply settings from the dialog the grid shading will be toggled back to its original setting. Although the modeless operation is not fully implemented, it has been included in this release because it is still a useful feature, because most of the actions you can perform via the SIS user interface do not affect the dialogue settings.*

---

#### **Related operational procedures**

- *How to verify echo sounder main functions on page 138*

#### **Parameter references**


- *Cross track – Display options on page 186*

## **4.5 Seabed image view**

The **Seabed image** window is either accessed through **View→Manage Windows** or by selecting it from the **Frames** button.

#### **Purpose**

The **Seabed image** displays the seabed backscatter data. For each ping a straight line is plotted, this covers the swath width. The darkness of the display at any point represents the reflectivity of the bottom.





The horizontal distance between the outermost crosses in the view is set by the swath width across parameters max and min. If these are set to be  $\pm 50$  m, the total distance is 100 m. This can be used to make rough dimension estimates of artefacts on the seabed.

This window applies to the multibeam echo sounders.

### Toolbar button


The toolbar of the **Seabed image** window holds the following buttons (from left to right):

Click this button	To
	Enter the seabed image show/hide options
	Print the view

### Parameter references

- *Seabed image – Show/hide* on page 189

## 4.6 Numerical display



The **Numerical display** window is either accessed through **View→Manage Windows** or by selecting it from the **Frames** button.

The **Numerical display** window allows you to monitor various SIS parameters. The parameters cannot be changed here. Exceeded limits are shown by red.

If you press the button next to the text, a list with selectable parameters will appear. Choose the parameter you want to monitor.

This window applies to all instruments.

Some parameters applies to specific instruments only.

### Related operational procedures

- *How to monitor the external sensors in SIS* on page 137
- *How to monitor the survey progress* on page 163
- *How to verify echo sounder main functions* on page 138

## 4.7 Message service view

The **Message service** window is either accessed through **View→Manage Windows** or by selecting it from the **Frames** button.

### Purpose

The **Message service** instantaneously displays all system generated information, warnings and error messages.

This window applies to all instruments.

The screenshot shows a software window titled 'Message service' with a dropdown arrow. Below the title bar, there are date and time selection controls. The 'From date/time' row shows Year: 2008, Mon.: 10, Day: 17, Hour: 10, Min: 33, Sec: 16. The 'To date/time' row shows Year: 2008, Mon.: 10, Day: 17, Hour: 13, Min: 32, Sec: 23. Below these are checkboxes for 'Hide message type' with options 'Info', 'Warning', and 'Error', all of which are currently unchecked. There is a 'File name' text box followed by an ellipsis button, and then buttons for 'Show', 'Print', 'Delete', and 'Help'. At the bottom, there is a table with four columns: 'Date', 'Time', 'Type', and 'Message'.

Date	Time	Type	Message
2008 10 17	10:33:16	3	Change in time difference too big
2008 10 17	10:33:26	3	Change in time difference too big
2008 10 17	10:33:37	3	Change in time difference too big
2008 10 17	10:33:47	3	Change in time difference too big


### Related operational procedures

- *How to monitor the external sensors in SIS* on page 137
- *How to monitor the survey progress* on page 163

## 4.8 Helmsman display view

The **Helmsman Display** window is either accessed through **View→Manage Windows** or by selecting it from the **Frames** button.

Purpose



The **Helmsman Display** provides steering guidance of the ship relative to planned survey lines.

This window applies to all instruments.

A line may have several waypoints, and the DTK, XTE, CMG and DST deviation indicators all show their values to the next waypoint or to the current line segment. The scale changes automatically. Red and green arrows indicate that the helmsman have to steer port or starboard to relocate. Before the ship reaches the start of the line, the indicator will form an arrow pointing downwards.

When reaching the end of the line (or before entering the line) the Helmsman Display will continue to display the ship's position relative to the continuation of the last line segment of the planned line.

Note \_\_\_\_\_

*The **Helmsman display** must be active when SIS is controlling the Autopilot.*

Toolbar buttons

The toolbar of the **Helmsman display** window holds the following buttons (from left to right):

Click this button	To
	Enter the helmsman display show/hide options
	Set annotation colours

Related operational procedures

- *How to start the Remote Helmsman Display on page 166*
- *How to plan a new job in SIS on page 162*
- *How to retrieve a planned job on page 163*
- *How to display planned lines on the Remote Helmsman Display on page 166*

### Parameter references

- *Helmsman display – Show/hide* on page 191

## 4.9 Time series view

The **Time series** window is either accessed through **View→Manage Windows** or by selecting it from the **Frames** button.

### Purpose

The **Time Series** window is used for presenting external interfaces or depth information as time series. Information from one or more sensors or beams can be selected.

Time series may be useful for detection of incorrect performance of the sensors or of incorrect depth determination.



### Toolbar buttons

The toolbar of the **Time series** window holds the following buttons (from left to right):

Click this button	To
	Enter the time series show/hide options
	Set annotation colours
	Clear plot

### Related operational procedures

- *How to monitor the external sensors in SIS* on page 137

### Parameter references

- *Time series – Show/hide* on page 193


- *Time series – Clear plot* on page 194

### 4.10 Waterfall view

The **Waterfall** window is either accessed through **View→Manage Windows** or by selecting it from the **Frames** button.

**Purpose**





In the **Waterfall** window the depth profiles from a number of pings are displayed as a function of across-track horizontal distance with a small vertical offset between each profile. This gives a crude 3D representation of the most recently measured bottom area.



Note that the colour coding applied to the profiles shows depth levels, not bottom detection.

**Toolbar buttons**

The toolbar of the **Waterfall** window holds the following buttons (from left to right):

Click this button	To
	Enter the Waterfall show/hide options
	Set annotation colours
	Set dynamic colours
	Reset the view

**Related operational procedures**

- *How to verify echo sounder main functions* on page 138

**Parameter references**

- *Waterfall – Show/hide* on page 195

**Related topics**

- *Keyboard and mouse in the Waterfall view* on page 42

## 4.11 Water column view

The **Water column** window is either accessed through **View→Manage Windows** or by selecting it from the **Frames** button.


**Purpose**

The Water column display shows a graphical image of biomass and other acoustic reflectors that might be present in the water column. The received amplitude of the reflected signal through the entire water column for each beam is presented. The vertical scale on the left of the display shows the depth in metres. The horizontal scale along the bottom of the display shows the across track distance in metres. The seafloor is shown as a yellow or red band in the data view.

The display may be found useful for debugging and for habitat monitoring.

The **water column** window applies to multibeam echo sounders with water column capabilities.

*Figure 8 Water column data with associated seabed image – passing a wreck*



#### Note

*Sound velocity corrections and ray bending corrections are not applied.*

### Water column logging

Water column data can selectively be logged to either the standard log file (.all) or to a separate water column file (.wcd). Water column datagrams can not be logged to both files simultaneously.

Water column logging to separate file must be enabled in the **Output setup** tab under **Installation parameters**.


Logging is toggled on/off from the Water column **show/hide** menu.

Please note that the logged data amount is very large, that is, typically 1 to 2 Gigabytes per hour.

Separate water column data (.wcd) files may optionally be logged to a disk different from that used for the raw data (.all) files. Water column data file locations are set from the **Logging** option accessed from **Tools**→**Custom**→**Set Parameters** for details.

## Zooming

It is possible to zoom in to a region of the grid by clicking the left mouse button and dragging a rectangle around a region of the grid. When the left mouse button is released, the region of the grid to which you have zoomed will be displayed.









Note that the **Zoom Reset** button now will be enabled, i.e. not longer dimmed. It is possible to zoom in even further, by clicking and dragging a rectangle inside the zoomed region.

To reset the zoom, click the **Zoom Reset** button. This will return the display to original scale. You can also reset the zoom by selecting one of the auto range options from the **Show/Hide** dialogue.

## Toolbar buttons

The toolbar of the **Water column** window holds the following buttons (from left to right):

Click this button	To
	Enter the Water Column show/hide options
	Set annotation colours

Click this button	To
	Set dynamic colours
	Pause the water column display
	Reset zoom
	Scale the axes automatically
	Scale the axes to currently received data
	Scale the axes to fixed values

### Related operational procedures

- *How to verify echo sounder main functions* on page 138
- *How to log water column data* on page 142

### Parameter references

- *PU communication – Output setup* on page 230
- *Water column – Show/hide* on page 196
- *Water column – Logging* on page 199
- *Logging* on page 274


## 4.12 Sound velocity profile view

The **Sound velocity profile** window is accessed either through **View→Manage Windows** or by selecting it from the **Frames** button.

### Purpose




The **Sound velocity profile** window is used for displaying the sound velocity profile being used by the multibeam echo sounder. It is not an editor.

The profile is a sequence of points. These have coordinates with increasing depth values.



### Toolbar buttons

The toolbar of the **Sound velocity profile** window holds the following buttons (from left to right):

Click this button	To
	Enter the Sound Velocity Profile show/hide options
	Set annotation colours
	Reset zoom

### Related operational procedures

- *How to monitor the external sensors in SIS on page 137*
- *How to collect the sound velocity profile on page 125*
- *How to convert your sound velocity profile to SIS format on page 126*
- *How to modify and load a sound speed profile into SIS on page 132*

### Parameter references

- *Sound velocity profile – Show/hide* on page 200

### Related topics

- *Keyboard and mouse in the Sound velocity profile view* on page 41
- *SVP Editor* on page 318.

## 4.13 Scope display


The **Scope display** window is accessed either through **View→Manage Windows** or by selecting it from the **Frames** button.

### Purpose

The **Scope display** is used for investigating the receiver echo data. It is mainly used for test purposes. The data is not logged.

The Scope display window applies to all multibeam echo sounders.

The data is presented as an xy series, having time on the horizontal x-axis and receiver echo level on the vertical y-axis. Beams close to normal incidence will have short echo and a noisy split beam phase signal. The outer beams will normally have a long echo and a well-defined phase curve. The range for the bottom detection is indicated by a vertical dotted line. Amplitude detection, filtered amplitude detection and phase detection are plotted.










Beam number to investigate is selected from **Runtime parameters→Simulator**. For system with dual swath capability the Swath number for the Scope Display is also selected from here.

The example above shows a phase detection for beam number 30.

### Toolbar buttons

The toolbar of the **Scope display** window holds the following buttons (from left to right):

Click this button	To
	Enter the Scope display show/hide options
	Set annotation colours
	Pause the scope display
	Reset zoom
	Scale the axes automatically
	Scale the axes to currently received data
	Reset zoom

### Parameter references

- *Scope display – Show/hide* on page 200

## 4.14 Stave display


The **Stave display** window is accessed either through **View→Manage Windows** or by selecting it from the **Frames** button.

### Purpose

The **Stave display** window shows a graphical presentation of the status of all the receiver elements or staves in the multibeam. The number of staves varies from multibeam to multibeam.

The Stave display can be helpful for debugging and verifying the performance of a system, establishing if there is interference from other systems, if there are air bubbles etc. The data is not logged.

This window applies to multibeam echo sounders with stave display capabilities.











The Stave display presents a grid in which each row of the grid corresponds to one data sample, and each column in the grid corresponds to one receive stave. Each grid cell shows the received signal level for the corresponding sample and stave.


The scale along the left vertical axis shows the sample number, the scale along the right vertical axis shows the range in meters, and the scale along the horizontal axis at the bottom shows the stave number.

### Toolbar buttons

The toolbar of the **Stave display** window holds the following buttons (from left to right):

Click this button	To
	Enter the Scope display show/hide options
	Set annotation colours
	Set dynamic colours
	Pause the scope display
	Reset zoom
	Scale the axes automatically
	Scale the axes to currently received data
	Reset zoom

## Zooming




You may zoom in to region of the grid by clicking the **left mouse** button and dragging a rectangle around a region of the grid.

When the left mouse button is released, the region of the grid to which you have zoomed will be displayed. Note also that the **Zoom Reset** button will now be enabled (i.e. it is no longer dimmed). It is possible to zoom in even further by clicking and dragging a rectangle inside the zoomed region.

To reset the zoom, click the **Zoom Reset** button. This will return the display to the scaling mode that existed prior to the original zoom operation. You can also reset the zoom by selecting one of the auto range options from the **Show/Hide** dialogue.

## Displaying cell information

It is possible to display the sample number, stave number, TVG and level for any grid cell. To display the cell information, hold down the **Ctrl** key and click **left mouse** button on the desired grid cell. Because the size of the grid cells sometimes is very small (down to several cells per screen pixel), it may be necessary to first zoom into a region of the grid before clicking on a cell.




The cell information will remain on the screen and will be updated in real time as stave data is received until the user left clicks somewhere inside the grid.

The user can repeatedly display cell information for several cells by holding down the **Ctrl** key and repeatedly clicking **left mouse** button on different grid cells. In this case, it may be helpful to pause the display first (otherwise the data will continue to be updated in real time).

### TVG curve

It is possible to display the TVG (Time Varying Gain) curve on top of the stave data. The TVG curve can be shown or hidden from the **Show/Hide** dialogue. The TVG curve scale is not shown, however it is possible to determine the TVG value at any location on the curve by pressing the **Ctrl** key and **left mouse** button on that location on the curve.



### Parameter references

- *Stave display – Show/hide* on page 201

## 4.15 PU sensor status view

The **PU sensor status** window is accessed either through **View→Manage Windows** or by selecting it from the **Frames** button.

The window is intended for giving an overview of the current reception status of all selected sensor inputs on a PU. It shows which sensors are selected as active sensors. The information refers to the PU (Processing Unit) of the echo sounder selected as **Current echo sounder** combo box in the **Main** toolbar.

PU Sensor input status						
	COM1	COM2	COM3	COM4	UDP2	UDP5
GGA	P					
GGK						
GGA_RTK						
GST						
SIMRAD90						
Attitude		HM				
MK39 Mod2 Attitude, no heave						
HDT Heading						
SKR82 Heading						
ROV. depth						
ZDA Clock						
Height, special purpose only						
DBS Depth						
DBT Depth						
EA500 Depth						
ATTVEL						
1PPS Clock Synch.						

P = active position sensor  
 M = aktiv motion/attitude sensor  
 H = active heading sensor

Reload

The status information is presented as a matrix with columns with the PU input ports and a row for each of the available sensor types. The settings in this matrix reflects the settings in the Installation parameters frame (i.e. **Installation parameters**→**PU Communication Setup**→**Input Setup**). Colours are used to represent the status as follows:

- White:** Combination not selected.
- Green:** Input from sensor selected and received
- Red:** Input from sensor selected, but not received.
- Yellow:** Input from sensor selected and received but having poor quality.

Any letters in the marked combinations are used to indicate which combination is set as the active sensor. Different letters are used in the different supported languages. The English equivalents are:

- P:** The marked combination is set as active position sensor.
- M:** The marked combination is set as active motion attitude sensor.
- H:** The marked combination is set as active heading sensor.

The display is updated with a frequency of 1 Hz and any changes done in the **Installation Parameters** frame will be reflected.

Errors (red indications) and poor quality (yellow indications) will be reported to the error message system and may be viewed in the **Message Service** frame. The problem will also be indicated by setting the appropriate colour (red or yellow) in the PU status lamp in the **Main toolbar** in SIS. Errors will have priority over bad quality in the lamp setting.

---

**Note**

*Poor quality will only be reported for sensors selected as active.*

*PU sensor input status frame will only contain information for a PU if the PU has been started (i.e. selected in the “Not Started” combo box in the “Main toolbar”).*

---

### **Related operational procedures**

- *How to monitor the external sensors in SIS* on page 137

### **Parameter references**

- *PU communication – Input setup* on page 226

### **Related topics**

- *Main toolbar* on page 29
- *Current echo sounder* on page 33
- *Message service view* on page 62

## **4.16 New survey window**

The **New survey** window is accessed either through **View→Manage Windows** or by selecting it from the **Frames** button.

### **Purpose**

The **New survey** setup guides you through the configuration of all essential survey parameters. These include projection data, background maps, storage location and data gridding parameters. These are parameters that are vital for the data acquisition, and incorrect settings may not be possible to correct for in post processing.

## Note

---

*To avoid having to set all the survey parameters every time a new survey is created, we advise you to define your own Survey template from the **Survey administration** window, and select this template as basis for your new survey.*

---

The **New survey** parameters can be saved to current or all survey templates, and it is thereby not required to set the survey parameters more than once for a survey.

The **New survey** window contains the following tab-menus:

- **Basic parameters** – used to create and identify the new survey
- **Storage options** – used to specify parameters for SIS raw data logging
- **Advanced options** – contains the following sub-tabs:
  - Background data – used to specify background data such as projection, background map, tide and geoid data
  - Projections – used to specify what datum and projection to use for the survey
  - GridEngine Parameters – used to set the cell size when using the **GridEngine** gridding method

The parameters defined under **New survey** may also be accessed from the **Survey administration** window.

## Related operational procedures

- *How to configure your survey* on page 101
- *How to enter parameters for a new survey* on page 105
- *How to enter survey parameters* on page 102
- *How to define a new projection and datum transformation* on page 107

## Parameter references

- *Basic parameters* on page 216
- *Storage options* on page 219
- *Background data* on page 220
- *Projection parameters* on page 222
- *GridEngine parameters* on page 222

## Related topics

- *Survey administration window* on page 81

## 4.17 Survey administration window

The **Survey administration** window is accessed either through **View→Manage Windows** or by selecting it from the **Frames** button.

### Purpose

The **Survey administration** setup allows you configuration of all essential survey parameters. These include projection data, background maps, storage location and data gridding parameters. These are parameters that are vital for the data acquisition, and incorrect settings may not be possible to correct for in post processing.

In addition, the **Survey administration** is an administrative tool for handling several survey templates.

The **Survey administration** window contains the following tab-menus:

- **User handling** – used to identify the SIS user of the survey
- **Background data** – used to specify background data such as projection, background map, tide and geoid data
- **Survey template handling** – contains the same sub-tabs as found in the **New survey** window:
  - **Basic parameters** – administrative data for the available survey templates
  - **Storage options** – used to specify parameters for SIS raw data logging
  - **Advanced options** – contains the following sub-tabs:
    - \* **Background data** – used to specify background data such as projection, background map, tide and geoid data
    - \* **Projections** – used to specify what datum and projection to use for the survey
    - \* **GridEngine Parameters** – used to set the cell size when using the **GridEngine** gridding method
    - \* **CUBE parameters** – used to set the grid specifications when CUBE is being used

### Related operational procedures

- *How to configure your survey* on page 101
- *How to enter parameters for a new survey* on page 105
- *How to enter survey parameters* on page 102
- *How to define a new projection and datum transformation* on page 107

### Parameter references

- *Basic parameters* on page 216
- *Storage options* on page 219
- *Background data* on page 220
- *Projection parameters* on page 222
- *GridEngine parameters* on page 222
- *User handling* on page 224
- *CUBE parameters* on page 225

### Related topics

- *New survey window* on page 79
- *CUBE* on page 375

## 4.18 Planning module window

The **Planning module** window is accessed either through **View→Manage Windows** or by selecting it from the **Frames** button.

### Purpose

The **Planning module** in SIS is a tool that can be used to create and display survey lines. These can be parallel lines, lines within a polygon or turns. The lines can be edited, changed direction of, extended or cut. Guidance information relative to the active survey line can be sent to the Helmsman display.

### Note

---

All planning buttons are disabled until this the Planning module is activated by:

- 1 Select **Planning** from the Show/Hide option of the Geographical window
  - 2 Press the **Planning** button **P**
- 

### Planning features

The Planning module has three elements:

- **Jobs** – used to create and save a new job, or to reactivate an existing job
- **Remote** – used to transfer data to a remote Helmsman Display
- **Objects** – used to create and manipulate lines and polygons within an existing job

### Related operational procedures

- *How to plan a new job in SIS* on page 162

- *How to retrieve a planned job* on page 163
- *How to display planned lines on the Remote Helmsman Display* on page 166

### Parameter references

- *Planning – Jobs* on page 202
- *Planning – Remote* on page 202
- *Planning – Object* on page 203

### Related topics


- *Keyboard and mouse in the Planning module view* on page 41

## 4.19 Installation parameters window

The **Installation parameters** window is accessed either through **View→Manage Windows** or by selecting it from the **Frames** button.

### Note

*Pinging must be Off to configure the Installation Parameters*



### Purpose

The **Installation parameters** window is used to set parameters for all navigation systems, motion sensors and sonar heads or transducers connected to the hydrographic system. These parameters include:

- **Sensor locations (x, y, z):** Used to input the relative locations of the sensors
- **Angular offsets:** Input of installation angles of the sensors
- **Waterline reference:** Definition of the ship's draft relative to the sensors
- **Position input system:** Setup of position input
- **Clock reference:** Definition of clock source
- **System parameters:** Used for setting up Tx and Rx opening angles and backscatter parameters
- **PU input/output datagrams:** Definition and setup of input and output datagrams
- **BIST:** Used for doing the Built-In Self Tests

### Related operational procedures


- *How to open the installation parameter interface* on page 112
- *How to modify the installation parameters* on page 112

### Parameter references

- *PU communication – Input setup* on page 226
- *PU communication – Output setup* on page 230
- *PU communication – Clock setup* on page 232
- *Sensor setup – Settings* on page 233
- *Sensor setup – Locations* on page 237
- *Angular Offsets for EM 1002* on page 238
- *System parameters for EM 1002* on page 239
- *BIST – Built-In Self Test* on page 240

## 4.20 Runtime parameters window

The **Runtime parameters** window is accessed either through **View→Manage windows** or by selecting it from the **Frames** button.



The window will differ, depending on what kind of echo sounder you have.

Equipment with a Processing Unit (i.e. all multibeam echo sounders) contains parameter setting pages for the following features:

- **Sounder main:** Used to set ping mode, swath coverage, beam spacing, depth and stabilization
- **Sound speed:** Used to enter the applicable sound speed data
- **Filter and gains:** Used to set what filter method and absorption coefficient to apply
- **Data cleaning:** Configuration of what rules to apply for data cleaning, ping processing, grid processing and for seabed image processing
- **Javad and Trimble:** Used for configuration of GPS raw data logging using the Javad or Trimble GPS receivers
- **AHT Logging:** Parameter setting for logging of the Applanix POSMV true heave system.
- **Simulator:** Parameters for simulator mode.
- **Survey information:** Displays survey parameters for current survey.

- **Advanced parameters:** Configuration of manual control of pulse length and TVG.
- **Singlebeam runtime:**

In addition to the full Runtime parameters window described in this section a scaled down window with only a subset of essential parameters are also available. This reduced runtime parameters window will occupy very little space, still allowing you easy access to basic runtime settings:

- See *Runtime parameters mini view* on page 85

### **Related operational procedures**

- *How to open the runtime parameter interface* on page 116
- *How to modify the runtime parameters* on page 117

### **Parameter references**

- *Sounder main for EM 1002* on page 243
- *Sound speed for EM 1002* on page 246
- *Filter and gains for EM 1002* on page 250
- *Data cleaning* on page 253
- *Javad and Trimble* on page 261
- *ATH Logging* on page 261
- *Simulator for EM 1002* on page 263
- *Survey Information* on page 265

## **4.21 Runtime parameters mini view**

The **Runtime param. Mini** frame is accessed either through **View→Manage Windows** or by selecting it from the **Frames** button.

The **Runtime Parameters Mini** frame provides easy access to most commonly used parameters of the Runtime Parameters.

The parameters available in the **Runtime Parameters Mini** frame are all a selection from the **Sounder Main** tab in the full **Runtime parameters** window.

## Runtime parameters Mini – EM 1002

### Up/down buttons

The up/down buttons have two modes: single press or continuous. By pressing and releasing the button once, the associated parameter is incremented/decremented by one. By pressing and holding the button, the associated parameter will be continuously updated.

When the parameters are changed, the background is marked using yellow colour. Press enter on the keyboard, or make a selection in a combo box, to confirm and send the parameters to the echo sounder (PU).

### Note

*When using the buttons in continuous mode no range checking will be made on the changed parameter values. The parameters can therefore be set outside valid bounds. However, when the button is released and you press enter to confirm, a single press on the same button or editing of another parameter will cause an error message to appear if the parameter is set outside valid boundaries.*

### Mini and full Runtime parameters frame synchronization

The Mini window can be displayed together with the full Runtime parameters window. If a change is made and confirmed in one of the two windows the other window will be updated automatically, keeping the windows synchronised.

### Related operational procedures

- *How to open the runtime parameter interface* on page 116
- *How to modify the runtime parameters* on page 117

### Parameter references


- *Sounder main for EM 1002* on page 243

## 4.22 Sensor layout view

The **Sensor layout** window is accessed either through **View→Manage Window** or by selecting it from the **Frames** button.






### Purpose

The **Sensor layout** gives a graphical presentation of the sensor locations on the ship which may be useful to verify installation parameters.



### Toolbar buttons

The toolbar of the **Sensor layout** window holds the following buttons (from left to right):

Click this button	To
	Enter the Sensor Layout show/hide options
	Set annotation colours
	Reset the view
	Zoom in
	Zoom out

### **Related operational procedures**

- *How to monitor the external sensors in SIS* on page 137

### **Parameter references**

- *Sensor layout – Show/hide* on page 210

### **Related topics**

- *Keyboard and mouse in the Sensor layout view* on page 42

## **4.23 Calibration view**

### **Note**

---

*The SIS calibration frame is designed for determination of sensor angular offsets. It is NOT intended for determining the angular orientation of the system transducers. These must be determined through measurements as described in the installation manual. The reason for this is that it is not possible to do a linear addition of sensor offsets and transducer orientation angles.*

*The only exception to this is if the transducers are oriented such that they have zero heading and pitch installation angles, i.e. that they lie horizontal when the pitch is zero and are mounted parallel to the keel, in which case receive transducer roll installation angle and sensor roll offset act as a linear sum. This may be exploited in temporary installations where it may be very difficult to measure roll installation angles with sufficient accuracy.*

*The calibration is neither intended for finding remaining errors in XYZ locations of the sensors. Accurate locations of the sensors must be determined using land survey methods as described in the systems installation manual.*

---

The **Calibration** window is accessed either through **View→Manage windows** or by selecting it from the **Frames** button.

### **Purpose**

The **Calibration** window is intended for analysis of data from a calibration survey, i.e. a survey to determine remaining biases in the depth observations. Depths from two different survey lines is compared in order to visualise the effect of the correction. Please refer to related operational procedures for description of the principles of a calibration survey.

The **Calibration** features of SIS can be run both during online and offline operations.



**Note**

*No correction values will be applied until these are entered in the **Installation Parameters** frame*

The **Calibration** frame applies to multibeam echo sounders only.

**Toolbar buttons**

The toolbar of the **Calibration** frame holds the following buttons (from left to right):

Click this button	To
	Enter the Calibration show/hide options
	Reset zoom

**Buttons**

- **Set:** Apply changes to the corridor width.  
To change the corridor width, enter a new value and press **Set**. If you select a new corridor, the previously used offsets will be applied and corrected data will be displayed in the diagram.
- **Apply:** Calculate and display the data points after setting new offsets.
- **Store:** Save the new offsets in the database.
- **Auto Calib:** If licensed this button brings up the dialogue to enter parameters to be used by **SeaCal**.

**Quick menu**

The Calibration window have a quick menu accessed by clicking on the right mouse button inside the view.

- Select shiptracks - First select two lines using Ctrl + Left mouse button.
- Create corridor - Then create a corridor using Ctrl + Left mouse button.

The system will now calculate and display the two lines from raw data. For a dual system one head at a time must be calibrated.

**Seacal auto calibration**

If licensed the **AutoCalib** button brings up the dialogue to enter parameters to be used by **SeaCal**.

**AutoCalib** may be used as an alternative to the visual determination of correction values as offered by the **Calibration** frame. It is also a useful tool for verifying the correction values found by the visual method.

### **Related operational procedures**

- *Roll offset in the acrosstrack direction* on page 145
- *Pitch offset and time delay* on page 146
- *Heading offset – Alternative 1* on page 148
- *Heading offset – Alternative 2* on page 149
- *Sound speed quality inspection* on page 151
- *Sound speed control* on page 152
- *Outer beam angle offset calibration* on page 152
- *Verification* on page 153
- *How to determine calibration values using SIS Calibration frame* on page 153
- *How to determine calibration values using SeaCal automatic calibration* on page 156
- *How to collect the sound velocity profile* on page 125
- *How to convert your sound velocity profile to SIS format* on page 126
- *How to modify and load a sound speed profile into SIS* on page 132

### **Parameter references**

- *Calibration parameters* on page 213
- *Seacal auto calibration* on page 214

### **Related topics**

- *Keyboard and mouse in the Calibration view* on page 42
- *SeaCal* on page 335

## 5 THE MENU SYSTEM


This chapter provides a brief description of the menu system provided by SIS. The menu options are not explained in detail, but references are provided for the detailed dialog box and functional description.

### 5.1 Main menu

The main menu is located on the top of the application window. It provides the following choices:

- *File menu* on page 91
- *View menu* on page 92
- *Tools menu* on page 93
- *Help menu* on page 95

### 5.2 File menu




The **File** menu gives you the following choices:

- **Import/Export:** Dialog for import and export of raw data and gridded survey data  
See *Import/Export* on page 278
- **Export xyz file:** Export of survey data to xyz ascii file  
See *Export xyz file* on page 286
- See **Remove survey:** Used to delete surveys from the database  
See *Remove survey* on page 287
- **Save settings:** Used to save current frame settings  
See *Save settings* on page 287

- **Save settings as...:** Save current frame settings with a new filename  
See *Save settings as...* on page 287
- **Delete settings:** Used to delete selected frame setting file  
See *Delete settings* on page 288
- **Set startup settings:** Used to select how you want the SIS frames to appear at start up  
See *Set startup settings* on page 288
- **Export PU parameters:** Used to save the Installation and Runtime parameters for current echo sounder to file in an ascii readable format  
See *Export PU parameters* on page 289
- **Import PU parameters:** Used to import previously saved parameters for a given echo sounder  
See *Import PU parameters* on page 290
- **Export user settings:** Used to save current database settings for later retrieval  
See *Export user settings...* on page 291
- **Import user settings:** Import previously exported database settings  
See *Import user settings...* on page 292
- **Create CUBE grid:** Used to create a CUBE grid after completion of data logging  
See *Create CUBE grid* on page 292
- **Quit:** Exit SIS  
See *Quit* on page 293

## 5.3 View menu




The **View** drop-down menu gives you the following choices:

- *Manage windows* on page 35
- *Icons* on page 37
- *C-MAP detail level* on page 37
- *Colour palette* on page 38

- *Status bar* on page 39


## 5.4 Tools menu



The **Tools** drop-down menu gives you the following choices:

- **External sensors:** This is where you define the interfaces to your external sensors that are attached directly to the Hydrographic Work Station (HWS)  
See *External sensors* on page 295
- **Instrument combination:** This is a dialog for creating combined interfaces from external sensors that can be started as any system sent from the PU  
See *Instrument combinations* on page 302
- **Remove instruments:** Used to remove selected instrument combinations.  
See *Remove instruments* on page 303
- **C-MAP:** Dialog for administrative for C-MAP  
See *C-MAP – Licence administration* on page 304
- **AutoCalib Wizard:** Wizard that will guide you through a SeaCal calibration  
See *AutoCalib Wizard* on page 305
- **SeaCal results:** Direct access to location where your Seacal result files are stored  
See *SeaCal results* on page 306
- **Extract IFF:** Used to extract position datagrams  
See *Extract IFF* on page 306
- **Custom...:** A new level of menu selections.  
See *Custom menu* on page 94

### 5.4.1 Custom menu




The **Custom...** sub-menu is accessed from the **Tools** menu. This menu is used to access various Custom applications. It is also possible to manage or add applications to this menu.

Choose between the following options:

- **SVP editor:** Used to load and edit sound speed profiles logged in .asvp or .actd format.  
See *SVP Editor* on page 318
- **Set parameters:** Parameter settings that are used to control the behaviour of SIS.  
See *SIS parameters – Set parameters* on page 266
- **Datagram distribution:** Used to route selected datagrams to given IP addresses on the network.  
See *Request datagrams from an echo sounder* on page 442
- **Projection setup:** Used to define the projections and datum transformation that you later can apply.  
See *Projection and datum parameters* on page 308
- **Create terrain models from ASCII files:** Dialog for creating terrain model from a Neptune ASCII file.  
See *Create terrain models from ASCII files* on page 363
- **Licence information:** Opens the log file to the license server, containing your SIS license information.

- **PU Simulator:** Used for simulation and playback of previously logged raw data.  
See *PU simulator and playback* on page 361
- **Objects:** Opens a utility for adding points, lines, images, text, polygons, video and html into the SIS map.  
See *SIS Objects* on page 344
- **SVP effects:** Opens a utility for displaying the beams as they go through the water.  
See *SVP Effects* on page 324
- **Configure...:** Used to manage existing applications in the **Custom** sub-menu.  
See *Configure...* on page 307

## 5.5 Help menu



The **Help** drop-down menu gives you the following choices:

- **Help:** Opens online help  
See *Help* on page 315
- **Build info:** Contains information about you SIS software build.  
See *Build info* on page 315
- **OpenGL settings:** Contains information related to SIS software drivers.  
See *OpenGL settings* on page 315
- **About SIS:** General SIS software information.  
See *About SIS...* on page 316

## 6 OPERATIONAL PROCEDURES

This chapter presents the most important operational procedures required to operate the SIS software.

You will find descriptions and main operational procedures on how to start and exit SIS, plan and run a survey, set installation and runtime parameters etc. in this chapter.

The following operational procedures are included:

### **Start, stop and operational procedures**

- *Normal operational sequence* on page 99
- *How to start pinging* on page 136
- *How to start SIS* on page 100
- *How to start the Remote Helmsman Display* on page 166
- *How to import a Neptune grid to SIS* on page 135
- *How to start the echo sounder* on page 134
- *How to interface a singlebeam echo sounder in SIS* on page 134
- *How to start and stop logging – Alternative 1* on page 141
- *How to start and stop logging – Alternative 2* on page 142
- *How to save data* on page 142
- *How to log water column data* on page 142
- *How to run the PU simulator* on page 164
- *How to export survey results after a survey* on page 167
- *How to exit the SIS software* on page 168
- *How to shut down the operator station* on page 168
- *How to shut down the Processor Unit (PU) or the Transceiver Unit* on page 168

### **Configuration procedures**

- *How to configure your survey* on page 101
- *How to enter parameters for a new survey* on page 105
- *How to enter survey parameters* on page 102
- *How to define a new projection and datum transformation* on page 107
- *How to setup the input from external sensors* on page 120
- *How to setup the output to external sensors* on page 122
- *How to enter the waterline* on page 122
- *How to open the installation parameter interface* on page 112
- *How to modify the installation parameters* on page 112
- *How to open the runtime parameter interface* on page 116

- *How to modify the runtime parameters* on page 117
- *How to collect the sound velocity profile* on page 125
- *How to convert your sound velocity profile to SIS format* on page 126
- *How to modify and load a sound speed profile into SIS* on page 132

### **Quality control procedures**

- *How to monitor the external sensors in SIS* on page 137
- *How to monitor the survey progress* on page 163
- *How to display realtime depths* on page 138
- *How to verify echo sounder main functions* on page 138
- *How to display a smooth surface* on page 140
- *How to look for artifacts* on page 140
- *How to display seabed imagery data in the Geographical view* on page 138

### **Calibration procedures**

- *Roll offset in the acrosstrack direction* on page 145
- *Pitch offset and time delay* on page 146
- *Heading offset – Alternative 1* on page 148
- *Heading offset – Alternative 2* on page 149
- *Sound speed quality inspection* on page 151
- *Sound speed control* on page 152
- *Outer beam angle offset calibration* on page 152
- *Verification* on page 153
- *How to determine calibration values using SIS Calibration frame* on page 153
- *How to determine calibration values using SeaCal automatic calibration* on page 156

### **Planning procedures**

- *How to plan a new job in SIS* on page 162
- *How to retrieve a planned job* on page 163
- *How to display planned lines on the Remote Helmsman Display* on page 166

### **SIS utilities**

Operational procedures describing various functionality of the SIS utilities are found in section *SIS utilities* on page 317. The following operational procedures are described:

- *How to run the PU simulator* on page 164

- *How to use SIS on an AUV/ROV* on page 371

## 6.1 Detecting the echo sounder on the network

When the SIS program starts it will automatically scan the network for connected echo sounders. This will normally take approximately 10 seconds. The detected echo sounders will be compared with a list of echo sounders detected on the previous run of the program. If new echo sounders are detected they will automatically be configured in the SIS program according to a predefined setup for each echo sounder type. This will take approximately 5-10 seconds for each new echo sounder. All detected echo sounders will then be listed in the **Current echo sounder** combo box, available for selection of an echo sounder in further configuration.

In addition, the same echo sounders may be listed in the **Echo sounder - not started** combo box, depending on whether the autostart mechanism is triggered or not. The autostart mechanism will automatically start all detected echo sounders, provided they are exactly the same as on the previous run, that is, if no echo sounders are missing and no new echo sounders are added since the last run. Otherwise the echo sounder will appear in the **Echo sounder - not started** combo box and must be started manually.

Choose which system you want to change the parameters for, by selecting it from the **Current echo sounder** combo box.

Since several types of echo sounders, with different purpose and capabilities, are handled by the SIS software, the parameter settings for the different types will vary depending on system.

The multibeam echo sounders broadcasts their existence on the network. EA single beam echo sounders, from version 2.4.0.0 and onwards, will also be detected on the network by SIS. Earlier versions of single beam echo sounders and other sensors transmitting NMEA datagrams must be set up manually in SIS. Use the **Add instruments combinations** found in the **Tools** menu. When defined, these sensors will be handled the same way as echo sounders that broadcast their existence on the network.

The external sensors, connected directly to the HWS, such as a sound velocity probe, heading and position sensors are registered in the **External sensors** found in the **Tools** menu.

### Note

---

*It is important that the default parameter settings for each echo sounder is checked and/or modified according to the operational and physical conditions applicable for the current echo sounder.*

---

**Parameter references**

- *Instrument combinations* on page 302

**Related topics**

- *Echo sounder – Not started list* on page 32
- *Current echo sounder* on page 33

## 6.2 Normal operational sequence

---

**Note**

*To ensure correct setup and operation of SIS the **Survey Template Handling** is essential. When all parameters are set up and stored in the template, all future surveys that are set to using this template will be defined by these parameters.*

---

---

**Note**

*If SIS has been left inactive for some time, the operating system may have swapped the complete SIS process to disk. The operating system must then read SIS into the RAM again. This may take a few seconds. Datagrams including installation and runtime parameters must not be sent to the Processing Unit during this process.*

---

**Normal operational sequence**

The normal sequence of operations required for surveys run using SIS are as follows:

- 1 Start SIS  
See *Start SIS* on page 100
- 2 Enter survey and operator parameters, background data and set projection  
See *Enter survey and operator parameters, set projection* on page 101
- 3 Check installation and runtime parameters  
See *Check installation and runtime parameters* on page 110
- 4 Start the echo sounder  
See *Start the echo sounder* on page 134
- 5 Import a Neptune grid (optional)  
See *Import a Neptune grid to SIS* on page 135
- 6 Start pinging  
See *Start pinging* on page 136
- 7 Check sensor input

- See *Check sensor input* on page 136
- 8 Check echo sounder main functions
  - See *Check echo sounder main functions* on page 137
- 9 Start and stop logging
  - See *Start and stop logging* on page 141
- 10 Perform a system calibration (optional)
  - See *Perform a system calibration* on page 143
- 11 Plan a survey (optional)
  - See *Plan a survey* on page 159
- 12 Run the survey
  - See *Run the survey* on page 163
- 13 Export data
  - See *Export data* on page 166
- 14 Operate Helmsman Display (optional)
  - See *Remote Helmsman Display* on page 166
- 15 Exit SIS
  - See *Exit SIS* on page 168

## 6.3 Start SIS

### How to start SIS

- 1 Power up the echo sounder units.
- 2 Power up the Operator Station peripherals.

#### Note

---

*Your system may include a number of peripheral devices. Consult the applicable manufacturer's documentation for correct operation of these.*

---

- 3 Configure the single beam echo sounder(s) - if applicable.
- 4 Power up the SIS Operator Station.
  - The operating system on the SIS Operator Station loads automatically. When the boot process is finished, you can open the SIS program.
- 5 Click on the SIS icon on the desktop or selecting SIS from the Windows start menu.

When SIS starts, two background windows will be started:

- Licence server
- Web server (Windows server from version 3.7)

The licence server connects to the hardware licence dongle and provides the licences to the SIS program. The web server is an internal SIS component.

The dongle is connected to an USB port on the HWS. It is required to run the advanced options of SIS.

**Note**

*Do not stop the Licence server and the Web server applications. The applications must be running as long as SIS is running.*

- 6 Verify that the SIS application window opens as described in *The application window* on page 21.

## 6.4 Enter survey and operator parameters, set projection

### How to configure your survey

You have to define survey templates for the survey area before you start the survey.

- 1 Choose the frame **Survey Administration** and set the parameters for the survey type you will be running
- 2 Select the frame **New survey** and use the survey template from there
- 3 Define the survey name, and you are ready to go

The parameters can be saved to current or all survey templates, and it is thereby not required to set these parameters more than once for a survey. This method will save you a lot of work, and ensure correct survey parameter setup throughout the survey.

This section explains how to create and modify survey templates.

### Operational procedures

- *How to enter survey parameters* on page 102
- *How to enter parameters for a new survey* on page 105
- *How to define a new projection and datum transformation* on page 107

The parameter settings are not explained in details in this section. Please refer to the following sections for a complete description of the parameters:

### Parameter references

- *Survey parameters* on page 216
- *Basic parameters* on page 216
- *Storage options* on page 219

- *Background data* on page 220
- *Projection parameters* on page 222
- *GridEngine parameters* on page 222
- *User handling* on page 224
- *CUBE parameters* on page 225
- *Data cleaning* on page 253
- *Projection and datum parameters* on page 308

### **Related topics**

- *New survey window* on page 79
- *Survey administration window* on page 81

## **6.4.1 Set survey parameters**

### **How to enter survey parameters**

#### **User handling**

This is where you add new users of SIS.

- 1 Enter identification a the new user
- 2 Press **Update** to apply

#### **Background data**

This is where you can enable or disable background data files. The background data may be a projection file, a KSGPL contour file, a file containing predicted tide or a geoid data file. The background data are applied from the **New survey** frame.

- 1 Select the path of the background data location
- 2 Press the **Add** button to load the file
- 3 Select the path of background data you want to remove
- 4 Press **Delete** to remove the files from SIS.

The files are not deleted from the disk.

#### **Survey templates handling**

The survey templates are extremely useful for easy and correct setup of the survey parameters of SIS. Once a setup for a survey is completed the complete setup can be stored and used at next survey at the same place, at next survey with similar setup or just as a template for correct setup of a new template. The template you want to use is selected from the **New survey** setup. **Survey template handling** is used for creating new templates or modifying existing ones.

- 1 Select the **Basic parameters** tab.
- 2 Enter a new name in the **New survey template** text field if you want to create a new template,

or

select the template you want to modify from the New survey template drop down list.

- 3 Select the **survey-template** you want your new template to be based upon from the drop down list.  
You can select any of previously stored templates, previous used template or default template.
- 4 Select name of user.  
If you want a new user to be defined go to the **User handling** tab.
- 5 Press **Update** to apply.
- 6 Select the **Storage options** tab.
- 7 Select where you want gridded data to be stored
- 8 Select where you want your raw data to be stored
- 9 Select the naming convention of your raw data by selecting appropriate tick boxes
- 10 Enter name of the ship
- 11 Click **Apply to all survey templates** if you want your settings to apply to all loaded templates.

### Advanced options

This is where you select any background data available for your survey. The background data may be a projection file, a KSGPL contour file, a file containing predicted tide or a geoid data file.

- 1 Select the **Background data** tab.
- 2 Select or browse for the path to the background file

Note

---

*Background data must be loaded in the Geographical view by pressing the **Load background data** button found in the toolbar.*

---

- 3 Click **Apply to all survey templates** if you want your settings to apply to all loaded templates.
- 4 Select the **Projections** tab.
- 5 Select the applicable projection from the drop-down list.  
If your datum and projection is not in the list a new datum and projection can be defined from **Tools→Custom→Projection setup**.
- 6 Select the **GridEngine parameters** tab.  
The GridEngine parameters are thoroughly explained in .
- 7 Select what depth to display.

- 8 Select resolution of your grid, i.e. number of cells and cell size, suitable for your depth and expected coverage.

There are no applicable rules for selecting your resolution. To achieve best possible resolution the cell size should be as small as possible. Number of cells must be set according to the cell size to maintain expected coverage. Further, you must take memory usage into account. If the cell size is set too small the memory usage may be overloaded, and the display is unable to follow in real time.

As a rule of thumb you may use the following equation:

*Expected coverage  $\approx$  number of cells x cell size*

- 9 Select real time processing parameters by pressing the **Processing...** button.

You will be directed to the **Real time data cleaning** page normally accessed from the **Runtime parameters** frame. The real time data cleaning uses rules, i.e. a set of parameters that controls the algorithms used in the real time processing of echo sounder data.

- 10 Click **Apply to all survey templates** if you want your settings to apply to all loaded templates.

### **Cube parameters**

This procedure applies only if you want to use the CUBE data cleaning method instead of the default GridEngine. CUBE is enabled from **Tools**→**Custom**→**Set parameters**→**Logging**. For more information about CUBE see

- 1 Select the depth reference you want to use
- 2 Enter the geographical coordinates of the centre of your survey area.
- 3 Enter the width and height of your survey area.
- 4 Enter your required grid cell size.

The smaller grid cell size the better resolution. However, too small grid cells will not be accepted by the CUBE algorithms. You may have to enter a larger grid cell size.

### **Related operational procedures**

- *How to enter parameters for a new survey* on page 105
- *How to define a new projection and datum transformation* on page 107

### **Parameter references**

- *Survey parameters* on page 216
- *Basic parameters* on page 216
- *Storage options* on page 219

- *Background data* on page 220
- *Projection parameters* on page 222
- *GridEngine parameters* on page 222
- *User handling* on page 224
- *CUBE parameters* on page 225
- *Projection and datum parameters* on page 308
- *Data cleaning* on page 253
- *Logging* on page 274

### **Related topics**

- *CUBE* on page 375

## **6.4.2 Start a new survey**

### **How to enter parameters for a new survey**

#### **Basic parameters**

- 1 Open the **New survey** frame.
- 2 Select the **Basic parameters** tab.
- 3 Enter a unique **new survey name** descriptive to your survey
- 4 Select **survey template** you have defined in the **Survey administration** frame.

If a previous survey with the same or similar survey conditions was saved as a template, this template can be loaded to the new survey. This may save you some work, and ensure that correct survey parameters are being used.

- 5 Select a predefined **user**.  
The user name is appended to the header of the raw data. If your user name is not defined you may add a user from the **User handling** tab in the **Survey administration** frame.
- 6 Select an existing survey if you want to continue data logging to an existing survey.  
Press **Continue on existing survey** to confirm.
- 7 Add any comments that may give relevant information about the survey.

#### **Storage options**

- 1 Select where you want gridded data to be stored
- 2 Select where you want your raw data to be stored
- 3 Select the directory structure of where to store your raw data by selecting appropriate tick boxes
- 4 Enter name of the ship

- 5 Click **Apply to all survey templates** if you want your settings to apply to all loaded templates.

### Advanced options

This is where you select any background data available for your survey. The background data may be a projection file, a KSGPL contour file, a file containing predicted tide or a geoid data file.

- 1 Select the **Background data** tab.
- 2 Select or browse for the path to the background file

#### Note

---

*Background data must be loaded in the Geographical view by pressing the **Load background data** button found in the toolbar.*

---

- 3 Click **Apply to all survey templates** if you want your settings to apply to all loaded templates.

- 4 Select the **Projections** tab.

- 5 Select the applicable projection from the drop-down list.

If your datum and projection is not in the list a new datum and projection can be defined from **Tools→Custom→Projection setup**.

- 6 Select the **GridEngine parameters** tab.

The GridEngine parameters are thoroughly explained in .

- 7 Select what depth to display.

- 8 Select resolution of your grid, i.e. number of cells and cell size, suitable for your depth and expected coverage.

There are no applicable rules for selecting your resolution. To achieve best possible resolution the cell size should be as small as possible. Number of cells must be set according to the cell size to maintain expected coverage. Further, you must take memory usage into account. If the cell size is set too small the memory usage may be overloaded, and the display is unable to follow in real time.

As a rule of thumb you may use the following equation:

$$\text{Expected coverage} \approx \text{number of cells} \times \text{cell size}$$

- 9 Select real time processing parameters by pressing the **Processing...** button.

You will be directed to the **Real time data cleaning** page normally accessed from the **Runtime parameters** frame. The real time data cleaning uses rules, i.e. a set of parameters that controls the algorithms used in the real time processing of echo sounder data.

- 10 Click **Apply to all survey templates** if you want your settings to apply to all loaded templates.

### **Related operational procedures**

- *How to define a new projection and datum transformation* on page 107
- *How to enter survey parameters* on page 102


### **Parameter references**

- *Survey parameters* on page 216
- *Basic parameters* on page 216
- *Storage options* on page 219
- *Background data* on page 220
- *Projection parameters* on page 222
- *GridEngine parameters* on page 222
- *User handling* on page 224
- *CUBE parameters* on page 225
- *Projection and datum parameters* on page 308
- *Data cleaning* on page 253

## **6.4.3 Define a projection and datum transformation**

### **How to define a new projection and datum transformation**

- 1 Select **Tools**→**Custom**→**Projection setup** from the main menu.
- 2 Select the **Define projections** tab.
- 3 Locate the **Projection definition** section.
- 4 Press the **New** button.
- 5 Enter a name to identify the selected datum and projection, e.g. ED50\_UTM30
- 6 Enter the type of projection for mapping the ellipsoidal coordinates onto the map plane



Press **OK** to continue

**Datum information**

Datum transformation

☒ Datum transformation active

From ellipsoid: 01:WGS84 Choose ellipsoid

Rotation unit is RADIANS

Scale: -1.200

Rotation X: 0

Rotation Y: 0

Rotation Z: 0.156

Displacement X: 89.5

Displacement Y: 93.8

Displacement Z: 123.1

Information: WGS84 to ED50

Select transformation Delete transformation

**Ellipsoid**

Ellipsoid for projection: 1:WGS84 Choose ellipsoid

OK Cancel

- 7 Tick off for **Datum transformation active** if you want the entered datum transformation to be carried out to your input positions.

Datum transformation is by default turned off.

- 8 Press **Choose ellipsoid** to select the ellipsoid of the input position.

For GPS position input this will normally be the WGS84 ellipsoid.

- 9 Press **Select transformation** to use predefined datum transformation parameters from a **PROJ.4** file

or


- 10 Enter the 7-parameter datum transformation parameters in the applicable parameter fields

- 11 Press **Choose Ellipsoid** in the **Ellipsoid** field to enter the ellipsoid for the output position.

**Ellipsoid**

Ellipsoid for projection: 05:intl Choose ellipsoid

12



Select the ellipsoid and press **OK** to apply.

The available ellipsoids in SIS are identified by (scroll the side bar to view the parameters):


- id
- short name
- major axis (a)
- reverse flattening (rf)
- full ellipsoid name

e.g. for ED50, the International 1909 ellipsoid applies having the following parameters:

- id = 05
- short name = intl
- a = 6378388.0 m
- rf = 297.0

13 Press **OK** to apply the datum transformation selected.

When UTM projection type has been selected the **Define UTM projection** dialog will appear



14 Select **UTM zone** and whether you are on northern or southern hemisphere.

15 Press **OK** to apply.

16 Press **Edit...** to change the datum transformation or projection parameters selected

- 17 Press **Delete...** if you want to delete the settings you have chosen

### **Parameter references**

- *Projection and datum parameters* on page 308

### **Related topics**

- *Available projections in SIS* on page 311

## **6.5 Check installation and runtime parameters**

Installation and runtime parameters are associated with the echo sounder and not with the survey. This means that the installation and runtime parameters are set up separately for each individual echo sounder. These parameter settings will remain the same for that echo sounder, independent of the survey run.

The parameter settings for each echo sounder will be stored in a database. When an echo sounder is detected for the first time, all parameters will be set to a default value, determined by the type of echo sounder. It is important that the installation and runtime parameters are checked and updated if necessary.

### **Note**

---

*We recommend that you keep a record of the parameters and settings used in a safe and accessible place.*

---

**External sensors:** For interfaces to external sensors that are attached directly to the Hydrographic Work Station (HWS) the interface parameters must be defined in the External sensors dialog.

### **Note**

---

*The Installation parameter window can be displayed at any time, but parameters can only be modified when pinging and logging is deactivated.*

*The Runtime parameter window can be displayed at any time, independent of pinging and logging status.*

---

### **Operational procedures**

- *How to open the installation parameter interface* on page 112
- *How to modify the installation parameters* on page 112
- *How to open the runtime parameter interface* on page 116
- *How to modify the runtime parameters* on page 117
- *How to setup the input from external sensors* on page 120
- *How to setup the output to external sensors* on page 122

- *How to enter the waterline* on page 122

### **Parameter references**

- *Installation parameters* on page 226
- *Runtime parameters* on page 243
- *External sensors* on page 295

### **Related topics**

- *Installation parameters window* on page 83
- *Runtime parameters window* on page 84

## **6.5.1 Installation parameters**

The installation parameters are divided into three main groups described in the following:

- Communication setup parameters
- Sensor setup parameters
- BIST – self test

### **Communication setup parameters**

The communication setup parameters define the input and output settings for the serial - and network (Ethernet) ports on the echo sounder Processing Unit. In addition, this parameter group defines the type of information (datagrams) that is received and/or sent on the individual ports. To be able to set these parameters correctly it is necessary to know the type of equipment connected to each individual PU port. Depending on the port type, the connections are either direct using a serial link, or remote via the system network. The equipment type and which port the different equipment types may be connected to, is defined by a set of rules/restrictions. These rules are defined in the **PU communication**→**Input setup** tab located in the **Installation parameter** frame.

#### **Note**

---

*If the communication setup is not correct this may result in loss or corrupted functionality - in worst case an inoperable system.*

---

### **Sensor setup parameters**

In order to determine correct depth values the system must know the physical positions, tilt, biases and delays for all transducers and sensors. This information belongs in the second main group of installation parameters - sensor setup parameters. Also, based on the set of equipment that is connected to the echo sounder PU (Processing Unit), it may be necessary to select what equipment to use as active units when several alternatives are available.

If no selection is made, the system will automatically use the sensor connected to the lowest numbered port when two or more alternatives are available.

### **BIST - self tests**

The options available allow you to test individual functions and hardware items.

### **How to open the installation parameter interface**

The installation parameters for the different echo sounders are located in the **Installation parameter** window. All external sensors connected to the Hydrographic Work Station (HWS) are located in the **External sensors** dialogue box found on the **Tools** drop-down menu.

In order to open the installation parameter interface perform the following actions:

- 1 Select the echo sounder you want to change parameters for in the **Current echo sounder** combo box.
- 2 Select the Installation parameters by either:
  - Use the **Frame** button to select Installation parameters in the desired frame.or
  - Locate the **Manage Windows** selection from the **View** menu.
  - Select **Installation parameters** from one of the combo boxes and press OK.

### **How to modify the installation parameters**

#### **PU communication setup**

For detail parameter description refer to the following sections:

- 1 Select the **PU Communications Setup** tab.

Three sub-tabs are displayed.
- 2 Select the **Input Setup** tab.
  - 1 Set the communication settings for each of the ports you are using for input to the PU.

Select the port you want to modify first. Then baud rate, data bits, stop bits and parity must be set equal to the settings in the external sensor the port is connected to.

**Note**

- *COM1 – position input*
  - *COM2 – motion sensor input*
  - *COM3 – position input*
  - *COM4 – position input*
  - *UDP2 – position and depth input*
- 

- 2 Select the **Input format** of the data you want to read on the selected port.  
Select the format your external device is set up to output.
- 3 Select the **Output Setup** tab to define the datagrams to be output from the Processing Unit (PU)
  - 1 Select UDP Host port according to what type of data you want to configure your output for  
Port address is given by SIS and can not be changed.
  - 2 Select the datagram subscriptions for each output
  - 3 Select if you want to log water column data to a separate \*.wcl file
  - 4 Select if you want the PU to broadcast its existence on the network on given port.
- 4 Select the **Clock Setup** tab
  - 1 Select the time reference to synchronize the PU clock to.  
The PU clock can be synchronized to an external time reference, to the time of the active positioning system or to the clock in the operator station.
  - 2 Select whether a 1PPS signal from a GPS receiver shall be used to correct for clock drift.

**Related operational procedures**

- *How to modify the runtime parameters* on page 117
- *How to log water column data* on page 142

**Parameter references**

- *PU communication – Input setup* on page 226
- *PU communication – Output setup* on page 230
- *PU communication – Clock setup* on page 232
- *Water column – Logging* on page 199
- *Water column – Show/hide* on page 196

### Related topics

- *Timing* on page 395

### Sensor setup

- 1 Select the **Sensor Setup** tab.
- 2 Select the **Settings** tab
  - 1 Select what positioning system to modify by selecting its input port.

Only ports enabled for position input by the PU communication setup tab can be selected.
  - 2 Select what time tag to use for the position

This can be the **System** time defined by the time tag given by the PU at datagram arrival on the port, or it can be the time of the observation found in the **Datagram**.

To ensure a common time reference for position and depth input we normally recommend that the **System** time is used.
  - 3 Select if you want to correct your position input for roll, pitch and heading.

This will normally only apply if your position and attitude input comes from different systems and/or that this correction has not been applied before input to the PU.
  - 4 Enter a position delay.

You must refer to the position system's documentation to find the delay.

Delay will only apply if **Time to use** is set to **System**.
  - 5 Select name of the datum you are using.

Note \_\_\_\_\_

*This is only text information to the logged files. Actual datum is given by your position input. If required, datum transformation may be enabled from the **Tools**→**Custom**→**Projection setup** menu.*

---
  - 6 Select **Log all heights** if you want to enable height datagrams from the GGA and GGK position input with all height input having a quality factor as specified.
  - 7 Enter the quality indicator numbers (comma separated) that you want to accepted as your height observations.

The quality indicators are given by the NMEA GGA and GGK specifications.
  - 8 Select the **roll reference plane** according to your motion sensor.

- 9 Enter the motion sensor delay according to motion sensor documentation
- 10 Select your active sensors by selecting the port to which the relevant sensor is connected
- 3 Select the **Location** tab
  - 1 Enter the location offsets relative to the vessel reference point for the different sensors and transducers.

**Note** \_\_\_\_\_

*If the vessel's displacement or trim changes during a survey, the waterline value must be updated accordingly.*

---

- 4 Select the **Angular Offset** tab  
Enter the angular offsets for the different sensors and transducers.

**Related operational procedures**

- *How to define a new projection and datum transformation* on page 107
- *How to determine calibration values using SIS Calibration frame* on page 153
- *How to determine calibration values using SeaCal automatic calibration* on page 156

**Parameter references**

- *Sensor setup – Settings* on page 233
- *Sensor setup – Locations* on page 237
- *Angular Offsets for EM 1002* on page 238
- *PU communication – Input setup* on page 226

**System parameters**

- 1 Select the **System Parameters** tab
- 2 Verify that the backscatter offset parameters and the Tx and Rx opening angles are set as intended

**Parameter references**

- *System parameters for EM 1002* on page 239

**BIST**

- 1 Select the **BIST** tab.  
It contains several tests you can perform to check the operation of the echo sounder system
- 2 Press the **Run all BISTs** button

or

Press each BIST test button one by one

- 3 Verify that all BIST test buttons turns green when test is performed.

If any of the tests fails the specific test button will turn red or yellow, and a description of the test result will be displayed in the **PU BIST result** field.

Please refer to the echo sounder's maintenance manual for corrective actions.

### **Parameter references**

- *BIST – Built-In Self Test* on page 240

## **6.5.2 Runtime parameters**

Runtime parameters are divided into four main groups:

- Sounder Main parameters
- Sound Speed
- Filter and Gains
- Data Cleaning

The content of these groups will vary depending on echo sounder type. Additional groups may also exist.

### **Sounder main**

The sounder main settings concern the operational parameters for the echo sounder including coverage, depth and swath control.

### **Sound speed**

Sound speed settings concerns selection and use of sound speed profiles and sound speed at transducer settings.

### **Filter and gains**

Filter and gains settings concern filtering to avoid erroneous measurements, e.g. false bottom detection. It also includes settings for the bottom backscatter measurement and seabed imaging.

### **Data Cleaning and Seabed Image Processing**

Data Cleaning defines rule sets for how to carry out the gridding. There are two parameter groups: Ping processing rules and Grid processing rules. It also includes settings for the seabed imaging for the Geographical view.

### **How to open the runtime parameter interface**

To open the runtime parameter interface the following actions must be carried out:

- 1 Select the echo sounder you want to change parameters for in the **Current echo sounder** combo box.
- 2 Select the Installation parameters by either:
  - Use the **Frame** button to select Runtime parameters in the desired frame.or
  - Locate the **Manage Windows** selection from the **View** menu.
  - Select **Runtime parameters** from one of the combo boxes and press OK.

### How to modify the runtime parameters

#### Sounder main

- 1 Select the **Sounder Main** tab
- 2 Set the sector coverage parameters according to your conditions and requirements
- 3 Set the depth parameters according to your expected survey depth

#### Note

---

*The Min and Max depth settings are used to guide the echo sounder in tracking the bottom. Incorrect settings may result in a failure to detect the bottom and thus a disabled system. If the echo sounder has problems detecting the bottom within the min-max range use the **Force Depth** button with a measured depth or a depth from a chart.*

---

- 4 Set the swath control parameters
- 5 Set Pitch and Yaw stabilization parameters

#### Parameter references

- *Sounder main for EM 1002* on page 243

#### Sound speed

In order to ensure accurate depth determination, you must know the sound speed profile in the survey area. The profile may change with both time and position in the survey area. It may therefore be necessary to determine the profile several times during a survey. The profile is stored as a file.

- 1 Collect a sound speed profile from surface to bottom and save the profile to file.

- 2 Select the **Sound Speed** tab

This tab contains Sound Speed Profile and Sound speed at transducer depth.

- 3 Find and select the correct **Sound Speed Profile** file by using the **Browse** button.  
The text field will turn yellow.
- 4 Activate the profile by pressing the button marked **Use Sound Speed Profile**.  
The text field will return to original colour when loaded.
- 5 Select the **Sound speed at transducer** source as one of the following:
  - 1 Manual – Sound speed value must be entered.
  - 2 Profile – A value from the sound speed profile is used (existing value or interpolated).
  - 3 Probe – If you have a sound velocity probe attached at transducer depth the values from the probe is used. The offset value must then be specified.

### **Related operational procedures**

- *How to collect the sound velocity profile* on page 125
- *How to convert your sound velocity profile to SIS format* on page 126
- *How to modify and load a sound speed profile into SIS* on page 132

### **Parameter references**

- *Sound speed for EM 1002* on page 246

### **Filter and gains**

- 1 Select the **Filters and Gain** tab
- 2 Set the **Filtering parameters**.  
We recommended to only change the filtering parameters from default settings if false bottom detections is very likely.
- 3 Set the **Absorption Coefficient** parameters.  
A correct value for the absorption coefficient is important with respect to the validity of the bottom backscatter measurements.  
On broadband sonar systems, like the EM710, absorption coefficient matrixes are automatically calculated by SIS from sound speed profiles and CTD profiles.
- 4 Set the **Normal Incident Sector**.  
Degrees from nadir defines the angle at which the bottom backscatter can be assumed to be independent of the strong increase at normal incidence. The value is dependent on bottom type.

**Parameter references**

- *Filter and gains for EM 1002* on page 250

**Data cleaning****1** Select the **Data Cleaning** tab

This is where criteria for real time data cleaning are defined.

**Caution** \_\_\_\_\_

*Please familiarize yourself with the SIS data cleaning functionality before making any changes to it's parameters.*

*The SIS Data cleaning is described in the SIS reference manual and in the SIS online help.*

**Note** \_\_\_\_\_

*Real time data cleaning does not delete any data, invalid data is simply flagged.*

**Parameter references**

- *Data cleaning* on page 253

**6.5.3 External sensors**

The **External sensors** are used to define interfaces to external sensors that are attached directly to the Hydrographic Work Station (HWS).

**Note** \_\_\_\_\_

*Interfaces to external sensors that are attached to the Processing Unit (PU) are defined in the **Installation parameters**.*

The External sensors dialog contain setup information for the following sensors:

**Input**

- Sound velocity probe
- Real time tide
- SVP logger
- Barometer
- Geodimeter
- Heading
- Position

**Output**

- Auto pilot

- Dynamic positioning
- Depth below keel

## How to setup the input from external sensors

- 1 Enter the sound velocity probe parameters

### Sound velocity probe

To prepare and use an external sound velocity sensor the following steps must be followed:

- 1 Make sure that the external sensor is powered up and connected to a HWS input port (i.e. COM port).

Alternatively, in the case where SIS are receiving external sound velocity datagrams via UDP the datagrams must be available on the network.

- 2 Select the type of sensor or input to use as source for the sound velocity samples:


- a Tick the **Probe available** box to signify that a sound velocity sensor or external sound velocity datagrams is being used.

The **Probe type** combo box is now enabled

- b Select the specific type of sound velocity probe to be used.

The following choices are available:

- SV (C) - only sound velocity
- SV&T (C+T) - sound velocity and temperature
- SV&T (C+P) - sound velocity and pressure (pressure not significant)
- Ext. datagrams (C+T) - sound velocity and temperature



- c If one of the three sensors is selected the port where this sensor is connected must be set in the **Port** combo box.

**Note**

*If 'Ext. datagrams' is selected the port combo box is disabled as UDP is used. There is no need to set communication settings for the selected input COM ports. (Auto detect or fixed 9600 baud is assumed).*

- 3 Configure the **Sound speed** parameters in the **Runtime parameters**.
- 2 Tick off if you have input from either of the following sensors
  - Realtime tide
  - SVP Logger
  - Barometer
  - Geodimeter
- 3 Set the port number, baud rate, data bits, stop bits and parity for each input enabled.
- 4 Enter the Heading and position parameters

**Heading and position parameters**

- 1 Write a name in the **Sensor name** combo box.

The name given here will be the one that is displayed in the installation parameters for GPS and single beam echo sounders.
- 2 Choose either **serial line** or **ethernet** connection. Press **Add** for each sensor.
  - If you choose a serial port, mark the check box under **Serial** and select the port you want to use for heading and/or position by selecting it from the combo boxes under **Port**. The communication parameter is set with the respectively combo box.
  - If you want to use an Ethernet connection, mark the check box under **Ethernet**. The IP address and the port, where the data is to be send, is displayed in the text field to the right.
  - If serial line communication is chosen a small program starts automatically when the equipment is started. This program receives data on RS-232 and forwards the data on UDP. The program will close down automatically.
- 3 **Compass deviation file:** Use the browse button (three dots) to find the desired file.
- 4 **Position delay (sec):** Enter any known position delay.

The accuracy of the position sensor is vital for the data accuracy, and it is therefore important that the relative timing of vessel position data and system depth data is correct. To define the duration of life of the positioning system input data, you can enter a position delay.

A position delay is required if the position that is output on the port applies to an observation that was done a significant number of seconds ago. The position delay may be significant for systems where the internal computation and processing of the position takes time.

- 5 **Location offset (m):** Use the text fields to enter the location of the GPS antenna relative to the vessel's reference point.

*Caution* \_\_\_\_\_

*The positioning system may have internal offset parameters set. Make sure that the antenna offsets are not applied both in the position system and in SIS.*

---

### **How to setup the output to external sensors**

- 1 Tick off if you want to output to either of the following systems
  - Auto pilot
  - Dynamic positioning
  - Depth below keel
- 2 Set the port number, baud rate, data bits, stop bits and parity for each output enabled.

### **How to enter the waterline**

- 1 Locate the **Waterline (m) Downward (Z)** entry in lower left corner of the **External sensor** dialog box
- 2 Enter the vessel's waterline vertical location (in normal trim) in the vessel's reference coordinate system.

### **Related operational procedures**

- *How to modify the runtime parameters* on page 117

### **Parameter references**

- *External sensors* on page 295
- *Sound speed for EM 1002* on page 246

## 6.6 Enter a sound velocity profile

A sound speed profile must always be taken within the survey area and loaded in **.asvp** or **.actd** format into SIS before the survey is started.

We recommend that you collect at least two profiles at each location. If the two profiles deviates significantly, you should carry out further attempts until you are confident that you have a representative sound velocity profile.

The method used for collecting a sound velocity profile depends on the type of sound velocity probe you are using. You must refer to your sound velocity probe's user documentation for instructions on how to collect the sound velocity data.

There are three stages in the process of entering a sound velocity profile into SIS:

- 1 Collecting the sound velocity profile data  
See *How to collect the sound velocity profile* on page 125
- 2 Converting the sound velocity profile data to the SIS **.asvp** format  
See *How to convert your sound velocity profile to SIS format* on page 126
- 3 Checking and preparing the sound velocity profile for SIS  
See *How to modify and load a sound speed profile into SIS* on page 132

SIS reads the sound velocity profile in the **.asvp** and **.actd** formats only. The **.asvp** format is an ascii format consisting of a header row and data rows for each depth and sound speed as shown in the following example:

```
( SoundVelocity 1.00 12 200605290813 22.3452678
  66.4483298 4500 200605290813 200605301210 SVP-16 PE 8 )
0.1 1483.6
5.0 1484.2
7.0 1485.3
12.0 1488.1
20.0 1485.7
25.0 1484.0
40.0 1483.8
12000.0 1509.6
```

The **.actd** format is a special format containing water density in addition to the sound speed. It is used in ROV operations where the scaling factor is automatically calculated. The **.actd** format is not described further in this section. See *Sound speed and density profile format* on page 437 for description.

The SIS software package offers a number of utility programs that may assist you in collecting, converting, checking and loading your sound velocity profile.

Program	Description
SmartTalk	Logging sound velocity profile data from an AML sound velocity probe. Logging data in .csv format. Available on the SIS installation CD
csv2asvp	Converts the .csv file collected using SmartTalk into .asvp format. Available using the SVP Editor utility in SIS
SVPLoader	Logs sound velocity data from an AML or Morse sound velocity probe. Converts the data into the .asvp format. Available using the SVP Editor utility in SIS
SVP Manager	Reads any column based sound velocity file and will when configured convert the file to an .asvp file. Available on the SIS installation CD
SVP Editor	Reads the .asvp file, displays the profile and holds a number of functions for editing and preparing the profile for use in SIS. A SIS utility program.
SVP Editor	Also reads any column based sound velocity file and converts it to the .asvp format.

### Operational procedures

- *How to collect the sound velocity profile on page 125*
- *How to use SmartTalk on page 125*
- *How to use csv2asvp on page 126*
- *How to use SVP Loader on page 127*
- *How to use SVP Manager on page 128*
- *How to use SVP Editor to convert an SVP file to .asvp format on page 131*
- *How to modify and load a sound speed profile into SIS on page 132*

### Related operational procedures

- *How to modify the runtime parameters on page 117*

### Related topics

- *Sound speed profile format on page 434*
- *Sound speed and density profile format on page 437*
- *SVP Editor on page 318*
- *SVP Effects on page 324*
- *SVP Loader on page 332*
- *SmartTalk (SVP) on page 327*
- *External sensors on page 295*

## How to collect the sound velocity profile

The method used for collecting a sound velocity profile depends on the type of sound velocity probe you are using. You must refer to your sound velocity probe's user documentation for instructions on how to collect the sound velocity data.

In general the method is as follows:

- 1 Prepare the probe for data logging.  
There are two methods. Either to collect data through a data cable between the probe and the PC while the probe is lowered, or to collect the data within the probe and download the data to your computer when the probe is recovered.
- 2 Lower the probe slowly from the surface to the bottom, or to a required depth.
- 3 If you are logging data directly to the computer, ensure that data is being recorded.
- 4 Recover the probe slowly.
- 5 Save your profile in the SIS computer.

### Note

*If you are using an AML sound velocity probe you may use the **SmartTalk** utility program included on the SIS installation CD to log the sound velocity profile in a comma separated (.csv) format. The .csv format must then be converted to .asvp format.*


***SmartTalk** is not a Kongsberg Maritime software.*

*Alternatively, for the AML and Morse SVP probes the SIS utility **SVPLlogger** can be used to log and directly convert the sound velocity data to .asvp format.*

---

## How to use SmartTalk

The AML sound velocity probe collects data internally during the sound velocity dip. The logging must be configured before the you lower the probe, and the data is downloaded to your computer after recovery of the unit.



- 1 Connect the probe to the serial port on your SIS computer.
- 2 Press **Configure Instrument** to set up the communication and data logging
- 3 Select your instrument

- 4 Press **Configure**
- 5 Enter a log file name and set the logging parameters according to your requirements
- 6 Press **Program Instrument** to load the settings into the probe
- 7 Disconnect the probe and collect the sound velocity data
- 8 Reconnect when the probe is recovered
- 9 Select **Down Load Data** from the main dialog
- 10 Select your instrument
- 11 Select the correct file and the destination path
- 12 Press **Transfer file(s)** to start downloading
- 13 Select **View Data** from the main dialog
- 14 Select **Load File**
- 15 Evaluate the data briefly
- 16 Press **Export**
- 17 Select **Formatted Comma Separated Values**
- 18 Enter a **Destination file name** with extension **.csv**
- 19 Press **Export File**
- 20 Use the SIS utility **csv2asvp** to convert the file into **.asvp** format.

See *How to use csv2asvp* on page 126

### **How to convert your sound velocity profile to SIS format**


SIS reads the sound velocity format in the standard **.asvp** (Ascii Sound Velocity Profile) format. Your sound velocity data must be converted to the SIS **.asvp** format before they can be applied.

Depending on what type of probe you have SIS offers various utility programs to convert probe data into **.asvp** format.

### **How to use csv2asvp**

**csv2asvp** converts observation files from an AML SVP sensors in **.csv** format to **.asvp** format

- 1 Open the **SVP Editor** from the SIS menu  
**Tools→Custom...→SVP Editor**.
- 2 Select **Tools→csv2asvp**



- 3 Press **Choose file**.  
A standard Windows file open dialog appears.
- 4 Browse for the **.csv** file you want to convert.  
A message dialog appears telling you what file you have selected to convert.
- 5 Click the **OK** button.  
A message dialog appears telling you the converting process is done.
- 6 Click **OK**.
- 7 Click **Exit** to leave **csv2asvp**
- 8 Verify that the file is converted.  
The new file will have the same name as the original **.csv** file, but now with the extension **.asvp**.
- 9 Modify and load the sound velocity profile into SIS.  
See *How to modify and load a sound speed profile into SIS* on page 132

### How to use SVP Logger

**SVP Logger** logs raw data from **Morse** and **AML** SVP sensors and converts the data to **.asvp** format


SVP Logger assumes that a **Morse** or **AML** SVP probe is interfaced to the SIS HWS (Hydrographic Work Station) using the **External Sensor Input setup**.

For details, see

- *External sensors* on page 295
- *How to setup the input from external sensors* on page 120

- 1 Select **Tools**→**External sensors**
- 2 Locate the **SVP Logger** field
- 3 Check the **SVP Logger avail** checkbox
- 4 Select input port in the **Port** drop down list
- 5 Press **OK** to exit **External sensors**

- 6 Open the **SVP Editor** from the SIS menu  
**Tools→Custom...→SVP Editor.**
- 7 Select **Tools→SVPLogger**




- 8 Select the path of your SVP data by pressing **File to log raw data to...**
- 9 Select the path where you want the converted files to be saved to by pressing **SVP file to write...**
- 10 Select whether your SVP format is AML or Morse by checking/unchecking **AML-format instead of Morse**
- 11 Select whether your observations are in Bars or Meters by checking/unchecking **Input format is meters not Bar**
- 12 Enter your approximate latitude
- 13 Enter the surface pressure in bars
- 14 Press **Start** to start logging
- 15 Press **Stop** to stop logging.  
Observe that the content of the .asvp file is displayed.
- 16 Press **Send profile to SVP Editor** to enable modifications to the data.
- 17 Modify and load the sound velocity profile into SIS.  
See *How to modify and load a sound speed profile into SIS* on page 132

### How to use SVP Manager

When configured **SVP Manager** will convert any column based ascii SVP file to the **.asvp** format

SVP Manager is a utility program that is included on your SIS installation CD. You can use SVP Manager to define a standard conversion from your input SVP format to the **.asvp** format.


- 1 Locate **SVPMan** on your SIS installation CD.
- 2 Run the installation file called **SVP Manager.msi**.
- 3 Copy the **SVP Manager** program file to the desktop for accessibility
- 4 Start **SVP Manager**.



### Define the SVP format

First time you are using SVP Manager to convert your SVP data you need to define your format. Some known formats are predefined.

- 1 Locate the **SVP Sources** area
- 2 Press **Add**
- 3 Give a descriptive **Name**
- 4 Set **Source** to be a **File**
- 5 Set **Data Type** to **User defined**
- 6 Press the **Cfg** button to configure the input



7 Enter **Number of header lines** in your input file

8 Select the **Delimiter** used in your input file.

Note \_\_\_\_\_

*Tab and space may appear identical in a text file viewer.*

9 Select the column number in your input file where the **Depth** data is located

Note \_\_\_\_\_

*Depth and pressure data can both be selected for this field.*

10 Select the column number in your input file where the **Sound velocity** is located

11 Press **OK** to save the configuration

12 Press **OK** to save your user defined SVP source

For each file you want to convert:

5 Highlight the SVP source you have created a converting routine for.

6 Select **Read file**.

A standard Windows File dialog opens.

7 Select the file you want to convert

8 Enter an approximate location for the sound velocity profile in the **Enter position** dialog that appears.

9 Press **OK**

10 Observe that the sound velocity profile is shown in the **SVP Edit** windows that appears.

11 Verify that the file has been correctly converted.


12 Press **OK**

- 13 Select **Export file** from the SVP Manager main dialog.  
A standard Windows Save as dialog opens.
- 14 Save the file the .asvp file to the SIS directory  
../common/svp\_abscoeff
- 15 Press **Exit** when you want to leave SVP Manager
- 16 Modify and load the sound velocity profile into SIS.  
See *How to modify and load a sound speed profile into SIS*  
on page 132

### How to use SVP Editor to convert an SVP file to .asvp format

This procedure describes how to convert a SVP file from any column based ascii format to the .asvp format read by SIS.

- 1 Open the **SVP Editor** from the SIS menu  
**Tools→Custom...→SVP Editor**.
- 2 Expand the view by dragging the boundaries of the window.
- 3 Open the SVP file from the **File→Open in editor...** menu
- 4 Change the **Files of Type:** drop down selection to **All files**
- 5 Browse for your SVP input file and press the **Open** button  
The **Raw file editor** opens.



- 6 Select the delimiter from the drop down list.
- 7 Press **Split** to apply the delimiter.  
A new window will appear.

Col. 0	Col. 1	Col. 2	Col. 3	Col. 4	Col. 5	Col. 6	Col. 7	Col. 8
From fil...	Instrum...	389						
Ser	Interval ...	Integrat...	Air pres...	Salinity	Chart D...			
1	2							
Ser	Meas	Sal.	Temp	Density	S. vel.	Press	Date	Time
1	1	0.00	17.428	-1.297	1474.17	0.43	20/08/2...	04:39:33
1	2	0.00	17.420	-1.295	1474.15	0.40	20/08/2...	04:39:35
1	3	0.00	17.418	-1.295	1474.14	0.41	20/08/2...	04:39:37
1	4	0.00	17.409	-1.293	1474.11	0.38	20/08/2...	04:39:39
1	5	0.00	17.414	-1.294	1474.13	0.38	20/08/2...	04:39:41
1	6	0.00	17.412	-1.294	1474.12	0.42	20/08/2...	04:39:43
1	7	0.00	17.417	-1.295	1474.14	0.40	20/08/2...	04:39:45
1	8	0.00	17.421	-1.296	1474.15	0.37	20/08/2...	04:39:47
1	9	0.00	17.424	-1.296	1474.16	0.38	20/08/2...	04:39:49
1	10	0.00	17.431	-1.297	1474.18	0.39	20/08/2...	04:39:51
1	11	0.00	17.427	-1.297	1474.17	0.39	20/08/2...	04:39:53
1	12	0.00	17.427	-1.297	1474.17	0.38	20/08/2...	04:39:55
1	13	0.00	17.428	-1.297	1474.17	0.37	20/08/2...	04:39:57
1	14	0.00	17.423	-1.296	1474.16	0.39	20/08/2...	04:39:59
1	15	0.00	17.422	-1.296	1474.15	0.39	20/08/2...	04:40:01

- 8 Mark the columns you do not need.  
Position the mouse in the first data row to mark that column.
- 9 Press **Delete selected columns** to remove the columns you have marked
- 10 Move the columns by position the mouse pointer on the column header row and drag the column to right position.
- 11 Press **OK** when selected columns are in right place.  
You will now return to the **Raw file editor**
- 12 Remove all header rows by marking them and press the Delete key on your keyboard.
- 13 Select **Save as...**
- 14 Save the new file in the SIS directory **../common/svp\_abscoeff**  
The file extension is automatically set to **.asvp**
- 15 Modify and load the sound velocity profile into SIS.  
See *How to modify and load a sound speed profile into SIS* on page 132

### How to modify and load a sound speed profile into SIS

This procedure assumes that a sound velocity profile file is available in **.asvp** format.

- 1 Open the **SVP Editor** from the SIS menu  
**Tools→Custom...→SVP Editor**.
- 2 Expand the view by dragging the boundaries of the window.
- 3 Open the **.asvp** file from the **File→Open...** menu
- 4 Adjust the graphical view by

- 1 Select **From depth** and **To depth** according to your depth range  
Use the scroll bar on the right to scroll through your data.
- 2 Select **From speed** and **To speed** according to your recorded sound speed values  
or
- 3 Enable **Automatic speed scale** to automatically adjust the scale to display all sound speed observations
- 5 Check the observations for double entries or upward depths by choosing **Tools→Check profile**  
Observations that are suggested removed are highlighted.
- 6 Press **Delete row** to delete highlighted entries.
- 7 Remove gross errors/spikes from the profile by selecting the point you want to remove
- 8 Press **Delete row** to delete highlighted point
- 9 Continue step 7 and 8 until the profile is acceptable
- 10 Extend the profile from the **Tools→Extend** menu.  
This will add sound velocity values from last observed depth down to 12000 meters depth.
- 11 Thin the profile from the **Tools→Thin Profile** menu.  
This will reduce number of observations to adopt to the PU's limitations for sound velocity observations
- 12 Save the file from the **File→Save as...** menu  
It is recommended to use a filename that identify date, time, place and that the file is thinned
- 13 Select **File→Send primary svp to echosounder** to send the profile selected as you primary profile to SIS.
- 14 Return to SIS.
- 15 Select **Sound speed** in the **Runtime parameters** frame
- 16 Use the browse button to open the correct **.asvp** file.  
Normally the file will have been selected via the **Send primary svp to echosounder** command from SVP Editor.  
When selected the file name will be shown in the text field next to **Use Sound Speed Profile**. The text field background colour will turn yellow, notifying that the input must be accepted to be applied.
- 17 Press **Use Sound Speed Profile** to apply the selected sound speed profile

## 6.7 Start the echo sounder

The echo sounder is started by selecting the desired echo sounder from the **Echo sounder - not started** combo box. The **Logging**, **Pinging** and **Line counter** buttons will all be disabled until the echo sounder is ready. When the echo sounder is ready, you can start to ping.

### How to start the echo sounder

Before you start pinging, the echo sounder must be turned on.

- 1 Press the **Rescan** button to scan for available echo sounders on the network.
- 2 Select your echo sounder from the **Echo sounder - not started** combo box.

The **Logging**, **Pinging** and **Line counter** buttons will all be disabled until the echo sounder is ready. When the echo sounder is ready, you can start to ping.

Single beam echo sounders must be set up and started manually on its own Operator Station.

### Autostart

Echo sounders may start automatically when detected on the network, but only when the detected echo sounders are the same as last time SIS was started. This means that Autostart is not activated when new echo sounders are detected and/or previous used echo sounders are missing. The Autostart mechanism may be enabled/disabled by a setting in the SIS database. Default setting is disabled.

Autostart is enabled from **Tools**→**Custom...**→**Set parameters** under the **Display** settings.

### How to interface a singlebeam echo sounder in SIS

Singlebeam echo sounder (EA 400/600) software from version 2.4.0.0 can be controlled by SIS. SIS will automatically detect their presence on the network and allow you to start/stop pinging and logging from them. Data can still be stored as EA data, as SIS survey data, or both. The depths from the EA will be displayed in the Geographical window.

#### Note

---

*The EA data must contain navigation data to be read by SIS.*

---

- 1 In the EA software:
  - 1 Open the **Network Interface** dialog and locate the **Datagram output** field.
  - 2 Check the **Navigation** box to send navigation data to SIS.

- 3 Open the **Navigation** dialog and locate the **Protocol** field.
- 4 Select the **NMEA** protocol.
- 5 Open the **Operation** dialog box
- 6 Check **SIS** checkbox.
- 7 Press **OK**.

The SIS display will apparently freeze.

- 2 Go to **SIS**
- 3 Press **Rescan** to scan for recognized systems on the network.

**Note**

---

*Both EA 400 and EA 600 systems will be identified by SIS as EA 600.*

---

- 4 Start the EA 600 system from the **Not started** drop-down menu of SIS.  
Allow SIS to initialize the use of the EA system. SIS is ready for use when the **Logging** and **Pinging** buttons becomes selectable.
- 5 Select **Pinging** from SIS to start EA pinging.  
or
- 6 Select **Logging** from SIS to start EA pinging and raw data logging.

The EA system will continue in normal operation.

Your vessel will be shown in the geographical display of SIS.

All EA parameter settings and the display of the Echograms will be shown in the EA software.

**Parameter references**

- *Display* on page 273

**Related topics**

- *Main toolbar* on page 29
- *Echo sounder – Not started list* on page 32

## 6.8 Import a Neptune grid to SIS

If you have a terrain model generated by the Neptune software and want to load this as your background grid in SIS you will need to add a definition of the projection to the Neptune file(s).

**How to import a Neptune grid to SIS**

SIS requires that a projection file is stored in the same folder as the gridded data. This applies both to Neptune and SIS grids. A projection file can be created as follows:

- 1 Select **Tools**→**Custom...**→**Projection setup**
- 2 Locate the **Projections in the database** area
- 3 Press the **Select projection in the database** button
- 4 Select a projection from the list displayed and press **OK**.  
The name of the selected projection is now shown in the **Projection definition** field.
- 5 Press the **Write projection to file...** button.
- 6 Name the file **sis\_proj.txt** and save it.

The Neptune grid can now be imported to SIS using the **File**→**Import/Export...** menu option.

If the desired projection is not available from the database, a new projection can be defined by pressing the **New** button in the **Projection definition** field.

#### Parameter references

- *Projection and datum parameters* on page 308
- *Import/Export* on page 278

## 6.9 Start pinging

### How to start pinging

Pinging must be started manually after the echo sounder is ready. When pinging is *On*, the **Waterfall**, **Cross track** and **Beam intensity** windows becomes active.

- 1 Select the echo sounder you want to ping with in the **Current echo sounder** combo box.
- 2 Press the **Pinging** button on the toolbar. The button is red when *Off* and green when *On*.

The selected echo sounder will now start transmitting.

### Related topics

- *Main toolbar* on page 29
- *Current echo sounder* on page 33
- *Beam intensity view* on page 56
- *Cross track view* on page 58
- *Waterfall view* on page 66

## 6.10 Check sensor input

Proper operation of the external sensors are vital for the SIS operation. These are sensors connected to the PU (Processing Unit) and not directly to the HWS (Hydrographic Work Station).

Sound speed at transducer depth is connected directly to the HWS.

External sensors are continuously monitored in SIS. The **Time series** window presents data from the motion sensor. Sensor data is also shown in the **Numerical display** window. Sensor errors are reported in the **Message service** window.

### **How to monitor the external sensors in SIS**

- 1 Select the **Time series** frame.
- 2 Verify that roll, pitch and heave data is being received by SIS.
- 3 Verify that the roll, pitch and heave data appears according to expected values.
- 4 Select the **Numerical display** frame.
- 5 Verify that values read from all your external sensors, including roll, pitch, heave and sound velocity are close to what you expect.
- 6 Select the **Message service** frame.
- 7 Scroll through the logged messages and verify that there are no messages indicating problems reading the external sensors.
- 8 Select the **PU sensor status** frame.
- 9 Verify that your sensors are marked with green, meaning that sensor is selected as active and that data is being received.
- 10 Select the **Sensor layout** frame.
- 11 Verify that your sensors are located correctly

### **Related topics**

- *Time series view* on page 65
- *Numerical display* on page 62
- *Message service view* on page 62
- *PU sensor status view* on page 77
- *Sensor layout view* on page 87

## **6.11 Check echo sounder main functions**

Before you start logging, you are advised to make sure that the echo sounder system is locked on the bottom and that the swath coverage is as expected.

The **Geographical** window presents a real-time view of the system(s) performance during online operation. The window shows the raw data from the system(s) after corrections have been applied for vessel attitude and sound speed.

Note

---

*The following information applies to multibeam echo sounders only. Single beam echo sounders and GPS equipment do not have this option.*

---

### **How to display realtime depths**

While pinging or logging, realtime depths may be displayed in the **Geographical** window using the following setup:

- 1 Press the **Option** button in the **Geographical** frame's toolbar.
- 2 Expand **Survey** in the left pan of the Geographical Options menu.
- 3 Select the **Realtime Depth**.
- 4 Press **OK**

### **How to verify echo sounder main functions**

Check the following windows:

- 1 Check the **Waterfall** window for a continuous bottom.
- 2 Check the **Cross track** window to see the depths for all the beams ping by ping.
- 3 Check the **Beam intensity** window for reasonable backscattering strengths for each individual beam.
- 4 Check the sensor status in the **Numerical display** window and in the **PU sensor** status.
- 5 Check the **Water Column** display if available.

### **Related topics**

- *Geographical view* on page 52
- *Beam intensity view* on page 56
- *Cross track view* on page 58
- *Numerical display* on page 62
- *PU sensor status view* on page 77
- *Waterfall view* on page 66

## **6.12 Geographical frame settings**

### **How to display seabed imagery data in the Geographical view**

Note

---

*The grid must be generated with the seabed image options enabled. The seabed image can be generated in real time or it can be generated during import of logged raw data.*

---

- 1 Generate seabed image data in real time by
  - 1 Select the **Survey administration** frame.
  - 2 Open the **Survey template handling** tab.
  - 3 Select the **Advanced** tab.
  - 4 Select the **GridEngine parameters** tab.
  - 5 Press the **Processing...** button.or generate seabed image data from logged raw data by
  - 1 Select **File→Import/Export...**
  - 2 Select **Raw data files**
  - 3 Enter Survey name, raw data path and other survey parameters as appropriate
  - 4 Locate the **Grid Engine Parameters** field at the bottom of the dialog
  - 5 Enter appropriate Number of cells and cell size.
  - 6 Press the **Processing...** button.
- 2 Press the **Advanced...** button.
- 3 Tick off for **Seabed Image Processing in Grid Engine**.
- 4 Type a name you want to save your new data cleaning rules as in the text field next to the **Save as** button.
- 5 Press **Save as**
- 6 Press **Apply** to make changes active.
- 7 If you are creating the grid through importing raw data, press OK now and await the import process to finish.
- 8 Select the **Geographical** frame.
- 9 Select the **Options** button.
- 10 Select **Survey→SIS Based Surveys** in the left tree structure.
- 11 Locate the **show/hide** field to the right in of the dialog
- 12 Check the **Seabed Image Overlay** option.
- 13 Select **Survey→SIS Based Surveys→Sonar Display Grid** from the left side tree structure
- 14 Tick off for **Enable Seabed Image**
- 15 Press OK
- 16 Select the area in the geographical view for the area you would like to display with high resolution seabed image by
  - 1 Click left mouse button in start point for the area.
  - 2 Drag the mouse to the end point for the area.
  - 3 Press the shift key.
  - 4 Release the mouse button and the shift key.

- 17 Observe that selected area is shown with seabed image mosaic.

### **Related operational procedures**

- *How to enter survey parameters* on page 102

### **Parameter references**

- *Geographical – Display options* on page 170
- *GridEngine parameters* on page 222
- *Data cleaning* on page 253
- *Import/Export* on page 278

### **How to display a smooth surface**

To see a good model of the seafloor, use the **Option** button and choose **Survey**→**SIS based survey**→**Depth operations: Min.** This will select the minimum value in each grid cell and create a surface from them. Noise will be hidden in this surface, but it will be the shallowest surface drawn very smooth.

- 1 Press the **Geographical option** button
- 2 Expand **Survey** in the left tree structure
- 3 Select **SIS based survey** in the tree structure
- 4 Locate **Depth operation** in the mid field on the right side of the window
- 5 Set **Depth operation** to **Minimum**

### **Parameter references**

- *Geographical – Display options* on page 170

### **How to look for artifacts**

**Inspection mode** is used to scan for objects on the seafloor and to filter out noise that may look like objects. The **I** button is used to toggle **inspection mode** on and off. When in inspection mode, the LOD is set to 0, depth operation is set to median depth and the depth scale factor is set to 2. Toggling the **I** button a second time will restore the previous settings.

Alternatively, you may manually set the inspection parameters as follows:

- 1 Press the **Geographical option** button
- 2 Expand **Survey** in the left tree structure
- 3 Select **SIS based survey** in the tree structure
- 4 Locate **Depth operation** in the mid field on the right side of the window
- 5 Set **Depth operation** to **Median**
- 6 Select **Gridded data** in the tree structure

- 7 Locate **Level of detail**
- 8 Choose a smaller **Level of detail (LOD)**  
You should not start using level of detail 0, as this may overload the system resources. Instead try to use an increasingly smaller level of detail until a good picture is found.
- 9 Select **General** in the tree structure
- 10 Locate **Light source**
- 11 Try to turn the **light source** on and off.  
When off, the light source will follow the mouse cursor and make it easier to see shadows from different angles.
- 12 Select **Survey** in the tree structure
- 13 Locate **Depth scale factor**
- 14 Try to change the **Depth scale factor** to see shadows even better.

#### **Parameter references**

- *Geographical – Display options* on page 170
- *Geographical – Inspection mode* on page 181

#### **Related topics**

- *Geographical view* on page 52
- *Keyboard and mouse in the Geographical view* on page 40

## **6.13 Start and stop logging**

Logging must be started manually after the echo sounder is ready. In the **Current echo sounder** combo box, select the echo sounder you want to ping with.

Note that if pinging is *Off* when logging is turned *On*, pinging will automatically be turned *On*. If logging is *On* and pinging is turned *Off*, logging will automatically be turned *Off*.

### **How to start and stop logging – Alternative 1**

During the survey, the vessel navigates along the pre-planned survey lines. Logging must be started at the beginning of each line. Stop the logging at the end of each line and start it again at the beginning of the next.

At the start of every survey line:

- 1 Press the red **not logging** button on the toolbar.
- 2 Verify that logging starts by that the button turns green.
- 3 Press the green **logging** button when the vessel has reached the end of the line.

- 4 Transit to the next line.
- 5 Press the red **not logging** button when starting the next line.
- 6 Press the green **logging** button when the final survey line has been completed.

### **How to start and stop logging – Alternative 2**

You can also start the logging at beginning of the first line and let it run continuously, toggling survey line change as appropriately.

At the start of the first survey line:

- 1 Press the red **not logging** button on the toolbar.
- 2 Verify that logging starts and the button turns green.
- 3 Press **Line Cnt (xxxx)** at the beginning of each survey line.
- 4 Verify that a new line number has been assigned.
- 5 Press the green **logging** button when the final survey line has been completed.

### **Related topics**

- *Current echo sounder* on page 33
- *Line counter toolbar set* on page 34

### **How to save data**

When the echo sounder has started logging, data is automatically saved to disk.

The **Line counter** button on the toolbar shows the line count for the currently selected echo sounder.

To avoid very large log files the counter for all active echo sounders are incremented automatically every 30 minutes (this is configurable). This, however, only happens when the counter has not been incremented by other means within the last 30 minutes, i.e. by pressing the line counter button or by stopping and restarting logging. **Interval for line counter** is set from **Tools→Set parameters→Logging**.

A full disk warning will be given. When a full disk warning is received, you must copy the surveyed data to an external storage device and delete the data from the logging computer.

### **Parameter references**

- *Logging* on page 274

### **How to log water column data**

Water column data can be logged to either the standard log file (.all) or to a separate water column file (.wcd). Water column data can not be logged to both files simultaneously. Water column logging to separate file is enabled as follows:

- 1 Open the **Installation parameters** frame.
- 2 Select the **Output setup** tab.
- 3 Enable **Log watercolumn to separate file**.
- 4 Open the **Water Column** frame.
- 5 Select the **Show/Hide** toolbar button
- 6 Toggle logging on/off by checking/unchecking the **Logging** option located as second option in the dialog.

#### **Parameter references**

- *PU communication – Output setup* on page 230
- *Water column – Logging* on page 199

## **6.14 Perform a system calibration**

This section contains the following procedures:

#### **Operational procedures**

- *Roll offset in the acrosstrack direction* on page 145
- *Pitch offset and time delay* on page 146
- *Heading offset – Alternative 1* on page 148
- *Heading offset – Alternative 2* on page 149
- *Sound speed quality inspection* on page 151
- *Sound speed control* on page 152
- *Outer beam angle offset calibration* on page 152
- *Verification* on page 153
- *How to determine calibration values using SIS Calibration frame* on page 153
- *How to determine calibration values using SeaCal automatic calibration* on page 156

#### **Note**

---

*This section applies to multibeam echo sounders only.*

---

To ensure maximum reliability and accuracy of the depth determination, it is strongly recommended that the system and it's externally connected sensors are calibrated before the start of a new survey.

All sensors must be accurately surveyed with respect to the vessel's reference point and with respect to the vessel's reference plane during installation of the system. The attitude sensor will normally with intervals be calibrated while along a quay using land survey methods.

The intention of the SIS calibration is to find remaining biases in the installation angles and to find any time synchronization biases between the systems. The biases can origin from transducer alignment, from the alignment of the attitude sensor or be caused by time synchronization differences between the sensors.

The correct calibration of the vessel's attitude sensors as well as determining the time delay of the positioning system is vital to the quality of the depth data determined by the multibeam echo sounder.

The built-in SIS calibration is used to process data from a calibration survey, usually consisting of one or more sets of overlapping lines as described below. It is recommended to use the SIS calibration, where depth data from two or more lines are compared. The offset values are found either by visually determining the correction values that gives best fit between the two depth curves, alternatively by using the SeaCal automatic calibration feature if licensed.

### **Determining a suitable calibration area**

#### **Note**

---

*Sound speed and echo sounder errors are not considered in this discussion. Sound speed must be thoroughly determined for the calibration area.*

---

On a flat area only a roll offset will cause significant depth errors. Thus, if the survey is to be run in a reasonably flat area, it may be sufficient to perform roll calibration only. However, a full calibration is normally required. The calibration must then be carried out to eliminate influence by other errors than the one you are calibrating for.

Note that the positioning accuracy is vital for good calibration results, except for the roll error calibration on a flat bottom.

The ideal calibration area is partly flat and partly a fairly steep slope with little change in depth across track, and with a distinct feature such as a peak or hollow in the flat area. If the heading and positioning errors are negligible, the flat area is not required if the slope has a reasonably constant depth across track. In order to resolve the pitch offset and time delay accurately, the slope should have an appreciable relative change in depth from top to bottom of approximately 30%. Note that the slope should not be too steep, say not more than 20°, otherwise the echo sounder may have problems in maintaining good data quality.

### **Related operational procedures**

- *Run the survey* on page 163

### Parameter references

- *Calibration parameters* on page 213


### Related topics

- *Calibration view* on page 88
- *SeaCal* on page 335

### Roll offset in the acrosstrack direction

- 1 Choose a horizontally flat area (at least acrosstrack)
- 2 Survey two lines in opposite directions.  
Ensure that sufficient lead-in time to the line is used allowing the roll sensor to stabilize.
- 3 Place a calibration corridor orthogonally to the survey lines.

*Figure 9 Roll offset calibration procedure*



- 4 Compare depth data from the two lines in the selected corridor.

If there is a roll offset, there will be a depth difference between the two data sets, increasing with across-track distance from the centre where it is zero.


#### **Pitch offset and time delay**

- 1 Choose an area with a continuous but not too steep slope along-track
- 2 Survey two lines in opposite directions with constant vessel speed along each line
- 3 For time delay calibration, survey a third line on top of the two with constant, but significantly lower speed.

The direction of the last line is not essential. Ensure that sufficient lead-in time to the line is used for the pitch sensor to stabilize.

- 4 Place a calibration corridor parallel to the survey lines, on top of the vessel track

Figure 10 Pitch offset and time delay calibration procedure



(cd022004)

- 5 Compare depth data from the two lines in the selected corridor.

Any alongtrack depth difference between the runs may be due to four different factors:

- Pitch offset
- Time delay between actual position and position when position datagram is supposed to be valid
- For multibeam echo sounders with transducers a position distance offset (either due to an error in the positioning system or an error in entered locations)
- Tide difference

- 6 Determine any time delay in the position system

Note that a depth error on a constant gradient slope, due to pitch offset, increases with increasing depths. Depth errors caused by position time delay increases with vessel speed, whilst errors due to distance offset is independent of depth and speed.

Comparing data from the two lines in the same direction, but with different vessel speed, will thus allow the time delay to be found.

**7 Determine any pitch offset.**

After the correction for time delay error has been applied to the data, the pitch offset can be determined from the two lines run in opposite directions.

**Note**

---

*If PPS and time from datagram are used, there should be zero time delay. Please refer to Timing on page 395 for a detailed explanation.*

---

**Heading offset – Alternative 1**

**Note**

---

*The best check of the gyro is done using land survey methods while in harbour.*


---

**1** Run two parallel lines up or down a slope in the same direction, separated, but with overlap in-between.

**2** Select a calibration corridor.

The corridor used for comparison must be placed alongtrack in-between the lines.

Figure 11 Heading offset calibration procedure  
(alternative 1)



(cd022005)

- 3 Compare depth data from the two lines in the selected corridor.

Any heading offset will give a depth difference between the two lines.


### Heading offset – Alternative 2

- 1 Find an easy recognizable point or feature on the bottom such as a peak or a depression.
- 2 Run two survey lines at opposite sides of this feature so that the point will be in the outer part of the echo sounder swath. Survey these two lines in same direction.

### 3 Select a calibration corridor

The corridor used to compare data from the two survey data sets must be placed so that it intersects the feature, and is parallel to the survey lines.

*Figure 12 Heading offset calibration procedure (alternative 2)*



(cd022007)

### 4 Compare depth data from the two lines in the selected corridor.

If there is a heading offset, you will have a different location alongtrack in the two data sets

Note \_\_\_\_\_

*Accurate positions and position time delays are required.*



### Sound speed quality inspection

- 1 Survey two lines or more, perpendicular to each other.

This means that the two lines in the pair cross each other on a flat area of the sea floor with a difference in the sailing direction of about 90 degrees.

- 2 Create calibration corridors in the crossover area

*Figure 13 Outer beam angle calibration*



(cd022008)

- 3 Compare the depth in different points in the crossover region.

Depth differences along the two centre lines with respect to the outer edges of the swath from the other line (i.e. points 2, 4, 6, 8) will be due either to roll or sound speed errors. Note

that the depth error due to sound speed has the same sign, while those due to roll changes sign across the centre line.

### **Sound speed control**

The same procedure as used for the outer beam angle offset calibration may be used as a check for sound speed corrections. Provided that the roll offset and outer beam angle offsets are correct, any depth deviation between the two lines in the two calibration corridors are due to sound speed errors, either in the used profile, and/or in the sound speed at transducer depth.

### **Outer beam angle offset calibration**

Please see *Outer beam angle calibration* on page 151 for a graphical description of the method.

Note \_\_\_\_\_

*The outer beam angle offset calibration applies to EM 1002 only*

---

Note \_\_\_\_\_

*The outer beam angle offset is critically dependent upon correct roll calibration and correct sound speed calibration.*

---

- 1 Run two perpendicular survey lines on a relatively flat bottom.  
The depth must be approximately 50 to 100 meters, and 150 degrees coverage must be used.
- 2 Set a calibration corridor along each of the lines in the crossover area.
- 3 Compare the depth in different points in the crossover region.  
Any angular error at the points 2, 4, 6 or 8 may be due to errors in:
  - Outer beam angle offset
  - Sound speed
  - Roll offset
- 4 Determine the roll offset  
If sound speed and roll offset are correct, determine angular errors by changing the roll offset angle to make the outer beam depths equal at 2, 4, 6 and 8, and take the average of these.  
  
If the outer beams are too shallow compared to the centre beams, the outer beam angle offset is positive, if they are too deep the outer beam angle offset is negative.

- 5 Add the outer beam angle offset to the outer beam angle offset already used in the installation menu.

### Verification

#### Important

---

After the calibration values have been determined, we strongly advise you to repeat the procedure for verification. This is especially important if you initially had large errors (exceeding 0.1 degrees).

---

### Automatic calibration

SIS offers an automatic calibration using the **SeaCal** program. Calibration survey lines and selection of corridors are as described in the procedures above. **SeaCal** will based on the selected lines and corridor compute the offset values for each parameter that gives best fit, i.e. smallest residual with highest possible reliability. **SeaCal** may be used as an alternative or as an addition to the visual method.

### 6.14.1 How to determine calibration values using SIS Calibration frame

Calibration will only work with two or more selected lines in a survey. The lines must have been surveyed according to recommended patterns. These patterns are:

- Roll calibration: parallel lines over a flat area, in opposite direction and with overlap for the outer beams
- Pitch calibration: parallel lines over a slope, in opposite direction and with lines on top of each other
- Heading calibration: parallel lines over a slope or a seabed feature, same direction and with overlap for the outer beams
- Time: same as for pitch calibration, but with different constant vessel speed for the two lines


#### Note


---

*Stored Shiptracks must be turned on from the **Geographical Options** menu.*

---

- 1 Select **Calibration** from the frame selection drop down list of the main toolbar to enable the calibration mode.



- 2 Press C to enable selection of lines and calibration corridor
- 3 Press the **Follow ship** button  to stop the view from moving along with the ship
- 4 If more than one Survey is loaded, select from the **Survey List** box which survey to use.
- 5 Select the lines by holding down the **Ctrl** button and selecting the lines using **left mouse** button.

You can check that you have picked the correct line by looking at the file name of the selected line that appears in lower left corner of the SIS application window.

#### Note

*You may need to zoom in to be able to separate and select the correct lines*


- 6 Enable selection of a **calibration corridor** to show the depth data for by holding down the **Ctrl** button and click the **right mouse** button
- 7 Select a corridor by holding down the **Ctrl** button and clicking using **left mouse** button at the two end points of the selected line

Data from two or more lines inside this corridor will be analysed.

- For roll calibration – select a corridor across the two survey lines
- For pitch calibration – select a corridor along the survey lines
- For heading calibration – select a corridor along the survey lines
- For timing calibration – select a corridor along the survey lines

When a corridor has been selected, the calibration module will read the raw depth and display them in a diagram.

- 8 Make sure the depth data for the selected survey lines along the selected corridor is displayed in the **Calibration** frame.



The system will use data within the corridor, which represents all points within a specified distance from a calibration line. The data will be displayed using a two-dimensional diagram with the horizontal axis representing the distance along the line, and depth along the vertical axis. Data from two different survey lines will be shown in the same diagram, each with its own colour.

In the Calibration window you can change the offset value of the sensor you are calibrating and immediately see its effect on the depths shown. The offset value giving the best fit between the curves is the result of the calibration.

#### Note

*The offsets applied in the selected files are shown as **Current Offset**. These are not necessarily the current ones in the Installation parameters. Take care to check that the lines used for calibration have been run with the same parameters as the current ones in the Installation parameters*

- 9 Enter an estimated correction value for the sensor you are calibrating, i.e. either roll, pitch, heave or time
- The values can be increase/decreased by using the spin buttons.
- 10 Press **Apply** to calculate and display the effect on the depth curves
- 11 Iterate through step 9 and step 10 until you find the value that gives best visual fit between the two depth curves
- The offset value that gives the best fit between the depths on the two calibration lines is finally to be entered in the corresponding sensor field in the system's **Installation parameters**.
- 12 Write down the offset values you want to use
- 13 Press **Store** to save the new offset values in the database.

- 14 Apply additional correction values to the offset angles entered from **Installation parameters**→**Sensor setup**→**Angular offset**
- 15 Verify the calibration results by rerunning the calibration procedure step 1 to step 13.  
If the calibration was successful, the new correction values will be close to zero.

### Parameter references

- *Angular Offsets for EM 1002* on page 238

### Related topics

- *Calibration view* on page 88
- *Keyboard and mouse in the Calibration view* on page 42

## 6.14.2 How to determine calibration values using SeaCal automatic calibration

Automatic calibration requires two or more selected lines that have been surveyed according to patterns described earlier in this chapter. The lines may be the same as you have used for visual determination of calibration values as described in *How to determine calibration values using SIS Calibration frame* on page 153. If you already have selected your calibration lines you do not have to repeat it.

- 1 Select the lines by holding down the **Ctrl** button and selecting the lines using **left mouse** button.  
You can check that you have picked the correct line by looking at the file name of the selected line that appears in lower left corner of the SIS application window.

Note

*You may need to zoom in to be able to separate and select the correct lines*

- 2 Zoom back to a view showing the complete length of the lines.  
If not, only data from the view will be used in the computation.

- 3 Select what head you are calibrating.

Note

*If you have a dual head system you are allowed to calibrate both heads in one computation. Select **Both heads** to calibrate both heads.*

- 4 Press the **AutoCalib** button

The screenshot shows the 'AutoCalib' window with the following settings:

Parameter	On\Off	Initial Value(s)
Roll	<input checked="" type="checkbox"/>	0
Pitch	<input type="checkbox"/>	0
Heading	<input type="checkbox"/>	0
X0	<input type="checkbox"/>	0
Y0	<input type="checkbox"/>	0
Roll Scale	<input type="checkbox"/>	0
Y-Scale	<input type="checkbox"/>	0
Relative Tide	<input checked="" type="checkbox"/>	
Beam Sector	<input checked="" type="checkbox"/> All	0 90
Maximum sea depth	<input checked="" type="checkbox"/> All	12000
Resolution	<input checked="" type="checkbox"/> Auto	0
Max iterations	<input checked="" type="checkbox"/> Auto	20

Below the table, the 'Type of computation' section has two radio buttons: 'Calibration' (unselected) and 'Calibration with Reliability test' (selected).

At the bottom right are 'Accept' and 'Cancel' buttons.

5 Tick off for the element you are calibration, i.e. either roll, pitch or heading. Further, we recommended to tick off for the following additional parameters:

- Relative Tide: All
- Beam Sector: All
- Maximum sea depth: All
- Resolution: Auto
- Max iterations: Auto


Leave the remaining parameters unchecked.

6 Set **Type of computation** to **Calibration with Reliability test**

7 Press **Accept** to start the computations

Depending on the data consistency there will be a number of iterations carried out. You may follow the iteration process in a command window appearing.

When completed the window **Open SeaCal result file** appears.



- 8 Open the \*.res file. The filename of the result file has the format **Seacal\_yyyymmdd\_hhmmss.res**, where yyyymmdd is date of computation and hhmmss is local time of computation.

Note

---

*For dual head systems the result file name will be **Seacal\_yyyymmdd\_hhmmss.res** for head 1 and **Seacal2\_yyyymmdd\_hhmmss.res** for head 2.*

---

The **SeaCal Results** window will appear. In example below roll has been calibrated giving the following results:

- Roll calibration value = - 0.118, i.e. the correction value that may be applied
- Correlation = - 0.01
- Reliability = - 0.94, i.e. close to 1, which is best achievable figure for reliability

The result values for roll are labelled with green label, which means results are consistent and considered to be reliable.



**SeaCal Results**

Results

Parameter	Value	Correlation	Reliability	Status	Sigma
Roll	-0.118	OK -0.01	OK 0.94		0.000
Pitch	0.000	OK -0.00	Evaluate 0.00	fixed	0.000
Heading	-0.000	OK 0.00	Evaluate 0.00	fixed	0.000
X0	-0.00	OK 0.00	Evaluate 0.00	fixed	0.00
Y0	-0.00	OK 0.00	Evaluate 0.00	fixed	0.00
H0	-0.00	OK 0.00	Evaluate 0.00	fixed	0.00
Roll Scale	-0.00000	OK -0.01	Evaluate 0.00	fixed	0.00000
Y-Scale	-0.00000	OK -0.01	Evaluate 0.00	fixed	0.00000

Legend: OK Evaluate Evaluation strongly recommended

OK

- 9 Press OK to finish.

Note

*No corrections are applied. Correction values must be entered into **Angular Offsets** set in the **Installation Parameters** frame*

Note

*To review the SeaCal results, select **Tools**→**Seacal Results** from the SIS main menu*

### Related operational procedures

- *How to determine calibration values using SIS Calibration frame on page 153*

### Parameter references

- *Seacal auto calibration on page 214*
- *SeaCal results on page 306*

### Related topics

- *SeaCal on page 335*

## 6.15 Plan a survey

### Introduction

A survey plan will normally define the following factors:

- The survey area
- Bottom conditions
- The survey lines
- The direction and order of the survey lines
- The survey lines required for system calibration
- The location and timing for sound speed profiles

When planning the survey lines islands, coastlines, shoals and other obstacles within the survey area that may have influence on safety or efficiency of the survey must be taken into account. The achievable coverage of the multibeam echo sounder and the overlap required between neighbouring lines is usually used to determine the line spacing.

A fully comprehensive survey plan is most useful in areas of deep waters or where the depth and hence coverage is fairly constant. In shallow waters where the depth changes rapidly and may not even be known, a comprehensive plan may not be as useful, especially if the survey is to be run with a small and agile vessel. A defined survey area boundary plus a few pre-planned lines for calibration may then be enough. Actual coverage is obtained on the spot instead of being used to determine the survey lines.

The SIS Planning module allows a survey to be split into sub-surveys or jobs. The survey area boundary may be defined as a polygon with any number of corners, as may areas which are not to be entered. Automatic line clipping at the polygon boundaries and automatic generation of parallel lines is supported.

During the survey, planned lines may be activated to generate steering information for the bridge and helmsman's display. The purpose of the Planning module is thus to provide help before and during the survey.

### **Factors to consider**

- A survey is normally planned taking the following into account:
  - Echo sounder coverage
  - Seafloor topography
  - Sound speed variations
  - Weather conditions
- The requirements for calibration of the positions (time delay), heading, roll and pitch sensors must be considered, and how and where to gather sound speed profiles.

- Coverage capability determines line spacing, and as it varies with bottom reflectivity, this must be estimated. Usually 10% overlap between lines is sufficient, but if large variations in bottom reflectivity is expected, or reflectivity is unknown, it may be necessary to increase the overlap. The overlap must also be increased if the vessel's roll is excessive.
- If there are steep slopes on the bottom, it is strongly advised to run along these slopes, not up or down them. This is beneficial for keeping coverage reasonably constant along the survey lines, thus making survey planning easier. However, the main reason for this advice is that the echo sounder performance will usually be poorer when running up or down a slope rather than along. This is because less acoustic energy is reflected towards the transducer from steep slopes, causing poorer detections and the possibility of false detections in sidelobes. Sidelobe detections is however very rare in the Kongsberg multibeam echo sounders due to the advanced signal processing implemented. Note that if circumstances require that survey lines are run up or down a slope, reduction of vessel speed may be required to allow the echo sounder to track the bottom continuously.
- Coverage capability is also affected by weather conditions and possibly also by vessel speed. Heavy seas and possibly vessel speed lead to increased noise level, and may also cause aeration on the Sonar Head or the transducer array.
- Aeration is a function of sea state, but also of the heading with respect to the wave direction and the vessel speed. It is strongly advised that one builds a record of coverage and aeration problems versus sea state, heading with respect to wave direction, and vessel speed. This record may be helpful in ensuring that surveys can be performed efficiently with a minimum of line rejections and corresponding reruns and infills.
- Any drift rates of roll, pitch and heading should also be recorded to enable efficient planning of calibration intervals. If calibration is required before a survey, a suitable calibration area must be identified before reaching the survey area.
- A sound speed profile must always be taken within the survey area and loaded into SIS before the survey is started. In some areas the profile will vary, mostly due to fresh water inflows from rivers or currents from areas with different salinity. Surface sound speed variation may be strongly affected by solar warming. If variations can be expected, where and when sound velocity profiles are to be taken must be planned, and the survey line schedule adjusted to take this into account.

- If the measured sound speed value at the Sonar Head or the transducer array depth is continuously measured, it is recommended to compare this to what is observed by the profiling instrument to evaluate the need for observing a new profile.
- Note that in some cases the coverage capability of the echo sounder cannot be fully utilized, because remaining errors in roll and sound speed profile measurements, which are critical for maintaining the accuracy of the outer beams, become too large. The ray bending effect (Snell's law) may also reduce the online coverage since the energy can bend inwards.

### **How to plan a new job in SIS**

- 1 Select the **Planning module** frame.  
The Geographical view must also be accessible.
- 2 Expand **Jobs**.
- 3 Press **New job**
- 4 Enter a descriptive name of the job
- 5 Select your preferred coordinate format
- 6 Expand **Objects**
- 7 Select **New line**, **New polygon**, **New line from** or **New object** depending on your plan.
- 8 Select the end points of your object by pointing the mouse in the geographical view, hold the **Ctrl** button while clicking on the **left mouse** button.
- 9 Hold the **Ctrl** button while clicking on **right mouse** button to bring up the **confirm changes** menu.
- 10 Press **Accept** to finish the object
- 11 Press the **New line**, **New polygon**, **New line from** or **New object** again to finish the process.
- 12 Select one of the planned lines or objects by **ctrl + left mouse** button.
- 13 Observe that the buttons that can be used to modify your plan becomes active.
- 14 Edit, move, extend, reverse, make parallel lines, etc. according to your plan.
- 15 Press **Save Job** or **Save Job as....**
- 16 Transfer plan to the Remote Helmsman display when your plan is ready by expanding **Remote** and pressing **Transfer plan**

### **Parameter references**

- *Planning – Jobs* on page 202

- *Planning – Remote* on page 202
- *Planning – Object* on page 203

**Related topics**

- *Planning module window* on page 82
- *Keyboard and mouse in the Planning module view* on page 41

## 6.16 Run the survey

**Operational procedures**

- *How to retrieve a planned job* on page 163
- *How to monitor the survey progress* on page 163
- *How to run the PU simulator* on page 164

**How to retrieve a planned job**

- 1 Open the **Planning module** frame.
- 2 Expand **Jobs**
- 3 Press the **Open job** button.  
A standard file open window appears.
- 4 Select the file where your planned survey lines are stored.
- 5 Verify that the correct job is loaded.
- 6 Expand **Remote**.
- 7 Press **Transfer plan** so send the planned lines and objects to the remote helmsman display.

**Related operational procedures**


- *Plan a survey* on page 159

**Start and stop logging**

Observe the procedures in *Start and stop logging* on page 141.

**How to monitor the survey progress**

There are different ways to monitor the progress depending on the system you are running. The logging and system status is observed and presented in **Status information**. The following is a summary of the **Status information**:



**1 Observe the Geographical window.**

The **Geographical** view gives an overall control of the performance of SIS and the multibeam echo sounder

**2 Observe logging, pinging and line number status.**

On the right hand side of the toolbar there are three buttons which show the status of **logging**, **pinging** and **line number**.

**3 Observe the Numerical display**

In the **numerical display** view you may select the sensor data values you want to monitor.

**4 Observe the status lamps.**

Three **status lamps** on the main toolbar give status of hardware units (applies to multibeam echo sounders only).

**5 Observe the sound velocity.**


### How to run the PU simulator

The PU Simulator is a replay program using logged raw data from EM multibeam echo sounders.


**1 Start the PU simulator from the Tools→Custom...→PU Simulator menu.**

PU.exe will start in the background.


If PU simulator has been run before on your SIS installation you will be prompted whether to continue from last set of raw data or to start a new replay.



- 2 Press **OK** to continue last dataset.  
The **PU control** will open and start output of selected raw data.  
or
- 3 Press **Cancel** to select a different dataset.  
The **PU control** will open.
- 4 Select the raw data files to replay by pressing **Start**.  
A file selection dialog box will open.



- 5 Browse to the directory of your raw data files.
- 6 Press **Open** to activate the replay.
- 7 Observe that raw data from selected type of echo sounder with head serial number 888 is broadcast in the PU.exe command window.



- 8 Return to the SIS window to observe the replayed data.  
You can operate SIS as with any other echo sounder.
- 9 If you have a slow computer, you can press **Pause** to allow SIS to catch up.
- 10 You can control the speed of the simulator by reducing the playback rate
- 11 Press **Stop** in the **PU control** window to stop the simulator

#### **Related topics**

- *Time series view* on page 65
- *Numerical display* on page 62
- *Message service view* on page 62
- *PU sensor status view* on page 77
- *Sensor layout view* on page 87
- *Main toolbar* on page 29
- *Sound velocity profile view* on page 70
- *PU simulator and playback* on page 361

## **6.17 Export data**

Data can be exported into various output data formats. The formats are described in the parameter section of this manual.

To export data use the **Import/Export** dialogue box found in the **File** menu.

#### **Parameter references**

- *Import/Export* on page 278

## **6.18 Remote Helmsman Display**

### **How to start the Remote Helmsman Display**

The Helmsman Display must be connected to the echo sounder's operator station (normally the HWS). From the HWS Operator Station you can control what surveys to be displayed on the remote Helmsman Display as follows:

- 1 Import the survey to be shown
- 2 Select **Transfer grids** from the **Planning module**.
- 3 Verify that the same grids (terrain models) are displayed on the Remote Helmsman Display.

### **How to display planned lines on the Remote Helmsman Display**

You can display all the currently planned lines on the Remote Helmsman Display:

**1 Select Transfer plan from the Planning module**

Current active line will always be sent from the HWS Operator Station to the remote Helmsman Display. The Helmsman is presented with guidance information, such as distance from planned line to current position and other information about current line.

The Helmsman may freely set his own colours, shading, scale and area to display. He can choose to see a completely different area than what is currently surveyed. This makes it possible for the Helmsman to do his own quality assessment of the surveyed data and to take action if required.

If the logging stops for whatever reason, the Helmsman Display will no longer update. This allows the Helmsman to follow the progression of the survey.

**Related topics**

- *Helmsman display view* on page 63
- *Planning module window* on page 82

Installation of the Remote Helmsman Display is described in the SIS Installation Procedure, document number 164891.

## **6.19 Exporting survey results**

**How to export survey results after a survey**

There are several different possibilities and formats available for exporting the results from a survey:

- 1** Raw data as recorded using the binary instrument data format described in the Operator manual – EM series Datagram Formats, published on the webpage [www.kongsberg.com](http://www.kongsberg.com) under multibeam echo sounders. Examples of compatible software systems are Neptune B and CARIS HIPS.
- 2** Flags – The flag is compatible with Neptune B. Data cleaning (flagging out soundings) performed by SIS, can be inspected and/or modified in Neptune B.
- 3** All soundings in xyz-format. The following variations can be selected:
  - Depth in centimetres
  - Tide corrected depth (cm). (Correction are derived from predicted or real time tide.)
  - Geoide and RTK corrected depth (cm).
  - Seafloor to geoide distance (cm).
  - Seafloor to ellipsoid distance (cm)
- 4** Grid node value from Grid Engine, binary or ASCII format.

- 5 Contour lines in DAF format. The DAF format is compatible with the DKART software for electronic charting.
- 6 Terrain model generated by CUBE.
- 7 Raw data converted to .XTF format. This is an option which includes a converter program.

#### **Parameter references**

- *Import/Export* on page 278
- *Export xyz file* on page 286

## **6.20 Exit SIS**

### **How to exit the SIS software**

SIS can be exited by one of the two following methods:

- 1 Stop logging and pinging.
- 2 Select **File**→**Quit**,  
or
- 3 Press the **Close** button in upper right corner of the SIS window.

### **How to shut down the operator station**

The SIS Operator Station is first powered down:

- 1 Switch the power *Off*
- 2 Switch off all peripherals

### **How to shut down the Processor Unit (PU) or the Transceiver Unit**

- 1 Open the door on the Processing/Transceiver Unit
- 2 Switch the power *Off*
- 3 Alternatively, use the Remote Power switch

## 7 PARAMETER REFERENCES

This chapter provides reference information about the dialog boxes, parameters and functions used throughout the Seafloor Information System (SIS). The information is provided in the following order:

- *Frame toolbars parameters* on page 169
- *Calibration parameters* on page 213
- *Survey parameters* on page 216
- *Installation parameters* on page 226
- *Runtime parameters* on page 243
- *SIS parameters – Set parameters* on page 266
- *File menu parameters* on page 278
- *Tools menu parameters* on page 295
- *Projection and datum parameters* on page 308

### 7.1 Frame toolbars parameters

This section contains description of the dialog boxes and parameter settings provided by the **Frame** toolbars in SIS.

#### Topics

- *Geographical – Display options* on page 170
- *Geographical – Show depth under cursor* on page 181
- *Geographical – Grid shading* on page 181
- *Geographical – 2D or 3D* on page 181
- *Geographical – Inspection mode* on page 181
- *Geographical – Compass button* on page 182
- *Geographical – KSGPL edit mode* on page 182
- *Geographical – Planning edit mode* on page 182
- *Geographical – Calibration edit mode* on page 182
- *Geographical – Follow ship* on page 183
- *Geographical – Load background data* on page 183
- *Geographical – C-MAP manipulation mode* on page 183
- *Geographical – Information field* on page 183
- *Beam intensity – Show/hide* on page 185
- *Colour coded depth – Show/hide* on page 186
- *Cross track – Display options* on page 186
- *Seabed image – Show/hide* on page 189
- *Helmsman display – Show/hide* on page 191
- *Time series – Show/hide* on page 193

- *Time series – Clear plot* on page 194
- *Waterfall – Show/hide* on page 195
- *Water column – Show/hide* on page 196
- *Water column – Logging* on page 199
- *Sound velocity profile – Show/hide* on page 200
- *Scope display – Show/hide* on page 200
- *Stave display – Show/hide* on page 201
- *Planning – Jobs* on page 202
- *Planning – Remote* on page 202
- *Planning – Object* on page 203
- *Sensor layout – Show/hide* on page 210

Display buttons related to colour selection, zooming and scaling are not included in the following.

### **Related topics**

- *The application window* on page 21
- *SIS frames* on page 22
- *Toolbars* on page 29
- *View menu* on page 35
- *Keyboard and mouse operations* on page 40
- *Common display buttons* on page 43

### **Related operational procedures**

- *How to monitor the external sensors in SIS* on page 137
- *How to monitor the survey progress* on page 163
- *How to display realtime depths* on page 138
- *How to verify echo sounder main functions* on page 138
- *How to display a smooth surface* on page 140
- *How to look for artifacts* on page 140
- *How to display seabed imagery data in the Geographical view* on page 138

## **7.1.1 Geographical – Display options**

### **Options**

The **Options** menu contains a tree structure on the left side that can be used to select which menu pane (i.e. set of options) to show on the right.


The tree list on the left side contains the following parameter settings:

- General

- Survey
  - SIS Based Surveys
    - \* Sonar Display Grid
  - Neptune Based Surveys
  - Gridded Data
    - \* Shading
  - Point Data
- KSGPL


A number of check boxes becomes available for each of above listed parameter setting.

- **General:** Select general display options for the **Geographical** window.



- **Show/Hide:**
  - \* **Graticule:** Toggle show/hide graticule
  - \* **Survey ship:** Show the survey ship or not.
  - \* **C-MAP background:** Use C-MAP as background map. When the C-Map edit is enabled, clicking the right mouse button in the geographical view will display additional C-Map objects information .
  - \* **Planning:** This will enable the planning module in the **Geographical** window. A planning button **P** will be added to the **Geographical** window toolbar.
  - \* **KSGPL:** Turn KSGPL (Kongsberg SIS Graphic Programming Language) on or off.
    - \* Unchecked: No input/output is allowed. This will also hide all the loaded KSGPL objects.
    - \* Checked: Use predefined settings.
- **Graticule Label Format:** Show or hide the position text fields (latitude and longitude)
  - \* DD.DD: Display position as decimal degrees.
  - \* DD MM.MM: Display position as degrees and decimal minutes.
  - \* DD MM SS.SS: Display position as degrees, minutes, and decimal seconds.
  - \* Projection: Display position as projection coordinates.
- **Light Source:** Toggle light source on or off to achieve shadowed effects
- **Light Position:** Position light source according to your preferences:
  - \* Upper left corner
  - \* Upper right corner
  - \* Lower left corner
  - \* Lower right corner
  - \* Follow cursor

- **Surveys:** Set your preferences for display of current survey.




— **Show/Hide:**

- \* **Realtime depths:** Show realtime depths or not. All depths can be shown as a tail behind the ship.
- \* **Realtime shiptrack:** Show shiptrack current line or not.
- \* **Realtime coverage:** Show coverage from current line or not.
- \* **Surveys:** Set what type of surveys you want to be displayed from
  - \* SIS Based Surveys
  - \* Neptune Based Surveys
  - \* Gridded Data
  - \* Point Data

— **Realtime Depth:**

- \* **Colour by Depth:** Display dynamic colours by depth
- \* **Single Colour:** Display one only one colour for all depths

- **Depth Scale Factor:** Factor by which depth is multiplied by. This has the effect of stretching the grid along the depth axis (i.e. a depth scaling factor of 2 stretches the waterfall grid to twice its normal height). This can make it easier for example to discover artefacts.
  - \* x 1: No scaling
  - \* x 2: Scale the depth by 2
  - \* x 5: Scale the depth by 5
  - \* x 10: Scale the depth by 10
- **Survey Reload:** Interval in seconds between reloading the survey.  
May be set to **Auto Reload** by ticking off the check box.
- **SIS Based Survey**



\* **Show/Hide:**

- \* **Stored Shiptrack:** Toggle to show the stored shiptrack or not. Currently logged line/realtime shiptrack will be stored to disk as a stored shiptrack whenever a new line is being created.
- \* **Stored Coverage:** Show the stored coverage or not. The currently logged line/realtime coverage will be stored to disk whenever a new line is being created.
- \* **Processed Positions:** Shows position quality. The positions can be colour-coded by the quality indicator in the GGA datagram. Note that logging must be off for position quality to be displayed. IFF is extracted from activated survey. See also *Extract IFF* on page 306.
- \* **Seabed Image Overlay:** Enable or disable the seabed image display in the Geographical window.

Note \_\_\_\_\_

*Must be selected to enable seabed image features described in **Sonar Display Grid** in the following.*

---

- \* **Depth Type:** Select depth variable to be displayed.
  - \* Z: Depth, sea surface to sea bottom distance.
  - \* Zt: Tide file corrected depth, vertical datum to seafloor distance.
  - \* Zv: Geoide and RTK corrected depth, vertical datum to seafloor distance.
  - \* Zg: Seafloor to geoide distance.
  - \* Zr: Seafloor to ellipsoid distance.
- \* **Depth Operation:** Parameter to set what depth to be displayed:
  - \* Min: Minimum depth of each cell will be displayed
  - \* Median: Median depth of each cell will be displayed
  - \* Max: Maximum depth of each cell will be displayed


- \* **Grid Colour Value:** Grid values are presented according to given values with given colour scheme.
- \* **Depth:** Display depth values of the grid
- \* **Backscatter:** Display backscatter values of the grid
- \* **Points per cell:** Display number of cells of the grid
- \* **Depth diff. per cell:** Display depth differences in the grid
- \* **Grayscale:** Map a grayscale range (i.e. black to white) to a range of data. The grayscale range and the data range to which the grayscale is mapped are set via the **Dynamic Colours** dialogue.
- \* **Position Colour Coding:** For position monitoring the colour coding of position may be given by
  - \* Single colour, or by
  - \* GPS quality indicator
- \* **Sonar Display Grid:** The seabed image data generated by the grid engine can be viewed in the Geographical display.

#### Note


---

*To show the seabed image data in the Geographical view the following must be enabled:*

- \* The **Seabed Image Overlay** check box located in the **Show/Hide** menu of the **SIS Based Survey** branch of the Geographical Options must be selected.
- \* **Seabed Image Processing in GridEngine** located in **Runtime parameters→Data Cleaning→Advanced**




- \* **Sonar Display Grid:** Check box for enabling seabed image. Disabling this check box will delete all seabed images that has been previously loaded (if any).  
  
The **Clear Image** button will clear the geographical display of the seabed image.
  - \* **Grid size:** Selects maximum number of grid cells that can be viewed by the **Sonar Display Grid** option.
  - \* **Dynamic range:** Sets the minimum and maximum intensity values (dB) for the range to be displayed
- **Neptune based survey(s):** This choice is available only if you have imported Neptune based surveys.



- \* **Colour Coding:** Check box for selecting whether static or dynamic colour scheme are going to be used for the presentation in the Geographical display.

- **Gridded Data:** Parameters for presentation of the gridded data in the Geographical display.




\* **Drawstyle:**

- \* **Points:** Presents gridded data as points
- \* **Triangles:** Presents the triangles used to form the surface formed by the gridded points
- \* **Filled:** Presents the filled triangles
- \* **Text (dynamic colour):** Presents gridded values as colour coded text
- \* **Text overlay (dynamic colours):** Presents the gridded values as colour coded text on top of the filled colour coded surface
- \* **Text (static colour):** Presents gridded values as text
- \* **Text overlay (static colour):** Presents gridded values as text on top of the filled surface

- \* **Level of Detail:** Specifies to what level of details the gridded data are to be presented by in the Geographical display
  - \* **LOD Auto:** SIS will automatically choose the best LOD using available system resources
  - \* **LOD 0:** Presents all processed data
  - \* **LOD 1:** Reduced presentation to 1/4 of LOD 0
  - \* **LOD 2:** Reduced presentation to 1/4 of LOD 1
  - \* **LOD 3:** Reduced presentation to 1/4 of LOD 2
  - \* **LOD 4:** Reduced presentation to 1/4 of LOD 3
  - \* **LOD 5:** Reduced presentation to 1/4 of LOD 4

Refer to *Geographical – Level of Detail* on page 183 for further details

- \* **Transparency:** Set grid transparency. Choose values from 0 (not transparent) to 100 (maximum transparent)
- **Shading:** Set options for the shade model used for displaying the data.



- \* **Triangulation method:** Triangulation can in certain circumstances enhance the picture quality significantly. From this menu you select whether centre point in each grid or the true point are going to be used in the triangulation.
- \* **Smoothing method:** Four levels of grid smoothing can be chosen. Level 0 provides no smoothing. Level 1 through 3 provides increasing levels of smoothing. Higher level requires more processing power, hence it is recommended to leave the smoothing method to level 0 when the CPU load is high.

– **Point Data:**

- \* **Point Type:** Defines what type of points to be displayed of:
  - \* **All** points
  - \* **Valid** points only
  - \* **Invalid** points only
- \* **Point size** in number of pixels
- \* **Max points:** Maximum number of points allowed. If there are more points in the area than this no points will be displayed.

• **KSGPL:**

- **KSGPL Object types:** Available object types:
- \* [0] – Generic objects (objects without an object type)
  - \* [1] – Coast
  - \* [2] – Dryfall
  - \* [3] – Riverbank
  - \* [4] – Text

### 7.1.2 Geographical – Show depth under cursor



The depth of the grid under the cursor can be displayed in a pop-up text box by toggling the **Show depth under cursor** button **D**, or by toggling the **F8** hotkey.

### 7.1.3 Geographical – Grid shading



Grid shading can be toggled on/off via the **Toggle Grid Shading** button **S**. The **F4** hotkey can also be used to toggle the grid shading on/off.

### 7.1.4 Geographical – 2D or 3D



Press the **3D** button to enter the 3D mode. 3D mode will allow you to pan, zoom and rotate the currently loaded grid(s) in 3 dimensions. Panning and zooming will work both in 2D and 3D. **Shift + Right mouse** button will rotate the data. Note that no new data will be reloaded in 3D mode. Press the **3D** button to return to 2D mode.

### 7.1.5 Geographical – Inspection mode



**Inspection mode** is used to scan for objects on the seafloor and to filter out noise that may look like objects. The **I** button is used to toggle **inspection mode** on and off. When in inspection mode, the LOD is set to 0, depth operation is set to median depth and the depth scale factor is set to 2. Toggling the **I** button a second time will restore the previous settings.

### 7.1.6 Geographical – Compass button



The **compass** button is used to read position, distance and heading information from the **Geographical** window. Use **Ctrl + Right** mouse button inside the Geographical window to open the **Compass action** short-cut menu. The following options are available:

- **Measure position:** This is used to display the position of a given point in the view. Move the cursor inside the view. Position information (lat/lon) is given at the cursor's tip.
- **Measure distance and heading:** This is used to measure position, distance and heading between two points in the view. Use **Ctrl + Left** mouse button to mark position 1. Draw a line to position 2 and use **Ctrl + Left** mouse button to mark this position. The requested information is given at the cursor's tip.

### 7.1.7 Geographical – KSGPL edit mode



Press the **KSGPL** button **K** to allow KSGPL manipulation. This button is made available only if the KSGPL option is selected in the **Options→Show/Hide** dialogue box.

### 7.1.8 Geographical – Planning edit mode



Press this button to allow **Planning** manipulation. This button is made available only if the Planning option is selected in the **Show/hide** dialogue box.

### 7.1.9 Geographical – Calibration edit mode



Press the **Calibration** button **C** to allow calibration manipulation. This button is made available only if the Calibration window is opened in one of the other frames.

### 7.1.10 Geographical – Follow ship




This button is used to force current view to follow the ship wherever it moves. It is possible to pan the ship to a user defined location on the screen.

### 7.1.11 Geographical – Load background data



Press the **Load background data** button to add background data to the **Geographical** window. Data can be loaded from the current active survey or you can browse for stored background files (\*.bgksgpl).

### 7.1.12 Geographical – C-MAP manipulation mode




Press the **C-Map** button to allow C-Map manipulation. This button is made available only if the C-Map background is enabled in the **Options**→**Show/Hide** menu. Please note that C-Map functionality requires a separate C-Map license.

#### Related topics

- *C-MAP detail level* on page 37
- *C-MAP – Licence administration* on page 304
- *C-MAP CM-93/3* on page 354

### 7.1.13 Geographical – Information field



The **Information field** shows current scale of the Geographical window and its position in degrees lat/lon with two decimals. The monitor size is read from the database.

### 7.1.14 Geographical – Level of Detail

Data may be displayed in the **Geographical window** with various levels of details, based on the current map scale selected by the operator.

The gridding system use two types of grids:

- Processing grid


- Display grid

The processing grid is used for processing depth data, and the display grid is used for displaying data. Data is transferred from the processing grid to the display grid, and from the display grid with a lower level of detail to the display grid with a higher level of detail.

The number of levels of details depends of the number of cells in the processing grid. A processing grid with 64x64 cells will have 6 levels of detail, in other words  $\log_2(64)$ .

The organization of process grids and display grids may look as shown in the figure below.

*Figure 14 Organization of process grids and display grids (example)*



When looking at a small area it can be convenient to select LOD 0, as all processed data then will be displayed. In a larger scale a higher LOD should be used.

Choose between the following levels:

- LOD 0
- LOD 1
- LOD 2
- LOD 3
- LOD 4
- LOD 5
- LOD auto

## Note

---

*Due to the limitations in memory and processing capabilities inherent in today's PC platform, it is necessary to impose some restrictions in SIS with regard to display and handling of survey data.*

*When a high resolution presentation is selected (e.g. LOD 0) more data must be fetched from the GridEngine to be able to display the necessary details.*

*The restrictions in SIS are imposed when a level of detail other than "LOD auto" is selected. To avoid an overload situation in this case, SIS will restrict the size of the displayed survey area. This will reduce the amount of the fetched data.*


*When "LOD auto" is set, SIS will automatically choose a LOD level that will not overload the system and no area size restrictions are imposed.*

*The settings to control the restriction handling is found in the menu **Tools**→**Custom**→**Set Parameters**→**Advanced display options**. These settings are intended for internal KM use and other advanced users and should normally not be changed.*

---

## 7.1.15 Beam intensity – Show/hide

### Show/Hide button



**Active:** Activate or deactivate the display. Deactivating the display will minimize the CPU usage of the display.


**Axes:** Show or hide the axes.

**Grid Lines:** Show or hide the grid lines.

**Legend:** Show or hide the legend.

## 7.1.16 Colour coded depth – Show/hide

### Show/Hide button



**Active:** Activate or deactivate the display. Deactivating the display will minimize the CPU usage of the display.


**Shade Model:** Options for setting the shade model used for displaying the data.

- **Flat:** Each cell has a distinct colour.
- **Smooth:** Colours are smoothly interpolated between cells.

## 7.1.17 Cross track – Display options

### Display options

The **Options** menu contains a tree list on the left side that can be used to select which menu pane (i.e. set of options) will be shown on the right.




The tree list on the left side contains the following parameter settings:

- Show/Hide
- General
- Scaling

A number of check boxes becomes available for each of above listed cross track display options.

- **Show/Hide:**
  - **Axes:** Show or hide the axes
  - **Grid lines:** Show or hide the grid lines
  - **Legend:** Show or hide the legend
  - **Depth Re Water Line:** Shows the depth (referred to the water line) of the most vertical beam. The size of depth figure is scaled to fit the frame. Enlarging this window makes it easy to read the depth at distance.



- **General:**
  - **Refresh Rate:** Specifies the rate with which the display is updated (i.e. number of times per second)
    - \* 1: Update the display once every second
    - \* 3: Update the display three times per second
    - \* 10: Update the display ten times per second
  - **Across Track Units:** Select the units for the horizontal axis.
    - \* Beams: Units for the across track scale are beams.
    - \* Meters: Units for across track scale are meters.
  - **Colour Coding:** Select colour coding of the depth curve to be displayed as:
    - \* Beam detection: Colours of the depth curve will be red for phase detection and blue for amplitude detection
    - \* Depth value: Colours of the depth curve will be displayed according to dynamic colours for depth set by

the **Dynamic colour** button of the **Geographical** window.  
See *Dynamic colours button* on page 45 for description.


- **Depth value:** Select depth variable to be displayed.
  - \* **Z:** Depth, sea surface to sea bottom distance.
  - \* **Zt:** Tide file corrected depth, vertical datum to seafloor distance.
- **Across Track Style:** Select the line style for the across track plot.
  - \* **Line:** The across track plot is displayed as a continuous line.
  - \* **Points:** The across track plot is displayed as a series of points.
- **Point size:** The size of each point in pixels when the style is **Points**. The value specifies line width in pixels when the style is **Line**
- **Deactivate display:** When selected the display become inactive, thus minimize the CPU usage of the display.
- **Scaling:**
  - **Depth:**
    - \* **Scaling Mode:** Options for controlling the scaling mode for the depth axis.
      - \* **Auto:** Automatically adjust the start and stop ranges to show the entire range of data each time data is received
      - \* **Fixed:** Use the start and stop ranges entered in the min and max text boxes:
        - \* **Min (m):** **Fixed** start (min) range in meters.
        - \* **Max (m):** **Fixed** stop (max) range in meters.
    - \* **Scaling factor:** You can choose to scale the cross track vertically by a multiplication factor or by a percentage of the view. This has the effect of stretching or compressing the cross track plot along the depth axis (e.g. a depth scaling factor of 0.25 compresses the cross track plot to a quarter of its normal height). This may be used for e.g. discovering artefacts.
    - \* **Compress Depth to Fit View:** When this option is selected, the data will not be stretched outside the current view. In cases where the depth scaling factor would cause the data to be stretched outside the view, this option has the effect of overriding the current depth scaling factor and using the next largest factor that will allow the plot to remain inside the current view. If the current depth scaling factor would not otherwise stretch

the data outside the current view, then this setting has no effect.

– **Across:**

- \* **Scaling Mode:** Options for controlling the scaling mode for the across axis.
  - \* **Auto:** Automatically adjust the start and stop ranges to show the entire range of data each time data is received.
  - \* **Fixed:** Use the start and stop ranges entered in the min and max text boxes
    - \* **Min (m):** **Fixed** start (min) range in meters.
    - \* **Max (m):** **Fixed** stop (max) range in meters.
- \* **Keep Across Axis Symmetric:** Keeps the across axis symmetric. If this option is selected, the across axis will be symmetric with respect to zero, even if the coverage is not the same to both sides.

### 7.1.18 Seabed image – Show/hide



**Active:** Activate or deactivate the display. Deactivating the display will minimize the CPU usage of the display.

**Paused:** Pause or continue the display. While paused, the display is shown, but it is not updated with new data.

**Time Markers:** Show or hide the time markers.

**Swath Width:** Options for setting the displayed swath width:

- **Across Min (m):** Across track start (min) range in meters
- **Across Max (m):** Across track stop (max) range in meters
- Auto scaling is enabled by setting the Swath Width to Across Max (m): 1.0 m and Across Min (m): -1.0 m.

**Dynamic Range:** Options for setting the amplitude range used for colour mapping.

- **Amplit. Min (dB):** Minimum expected amplitude

- **Amplit. Max (dB):** Maximum expected amplitude

**Colour Code:** Options for setting the type of colour coding used by the display.

- **High Intensity is Dark:** Darker colour (i.e. more black) indicates higher intensity
- **High Intensity is Light:** Lighter colour (i.e. more white) indicates higher intensity


**Shade Model:** Options for setting the shade model used for displaying the data. Smooth shading may provide slightly better results when the cell size is set larger than 1 pixel.

- **Flat:** Each cell has a distinct colour.
- **Smooth:** Colours are smoothly interpolated between cells.

**Cell Size:** Sets the cell size in pixels. Choosing a larger cell size reduces the CPU usage of this display significantly.

- **1 Pixel:** Cell size is 1 pixel
- **2 Pixels:** Cell size is 2 pixels
- **3 Pixels:** Cell size is 3 pixels
- **4 Pixels:** Cell size is 4 pixels

### 7.1.19 Helmsman display – Show/hide



**Active:** Activate or deactivate the display. Deactivating the display will minimize the CPU usage of the display.

**Position:** Show or hide the position text fields (latitude and longitude).

- **DD.DD:** Display position as decimal degrees
- **DD MM.MM:** Display position as degrees and decimal minutes
- **DD MM SS.SS:** Display position as degrees, minutes and decimal seconds
- **Projection:** Display position as projection coordinates

**DPT:** Show or hide the water depth text field.

**SOG:** Show or hide the speed over ground text field.

- **m/s:** Display speed over ground in units of meters per second
- **Knots:** Display speed over ground in units of knots

**COG:** Show or hide the course over ground text field. This is the course between position updates.

**DTK:** Show or hide the desired track text field. This is the heading of the current line segment.

**BRG:** Show or hide the course to waypoint text field. This is the heading from the current position to the next waypoint.

**XTE:** Show or hide the cross track error text field. This is the shortest distance to the current line segment.

**RNG:** Show or hide the range to waypoint text field. This is the distance from the current position to the next waypoint.

**ETW:** Show or hide the estimated time to the next waypoint text field. This is the estimated time of arrival at the next waypoint.

**ETA:** Show or hide the estimated time of arrival text field. This is the estimated time of arrival at the last point in current planned line.

**XTE Plot:** Show or hide the cross track error plot.

**APB Output:** Enable or disable output of the NMEA APB message to the autopilot.

For the setup of the serial line see *External sensors* on page 295


**Caution**

---

*NMEA APB datagrams contain information about the vessel's position with relative to the active survey line. The correctness of this information is critically dependent of the positioning system input, correct setup of the system and user definition of the survey. Using the APB datagrams as autopilot input is possible as a help in steering the vessel during the survey, but it cannot in any way relieve the vessel crew from the responsibility in safe handling of the vessel. The APB output is only available when the Helmsman Display window is open.*

---

## 7.1.20 Time series – Show/hide



**Active:** Activate or deactivate the display. Deactivating the display will minimize the CPU usage of the display.

**Axes:** Show or hide the axes

- Show or hide axis Y1
- Show or hide axis Y2

**Grid lines:** Show or hide the grid lines.

**Y1 Data Type:** Select the data type to plot on the Y1 axis from the following variables:

- Depth (4 beams): Depth of four user selected beams
- Depth (below keel): Depth below the water surface for the most vertical beam. The centre beam is most likely not the most vertical beam due to the roll of the vessel.
- Depth (centre beam): Depth of the centre beam
- Depth (EM and EA): Depth of the EA (single beam echo sounder) compared to the depth of the shallowest EM (multibeam echo sounder) beam (in the ping) that lies within the footprint of the EA sounder.
- Heave (active): Heave from the active motion sensor. This is selected for graphical presentation.
- Heave (inactive): Heave from the inactive motion sensor. This is logged to the hard disk.

**Y2 Data Type:** Select the data type to plot on the Y2 axis.

- Across (4 beams): Across track distance of four user selected beams
- Backscatter (4 beams): Backscatter strength of four user selected beams
- Backscatter (centre beam): Backscatter strength of the centre beam

- Height: Height from the height sensor
- Pitch/Roll (active): Pitch and roll from the active motion sensor. This is selected for graphical presentation
- Pitch/Roll (inactive): Pitch and roll from the inactive motion sensor. This is logged to the hard disk

**X axis Range Mode:** Mode used to set the X axis (time axis) range.

- Auto: Use the range of the longest displayed data series (show all data)
- Sync: Use the longest range common to all the displayed data series
- Fixed: Set the range to a fixed number of seconds
  - Window: Range (time window) in seconds

**User Beams:** The beams for the data types which require the user to select four beams. This feature is used to compare beams, normally on a flat seabed.

- Beam: First user selected beam
- Beam: Second user selected beam
- Beam: Third user selected beam
- Beam: Fourth user selected beam

**Line Draw Style:** Select the line style for the across track plot

- Line: The across track plot is displayed as a continuous line.
- Points: The across track plot is displayed as a series of points.

**Line width:** The line width in pixels when the style is **Line**. The value specifies point size in pixels when the style is **Points**


**Attitude Step:** Decimal factor for the attitude data

### 7.1.21 Time series – Clear plot



Press the **Clear plot** button to clear the time series display at any time.

## 7.1.22 Waterfall – Show/hide



**Active:** Activate or deactivate the display. Deactivating the display will minimize the CPU usage of the display.

**Paused:** Pause or continue the display of waterfall data. While paused, the display is visible, but it is not updated with new data.

**Gray Scale:** Display the Waterfall in grayscale. This mode requires less CPU than the full colour mode.

**Lighting:** Enable or disable lightning (and 3D shading). Useful in situations where the shape of the grid is such that shading makes the grid (or portions of the grid) difficult to see.

**Colour Scale:** Show or hide the colour scale legend (shown along the bottom of the grid).

**Show All Pings:** When selected, all pings are displayed. When not selected, only the most recent ping is displayed. Deselecting this options can reduce the CPU load of this display significantly (depending on the ping rate).

**Across Track Units:** Select the units for the horizontal axis.

- Beams: Unit for the across track scale is beams
- Meters: Unit for across track scale is meters

**Depth Scale Factor:** Factor to multiply the depth with. This has the effect of stretching the waterfall grid along the depth axis (e.g. a depth scaling factor of 2 stretches the waterfall grid to twice its normal height). This can e.g. make it easier to discover artefacts.

- x 1: No scaling
- x 2: Scale the depth by 2
- x 5: Scale the depth by 5
- x 10: Scale the depth by 10

**View Point:** Set the point from where the grid is viewed.

- Front Upper Left: Set the view point to the front upper left of the grid
- Front Upper Centre: Set the view point to front upper centre of the grid
- Front Upper Right: Set the view point to front upper right of the grid
- Front Middle Centre: Set the view point to front middle centre of the grid

**Light Position:** Set the position of the light source.

- Front Upper Left: Position the light source at front upper left of the grid
- Front Upper Centre: Position the light source at front upper centre of the grid
- Front Upper Right: Position the light source at front upper right of the grid
- Back Upper Centre: Position the light source at back upper centre of the grid

**Waterfall Style:** Set the style in which the waterfall grid is displayed.

- Filled: The grid is displayed as a surface
- Lines: The grid is displayed as a triangle mesh
- Points: The grid is displayed as a point set

### 7.1.23 Water column – Show/hide

#### Show/Hide button



Note



---

*Please note that the Water column show/hide menu has a scroll bar that must be used to see all options.*

---

**Active:** Activate or deactivate the display. Deactivating the display will minimize the CPU usage of the display.

**Logging:** Toggle water column data logging on/off. Note that logging to separate file must be selected from the Installation parameters.



**Axes:** Show or hide the axes.

**Colour Scale:** Show or hide the colour scale legend (shown along the bottom of the grid).

**Detected Depth Curve:** Show or hide a curve showing the detected depth for all beams. The curve is shown on top of the water column data.

**Paused:** Pause or continue the display of water column data. While paused, the display is visible, but it is not updated with new data.

**Stretch Data to Fill View:** When this option is not selected, the same scale is used for both the x- and y-axis. The data is displayed with correct proportions, but this may result in a lot of unused space in the view. When selecting this option, the x- and y-axis are scaled to fill the window.

**Head 1:** Show or hide the data from sonar head 1.

- **Max Angle Port:** The maximum beam angle to the port side for sonar head 1
- **Max Angle Stbd:** The maximum beam angle to the starboard side for sonar head 1

**Head 2:** Show or hide the data from sonar head 2 (applicable for dual sonar head sounders only).

- **Max Angle Port:** The maximum beam angle to the port side for sonar head 2
- **Max Angle Stbd:** The maximum beam angle to the starboard side for sonar head 2

**Overlap Mapping Mode:** Options for controlling how the data in the overlapped region is displayed (applicable to dual sonar head echo sounders only).

- **Cut:** The data from each head is cut vertically at 0 meters across
- **Blending Type A:** The overlap area is blended using alpha blending. No saturation in the overlap area.
- **Blending Type B:** The overlap area is blended using alpha blending. Saturated in the overlap area.

- Head 1 on Top: The data from head 1 is displayed on top of the data from head 2.
- Head 2 on Top: The data from head 2 is displayed on top of the data from head 1.

**Note**

---

*Blending Type A and Blending Type B Overlap Mapping Mode options are not enabled if the background colour is any other colour than black. Although it is not possible to change the background colour using Water Column Display menus, the SIS application does provide means to change the background colour via the Colour Dialog menu.*

---

**Depth Start Range Mode:** Options for controlling the start range mode of the depth axis scale.

- Auto: Automatically set the start range of the depth axis to match the minimum value of the data each time data is received.
- Auto Once: Automatically set the start range of the depth axis to match the minimum value of current data, then lock to this value in fixed range mode.
- Fixed: Use the start range for the depth axis entered in the Range (m) text box
  - Range (m): Fixed start range (in metres)

**Depth Stop Range Mode:** Options for controlling the stop range mode of the depth axis scale.

- Auto: Automatically set the stop range of the depth axis to match the maximum of the data.
- Auto Once: Automatically set the stop range of the depth axis to match the maximum range of current data, then lock to this value.
- Fixed: Use the stop range entered in the (Stop) Range text box.
  - Range (m): Fixed depth axis stop range (in metres).

**Across Start Range Mode:** Options for controlling the start range mode of the across axis scale:

- Auto: Automatically set the start range of the across axis to match the minimum value of the data each time data is received.
- Auto Once: Automatically set the start range of the across axis to match the minimum value of current data, then lock to this value in fixed range mode.
- Fixed: Use the range entered in the (Start) Range text box.
  - Range (m): Fixed across axis start range (in metres)

**Across Stop Range Mode:** Options for controlling the stop range mode of the across axis scale.

- Auto: Automatically set the stop range of the across axis to match the maximum value of the data each time data is received.
- Auto Once: Automatically set the stop range of the across axis to match the maximum range of current data, then lock to this value in fixed range mode.
- Fixed: Use the range entered in the (Stop) Range text box.
  - Range (m): Fixed across axis stop range (in metres).

**Colour Map Mode:** Select the type of colour mapping to be used by the display.

- Colour: Map a range of colours to a range of data. The range of colours and the data range to which the colours are mapped are set via the **Dynamic Colours** dialogue.
- Grayscale: Map a grayscale range (i.e. black to white) to a range of data. The grayscale range and the data range to which the grayscale is mapped are set via the **Dynamic Colours** dialogue.

### 7.1.24 Water column – Logging

Water column data can selectively be logged to either the standard log file (.all) or to a separate water column file (.wcd). Water column datagrams can not be logged to both files simultaneously.


Water column logging to separate file must be enabled in the **Output setup** tab under **Installation parameters**.

Logging is toggled on/off from the Water column **show/hide** menu.

Please note that the logged data amount is very large, that is, typically 1 to 2 Gigabytes per hour.

Separate water column data (.wcd) files may optionally be logged to a disk different from that used for the raw data (.all) files. Water column data file locations are set from the **Logging** option accessed from **Tools**→**Custom**→**Set Parameters** for details.

### 7.1.25 Sound velocity profile – Show/hide




**Active:** Activate or deactivate the display. Deactivating the display will minimize the CPU usage of the display.

**Axes:** Show or hide the axes.

**Grid Lines:** Show or hide the grid lines.

**Data Points:** Show the sound velocity profile sample values on the sound velocity profile plot.

### 7.1.26 Scope display – Show/hide



**Active:** Activate or deactivate the display. Deactivating the display will minimize the CPU usage of the display.

**Axes:** Show or hide the axes.

**Grid Lines:** Show or hide the grid lines.

**Legend:** Show or hide the legend.

**Annotation:** Show or hide the on screen text annotation.

**Data As Point:** Show the data series as a series of points, rather than a solid line.

**Amplitude:** Show or hide the amplitude plot.

**Filtered Amplitude:** Show or hide the plot of the filtered amplitude.

**Phase:** Show or hide the plot of the electrical phase difference between the two so-called half beams. This is also called the interferometric, or split beam, phase signal.

**Axis Setup:** Option for defining number of grid lines along the x and y axes.

- Y Division: Number of divisions along the y-axis
- X Division: Number of divisions along the x-axis


**Start Range:** Options for controlling the start range mode of the x-axis scale.

- Auto: Automatically set the start range of the x-axis to match the minimum value of the data each time data is received.
- Fixed: Use the start range for the x-axis entered in the Range (s) text box
  - Range (s): Fixed start range (in seconds)

**Stop Range:** Options for controlling the stop range mode of the x-axis scale.

- Auto: Automatically set the stop range of the x-axis to match the maximum of the data.
- Fixed: Use the stop range entered in the (Stop) Range text box.
  - Range (s): Fixed stop range (in seconds).

### 7.1.27 Stave display – Show/hide



**Active:** Activate or deactivate the display. Deactivating the display will minimize the CPU usage of the display.

**Axes:** Show or hide the axes.

- Axis Y1: Show or hide the Sample axis (the vertical axis to the left of the grid).
- Axis Y2: Show or hide the Range axis (the vertical axis to the right of the grid).

**TVG Curve:** Show or hide the TVG (time varying gain) curve. When shown, the TVG curve is displayed on top of the Stave data grid.

**Colour Scale:** Show or hide the colour scale legend (shown along the bottom of the grid).

**Paused:** Pause or continue the display of stave data. While paused, the display is visible, but it is not updated with new data. This may be useful for example if you want to look at the cell information of more than one cell in the grid for a single ping.

**Start Range Mode:** Options for controlling the start range mode for the vertical scale(s).


- Auto: Automatically set the start range to match the minimum range of the data each time data is received.
- Auto 90: Automatically set the start range to be 90 percent of the range to normal incidence each time data is received.

- **Auto Once:** Automatically set the start range (once) to match the minimum range of the data, then keep this fixed range.
- **Fixed:** Use the range entered in the Range (samples) text box.
  - Range (samples): Fixed start range (in samples).

**Stop Range Mode:** Options for controlling the stop range mode for the vertical scale(s).

- **Auto:** Automatically set the stop range to match the maximum range of the data each time data is received.
- **Auto Once:** Automatically set the stop range (once) to match the maximum range of the data, then keep this fixed range.
- **Fixed:** Use the range entered in the Range (samples) text box.
  - Range (samples): Fixed stop range (in samples).

### 7.1.28 Planning – Jobs



These buttons are used to create and save a new job, or to reactivate an existing job.

A job is a collection of planned lines and possibly one or more polygons. Each job is given a unique name. A job must first be selected as the current job before any other operations can be performed. The selected job can either be new, or you can continue to work on an existing job.

The following options are available:

- **New Job:** Create a new job
- **Open Job:** Open an existing job
- **Save Job:** Save the current job
- **Save Job as...:** Save the current job using a different name
- **Clear Job:** Clear the current job from the graphical display

### 7.1.29 Planning – Remote

These buttons are used to transfer data to a remote Helmsman Display, see *Remote Helmsman Display* on page 166.

Whenever data is transferred to the remote display it will replace whatever is already there. All defined lines, polygons and grids will automatically be transferred if **Transfer Plan** or **Transfer Grids** is selected.

The following options are available:

- **Transfer Plan:** Transfers lines and polygons to the remote display
- **Remove Plan:** Removes lines and polygons from the remote display
- **Transfer Grid:** Transfers the terrain data to the remote display
- **Remove Grid:** Removes the terrain data from the remote display

### 7.1.30 Planning – Object

#### Object

These buttons are used to create and manipulate lines and polygons within an existing job.

Buttons are enabled/disabled depending on allowed actions. As an example, a line must be activated in order to be able to deactivate it.

The following options are available:

- **New Line:** Create a new line by holding the Ctrl key down while clicking the left mouse button for each new point. At the end of the line, click the right mouse button to accept or cancel the operation.

This option is active until the **New Line** button is pressed again or **New Polygon** is selected.

- **New Polygon:** Create a polygon by holding the Ctrl key down while clicking the left mouse button for each new point in the polygon. Note that a polygon must have at least three nodes. When last point is defined, click the right mouse button, still holding down the Ctrl key, to accept or cancel the operation.

This option is active until the user changes to another option or presses the button once more.

- **New Line From:** Create a new line by entering the start position, it's azimuth and distance. The start coordinates can be given in geographical or projection coordinates.

- **New Object:** Create lines or polygons by entering the coordinates. The following features are available:
  - Object type: Select Line or Polygon
  - Coordinate type: Select Geographical or Projection coordinates
  - Name: Give the object an identifying name
  - Add: Add coordinates for a new point
  - Delete: Delete point from the list
  - Up/Down: Change the order of the points

- **Extend Line:** This option is only allowed if one line only is selected.


Press the **Extend Line** button to show the two end points of the line. Select which end you want to extend by holding the Ctrl key down while clicking on it with the left mouse button.

Click the right mouse button to accept or cancel the operation. When accepting, the object is deselected.

- **Activate Line:** First select the line, then press the **Activate Line** button to make the line active. The activated line will have a new colour and be deselected. This line will be sent to the Helmsman display (if present).
- **Deactivate Line:** First select the line, then press the **Deactivate Line** button to make the line inactive. This line will be removed from the Helmsman display (if present).
- **Reverse Line:** Every line has a defined direction, shown by a dot at the start of the line. Pressing the **Reverse Line** button will reverse the direction of all selected lines. Accepting this action will deselect the lines. Click the right mouse button to accept or cancel the operation. When accepting, the object is deselected.
- **Rename:** Press the **Rename** button to open a dialogue where you can change the object's name. The object will remain selected.

This option is only allowed if one object only is selected.

- **Make Parallels:** A user defined number of lines parallel to a selected line can be created using this option. Select a line and then press the button to open the **Parallel Lines** dialogue. This dialogue allow you to define how many lines to create in both directions (port and starboard). The distance and spacing between the lines (in metres) must be specified. Click the right mouse button to accept or cancel the operation. When accepting, the line is deselected.




This option is only allowed if one line only is selected. Any selected polygons are ignored.

- **Make Turn:** This option is used to create a turn between two lines. Pressing the **Make Turn** button will create a turn by adding a new line between the end point of the first line and the start point of the second line.

This option is only allowed if two (and only two) lines are selected.


- **Keep Lines Inside:** This option is used to clip the parts of a line lying outside the borders of a polygon.



When accepting, the objects are deselected. Multiple lines can be selected.

- **Keep Lines Outside:** This option is used to clip the parts of a line lying inside the borders of a polygon. When accepting, the objects are deselected. Multiple lines can be selected.
- **Fill Polygon:** This option is used to fill a polygon.

Select a polygon and a line and select **Fill Polygon**. This dialogue allow you to define the distance and spacing between parallel lines to be created (both port and starboard directions). The lines will be clipped at the polygon's border. When accepting, the objects are deselected.



- **Move Point:** Any point can be moved. Select a line or a polygon and press the **Move Point** button to show all points of the selected object. Select which point you want to move by holding the Ctrl key down while pressing the left mouse button and moving the mouse. The selected point will move with the mouse cursor until left mouse button is released. Pressing the left mouse button again elsewhere in the view, will continue moving the point with the mouse cursor until the mouse button is released again. This action needs to be confirmed prior to moving other points. When accepting, the line is deselected. This option is only allowed if one object only is selected.

---

**Note**

*It may be difficult to hit a point on an object if the point is directly on top of another object. Zooming in on the point may help.*

---

- **Insert Point:** A point can be inserted to an existing line or polygon. Select a line or a polygon and press the **Insert Point** button to show all points of the selected object. Insert a point by holding the Ctrl key down and clicking on one of the line segments using the left mouse button. After inserting the desired number of points, click the right mouse button to accept or cancel the operation. When accepting, the object is deselected.

This option is only allowed if one object only is selected.

Inserting a point may be found difficult. You may alternatively edit the SIS database as follows:

- 1 Get the current threshold value by calling:  

```
getParameter.bat
GEOVIEW_PLANNING_INSERT_VERTEX_THRESHOLD 1
```
- 2 Increase this value by 20 and update the database by calling:  

```
"setParameter.bat
GEOVIEW_PLANNING_INSERT_VERTEX_THRESHOLD 1 N"
```

 where "N" is the new value.
- 3 Open the **Show/Hide** button in the **Geographical** display, deselect the **Planning** check box, press **Apply**, then check **Planning** and press **OK**.

If this did not help, try to increase the value a bit more.

- **Delete Point:** Any point can be deleted. Select a line or a polygon and press the **Delete Point** button to show all points of the selected object. Delete a point by holding the Ctrl key down and clicking on it using left mouse button. After deleting the desired number of points, click the right mouse button to accept or cancel the operation. When accepting, the object is deselected.

Note that when deleting points, you must leave at least two points on a line and three points on a polygon.

This option is only allowed if one object only is selected.

#### Note

*If you find it difficult to delete a point in an object, the point may be directly on top of another object. Zooming in on the point may help.*

- **Edit Selected:** This option is used for editing objects. Select an object and press the button to open the **Planning Edit Module** dialogue.

This dialogue allow you to change, delete or add points as well as renaming the object. After updating, the object is deselected.

**Edit Selected**

Object Type: ☐ Line ☒ Polygon

Coordinate Type: Geographical (DD.DD)

Name: Poly\_1

Add Delete Up Down

	East/West	North/South
1	10.380372	59.489429
2	10.380337	59.490445
3	10.382697	59.490869
4	10.384098	59.489448

Ok Cancel

This option is only allowed if an object only is selected.

- **Move Selected:** Any object can be moved. Select one or more objects and press the **Move Selected** button. Move the objects by holding the Ctrl key down, pressing the left mouse button and then moving the mouse. The objects will move with the mouse cursor until releasing the left mouse button.

After moving the objects to the wanted location, click the right mouse button to accept or cancel the operation. When accepting, the objects are deselected.

This option is only allowed if at least one object is selected.

- **Delete Selected:** Press this button to remove all selected objects from memory. No confirmation is required.

This option is only allowed if at least one object is selected.

- **Export Selected:** Press this button to append all selected objects to an already existing job (to file).

This option is only allowed if at least one object is selected.

### 7.1.31 Sensor layout – Show/hide



#### Note

---

*Please note that the Sensor layout show/hide menu has a scroll bar that must be used to see all options.*

---


**Antialiasing:** Apply antialiasing to make the drawing appear smoother on the screen

**Ship:** Show or hide the ship

- Line width: in pixels

**Ships water line:** Show or hide the ship's water line

- Line width: in pixels



**Water plane:** Show or hide the water plane

- Water plane width: in meters
- Transparency: scaled from 1 to 100, where 100 is fully transparent and 1 is not transparent

**XY meter mesh:** Show or hide mesh in XY plane

- Width (m): Mesh width in metres

**XZ meter mesh:** Show or hide mesh in XZ plane

- Width (m): Mesh width in metres

**YZ meter mesh:** Show or hide mesh in YZ plane

- Width (m): Mesh width in metres

**Origo sphere:** Show or hide the ship's reference point as a small sphere

- Radius (cm): Radius of sphere, max 25 cm
- Transparency: scaled from 1 to 100, where 100 is fully transparent and 1 is not transparent


**Active sensors only:** Show or hide all system defines sensors

**Position system:** Show or hide the location of the position system

- Line width: in pixels
- Joint radius (cm): Position system is shown as a sphere with given radius. Max radius is 20 cm

**Motion sensor:** Show or hide location of motion sensors

- Line width: in pixels
- Joint radius (cm): Motion system is shown as a sphere with given radius. Max radius is 20 cm



**Transducer/head:** Show or hide location of transducer or head

- Line width: in pixels
- Joint radius (cm): Transducer or head is shown as a sphere with given radius. Max radius is 20 cm

**Depth sensor:** Show or hide location of depth sensor

- Line width: in pixels
- Joint radius (cm): Transducer or head is shown as a sphere with given radius. Max radius is 20 cm

**Echo sounder beam 1:** Show or hide visualisation of beam 1

- Depth: To what depth the beam is visualised (in metres)
- Transparency: scaled from 1 to 100, where 100 is fully transparent and 1 is not transparent

**Echo sounder beam 2:** Show or hide visualisation of beam 2, if applicable

- Depth: To what depth the beam is visualised (in metres)
- Transparency: scaled from 1 to 100, where 100 is fully transparent and 1 is not transparent

**Pipe:** Show or hide a visualisation of a seabed pipe

- Diameter (cm): of pipe (true size)
- Length (cm): of pipe
- Depth (cm): of pipe
- Transparency: scaled from 1 to 100, where 100 is fully transparent and 1 is not transparent

## 7.2 Calibration parameters

### Related operational procedures

- *How to determine calibration values using SIS Calibration frame on page 153*
- *How to determine calibration values using SeaCal automatic calibration on page 156*

0010\_20080116\_113636\_Pingeline.all Dir: 1.8 Spd: 2  
0009\_20080116\_113147\_Pingeline.all Dir: 180.4 Spd

☐ Head 1 ☒ Head 2 ☐ Both heads

Depth Value to use

Corridor Width (m)

Element	Current offset	Correction
Roll MRU (deg)	<input type="text" value="1.26"/>	<input type="text" value="0"/>
Pitch MRU (deg)	<input type="text" value="0.07"/>	<input type="text" value="0"/>
Heading MRU (deg)	<input type="text" value="0.04"/>	<input type="text" value="0"/>
Time (sec.)	<input type="text" value="0.00"/>	<input type="text" value="0"/>

The following calibration parameters may be set:

- **Head 1 / Head 2 / Both heads:** Select the sonar head(s) to be calibrated. Head 2 applies to dual head systems only.
- **Depth Value to use:** Choose between depth, tide corrected depth and depth referred to vertical reference point.
- **Corridor width (m):** Use the slidebar or the textfield to give a new value. Press **Set** to activate.
- **Current offset:** The Current offsets fields are used to show the offset values used when the data was logged. This field can not be changed.

- **Correction:** Set the correction value you believe give best fit between the curves. Press **Apply** to activate.


Note \_\_\_\_\_

*Only one element must be corrected for each set of lines*

---

- **Roll MRU (deg):** Use the slider or the textfield to give a new value. Press **Apply** to activate.
- **Pitch MRU (deg):** Use the slider or the textfield to give a new value. Press **Apply** to activate.
- **Heading MRU (deg):** Use the slider or the textfield to give a new value. Press **Apply** to activate.
- **Time (ms):** Use the slider or the textfield to give a new value. Press **Apply** to activate.

### Show/Hide button



**Show grid:** Show or hide the grid.

**Show legend:** Show or hide the legends

**Depth Scaling mode:** Options for controlling the scaling mode for the depth axis.

- **Auto** - Automatically adjust the start and stop ranges to show the entire range of data each time data is received.
- **Fixed** - Use the start and stop ranges entered in the min and max text boxes.
  - **Min (m):** Fixed start (min) range in meters.
  - **Max (m):** Fixed stop (max) range in meters.

### 7.2.1 Seacal auto calibration

The following **Auto Calib** parameters can be entered:

- Roll
- Pitch
- Heading
- X0 (translation alongships)
- Y0 (translation athwartships)
- Roll scale

- Y scale
- Relative tide
- Beam sector
- Maximum sea depth

For each parameter to be used, the corresponding On/Off button must be checked.

- **Resolution:** The resolution of the grid model applied in the calculation affects the computing time. The **Auto** option asks **SeaCal** to compute the resolution, but you can also define the resolution manually.
- **Max Iterations:** Usually, **SeaCal** needs two or more iterations to compute the calibration. You can define the maximum number of iterations manually, or you select **Auto**, i.e. **SeaCal** iterates until the solution is stable.
- **Type of computation:** It is also possible to select calibration with or without a reliability test. It is recommended to run this test, as it gives a comprehensive control of the calibration.

## 7.3 Survey parameters

This section contains a description of the dialog boxes and parameter settings provided by the **New survey** and the **Survey administration** frames in SIS.

### Topics

- *Basic parameters* on page 216
- *Storage options* on page 219
- *Background data* on page 220
- *Projection parameters* on page 222
- *GridEngine parameters* on page 222
- *User handling* on page 224
- *CUBE parameters* on page 225

The survey parameters that can be set and administrated from these dialogs partly overlap each other, but differs slightly depending on whether a new survey is being set up or the survey parameters are being modified.

### Related operational procedures

- *How to enter parameters for a new survey* on page 105
- *How to enter survey parameters* on page 102
- *How to define a new projection and datum transformation* on page 107

#### 7.3.1 Basic parameters

**Basic parameters** are accessed through **New survey**→**Basic Parameters**.

The survey name is mandatory when creating a new survey. Further, it is required that the parameters for the default surveys are maintained by the user.

The screenshot shows a 'New Survey' window with three tabs: 'Basic Parameters', 'Storage options', and 'Advanced options'. The 'Basic Parameters' tab is selected. Inside this tab, there are two buttons at the top: 'Save new survey' and 'Continue on existing survey'. Below these buttons are four dropdown menus: 'New Survey name' (a text input field), 'Select survey-template' (set to 'Default'), 'User' (set to 'SIS user'), and 'Existing Surveys'. At the bottom of the tab is a 'Comment' text area.

### Parameters

- **New Survey name:** Give a unique name to your survey (mandatory)
- **Select survey-template:** Load Storage and Advanced Options parameters defined in a template
- **User:** Select the identification of the user. To add new user(s), refer to *User handling* on page 224.
- **Existing Surveys:** Select an existing survey. Press **Continue on existing survey** button before the survey can be changed
- **Comment:** Give additional information about the survey
- **Save new survey:** Create the new survey. All parameters stored under the **Storage options** tab and the **Advanced options** tab are stored in the database for this new survey

The **Basic parameters** are also located under the **Survey templates handling** tab on the **Survey administration** frame. The look and parameters differs slightly from when accessed from **New survey**.

The Survey template handling manages the default surveys used as template.

The screenshot shows a web-based interface for survey administration. The main window is titled 'Survey administration' and has three tabs: 'User handling', 'Background data', and 'Survey templates handling'. The 'Survey templates handling' tab is selected. Inside this tab, there are three sub-tabs: 'Basic Parameters', 'Storage options', and 'Advanced options'. The 'Basic Parameters' sub-tab is active. It contains a section titled 'Add/Change survey template' with the following fields: 'New Survey template' (a dropdown menu), 'Select survey-template' (a dropdown menu with 'Default' selected), 'User' (a dropdown menu with 'SIS user' selected), and 'Comment' (a large text area). Below these fields is an 'Update' button. Below the 'Update' button is a section titled 'Delete survey template' with a 'Survey template' dropdown menu (set to 'empty') and a 'Delete' button. At the bottom of the 'Basic Parameters' sub-tab is a 'Survey type as default' dropdown menu (set to 'Default').

### Parameters - Add/Change survey template

- **New Survey name:** Select the survey you want to add/change from
- **Select survey-template:** Select a survey template for the parameters for Storage options and Advanced options
- **User:** Select a user. To add new user(s), you must use the **User handling** tool, see *User handling* on page 224.
- **Comment:** Write your own comment for the survey template
- **Update:** Update the existing default survey or add a new default survey to the database. This includes the parameters stored under the **Storage options** tab and the **Advanced options** tab.

### Parameters - Delete survey template

- **Survey name:** Select the survey you want to delete
- **Delete:** Delete the selected survey

## Parameters - Survey type as default

- **Default/Previous:** Define which default survey is to appear in the Select survey-type combo box

### 7.3.2 Storage options

**Storage options** are accessed through the **New survey** frame or through the **Survey administration** frame on the **Survey template handling** tab.


## Parameters

- **Survey data storage location:** Specify the location to store Survey Data files. Enter the folder identification directly, or use the browse button to navigate
- **Raw data root location:** Specify the location to store Raw Data files. Enter the folder identification directly, or use the browse button to navigate. Press the **Apply to all default surveys** button to apply
- **Current raw data storage structure:** Description of current structure
- **Use current structure:** Keep current structure
- **Clear new survey:** Create a new structure
- **Build raw data storage structure from tickboxes:** Build a new storage structure by enabling the check boxes you want to use. The new structure will appear in the text field behind **New raw data storage structure**
- **Shipname:** To identify the data files by your ship's name if the **Use as postfix in filename** check box is ticked off

- **Apply to all default surveys:** Update these parameters for all default surveys in the database. If you want to store these parameters to a particular survey, you must select a different survey template from the **Basic Parameters**

### 7.3.3 Background data

**Background data** is located under the **Advanced options** tab in the **New survey** display view and under the **Advanced options** tab under the **Survey templates handling** tab on the **Survey administration** display view.



#### Parameters

- **Path to Background data:** Choose the path you want to use for the background data. You can use the browse button to find a path
- **Comment:** Write your own comment for the background data
- **Apply this path to Default survey:** Apply the path.

If you want to store these parameters to a particular survey, you must use the **New Survey**→**Basic parameters** or **Survey Administration**→**Basic parameters**.

In the background data directory the following files can be stored:

- Projection setup: **proj.txt** used to define the geographic projection for the survey.
- KSGPL background data: **\*.ksgpl**. KSGPL formatted files with background data to be shown in the Geographical display.
- Predicted tide: **predictedtide.tide**, predicted tide file.
- Geoid model: **geoidmodel.geoid**, geoid model.

**Background data** can also be accessed from **Survey administration** frame. The look and the parameters differs slightly when accessed from here.

The screenshot shows a software window titled "Survey administration" with three tabs: "User handling", "Background data" (selected), and "Survey templates handling". Inside the "Background data" tab, there are two main sections: "Add data" and "Delete data".

The "Add data" section contains:
 

- A "Pathname" label followed by a dropdown menu showing "C:\sisdata\common\background" and a browse button ("...").
- A "Comment" label followed by a text area containing the text "Default background data".
- An "Add" button at the bottom.

The "Delete data" section contains:
 

- A "Pathname" label followed by an empty dropdown menu.
- A "Comment" label followed by an empty text area.
- A "Delete" button at the bottom.

### Parameters – Add data

- **Pathname:** Set the path to the background data
- **Comment:** Write your own comment for the background data
- **Add:** Add the selected path

In the background data directory these files can be stored:

- Predicted tide: `predictedtide.tide`, predicted tide file.
- Geoid model: `geoidmodel.geoid`, geoid model.
- Background image: Tiff and geotiff files.

If you want to store these parameters to a particular survey, please refer to *Basic parameters* on page 216.


### Parameters - Delete data

- **Pathname:** Select the path you want to delete from the combo box
- **Comment:** See information given about the selected path
- **Delete:** Delete selected path

### 7.3.4 Projection parameters

**Projections** is located under the **Advanced options** tab on the **New survey** display view and under the **Advanced options** tab under the **Survey templates handling** tab on the **Survey administration** display view.

When defining a survey or a survey template, you have to define what projection to use in that survey or survey template. New projections can be created and tested using the **Projection setup** application available from the **Tools→Custom** menu.



#### Parameters

- **Projection:** Select a projection from the drop-down combo box
- **Apply this projection to the Default survey:** These projections will be saved in the database for all default surveys

If you want to store these parameters to a particular survey, you must use the **New Survey→Basic parameters** or **Survey Administration→Basic parameters**.


If a survey is loaded into SIS, the user is prompted to change projection. If yes, all earlier surveys loaded into SIS will be removed, before activation of the new survey.

It is possible to change projection after a projection has been set.

### 7.3.5 GridEngine parameters

The **GridEngine parameters** is located under the **Advanced options** tab on the **New survey** display view and under the **Advanced options** tab under the **Survey templates handling** tab on the **Survey administration** display view.

When defining a survey or a survey template, you have to define what parameters to use for the GridEngine.



## Parameters

The terrain modelling module in SIS uses an internal Processing Grid. Nine Processing Grids may be loaded into RAM simultaneously. The Processing Grid is a square, and the size of one side should be approximately the expected swath width.

To find the best suited grid size the following rule of thumb may be used:

Expected coverage  $\approx$  Number of cells x Cell size

To achieve best possible resolution the cell size should be as small as possible. Number of cells must be increased accordingly to maintain the expected coverage.

### Note

---

*If the cell size is set too small the memory usage may become overloaded, and the display is unable to follow in real time.*

---

If the computer has sufficient RAM, a small Grid Cell Size may be selected. In that case, the number of Grid Cells in the Processing Grid may be increased.

- **Depth variable:** Set the depth variable to be displayed.

The depth variable can be set to:

- Z: Depth, sea surface to sea bottom distance.
- Zt: Tide file corrected depth, vertical datum to seafloor distance.
- Zv: Geoide and RTK corrected depth, vertical datum to seafloor distance.
- Zg: Seafloor to geoide distance.
- Zr: Seafloor to ellipsoid distance.

- **Number of cells:** Set number of cells in the processing grid:
  - 16 x 16
  - 32 x 32
  - 64 x 64
  - 128 x 128
  - 256 x 256
  - 512 x 512
- **Cell size (cm):** Set the cell size (in m). The selectable range is from 0.1 to 150 m
- **Processing parameters:** Set the Ping processing and Grid processing rules. These rules are explained under the **Data Cleaning** tab. See *Data cleaning* on page 253
- **Apply to all survey templates:** This will update the grid engine parameters for all survey templates currently in the database.  
If you want to store these parameters to a particular survey, you must use the **New Survey**→**Basic parameters** or **Survey Administration**→**Basic parameters**.

### 7.3.6 User handling

User handling is located under the **Survey administration** display view.

The screenshot shows a window titled "Survey administration" with three tabs: "User handling" (selected), "Background data", and "Survey templates handling". Inside the "User handling" tab, there is a sub-section titled "Add user / Change User information". This section contains a "User" label next to a dropdown menu, a "User Info" label next to a large text input area, and an "Update" button at the bottom.

#### Parameters – Add user/Change user information

- **User:** Type the name of the new user  
The user parameter is logged in the raw survey format files (.all-files). This makes it possible to recall who was responsible for the survey.
- **User Info:** Type any additional information about the user
- **Update:** Apply your changes

### 7.3.7 CUBE parameters

The CUBE (Combined Uncertainty and Bathymetry Estimator) algorithm is developed at The Centre for Coastal and Ocean Mapping (C-COM)/Joint Hydrographic Centre (JHC) at University of New Hampshire. The algorithm is available as a library and is used inside one separate module in SIS. The CUBE algorithm can be used as an alternative data gridding and data cleaning method in SIS. The gridding and data cleaning is a default process done by the GridEngine.

A CUBE grid can be generated for all the raw data files in a survey when logging is completed. This requires that all necessary parameters are defined in the survey template.

The screenshot shows a multi-tabbed window titled "Survey administration". The tabs are "User handling", "Background data", and "Survey templates handling". The "Survey templates handling" tab is active, showing sub-tabs "Basic Parameters", "Storage options", and "Advanced options". The "Advanced options" sub-tab is active, showing further sub-tabs "Background data", "Projections", "GridEngine Parameters", and "Cube parameters". The "Cube parameters" sub-tab is selected, displaying a form with the following fields:

- Depth variable: A dropdown menu with "Z" selected.
- Origin North: A text input field with the unit "deg.decimal degree" to its right.
- Origin East: A text input field with the unit "deg.decimal degree" to its right.
- Width: A text input field with the unit "km" to its right.
- Height: A text input field with the unit "km" to its right.
- Grid cell size: A text input field with the unit "meter" to its right.

#### Related topics

- *CUBE* on page 375

## 7.4 Installation parameters

This section contains a description of the dialog boxes and parameter settings provided by the **Installation parameters** frame in SIS.

### Topics

- *PU communication – Input setup* on page 226
- *PU communication – Output setup* on page 230
- *PU communication – Clock setup* on page 232
- *Sensor setup – Settings* on page 233
- *Sensor setup – Locations* on page 237
- *Angular Offsets for EM 1002* on page 238
- *System parameters for EM 1002* on page 239
- *BIST – Built-In Self Test* on page 240

### Related operational procedures


- *How to open the installation parameter interface* on page 112
- *How to modify the installation parameters* on page 112

#### 7.4.1 PU communication – Input setup

**Input Setup** is located under the **PU Communication Setup** tab on the **Installation parameters** display view.

#### Note

*When Input Setup configuration is changed the Sensor Setup tab must be checked. It is specifically important to check the Active Senors setting.*



### Parameters

**Input port:** This drop-down combo-box is used to select which of the PU (Processing Unit) ports the dialogue box shall apply to. Choose between the serial ports COM1 to COM4 or the network port UDP2.

- COM1: Normally used for position, clock and depth input.
- COM2: Designated to input from a motion sensor.
- COM3: Optional (position, motion and heading input).
- COM4: Optional (position and heading input).
- UDP2: Position and depth input.

#### COM port parameters:

- **Baud rate:** Define the baud rate for the currently selected serial port.
- **Data bits:** Select the number of data bits for the currently selected serial port.
- **Stop bits:** Select the number of stop bits for the currently selected serial port.
- **Parity:** Select the parity for the currently selected serial port.

#### The network addresses are as follows:

System	Network address
EM 120/EM 122:	157.237.14.60
EM 300/EM 302:	157.237.14.60
EM 710:	157.237.2.71
ME 70:	User defined
EM 1002:	157.237.15.60
EM 2000/EM 3000:	157.237.2.58
EM 3002:	157.237.2.61


#### The UDP have the following port setting:

Port	Port number
UDP2:	2022
UDP3:	2032 Currently not used
UDP4:	2042 Currently not used
UDP5:	User defined

- **Attitude 1** and **Attitude 2** radio buttons decide which of the two possible motion sensors to be used.
- **Use Ethernet 2** defines if the PU Ethernet 2 device are to be used or not. If not selected the sensor input is assumed to go via the traditional Ethernet 1. It is recommended to use Ethernet 2 for the Attitude Velocity. The Port number will still be used.
- **IP addr.** sets the IP address used by the Attitude Velocity sensor when transmitting data. **Net mask** sets the netmask to be used.
- **Port** sets the port number used by the Attitude Velocity sensor when transmitting data according to the following available settings:

Sensor	Port number
Kongsberg Seatex Seapath 200	3001
Applanix POSMV	5602
CodaOctopus F180	3000

Figure 15 UDP input principles



**Note**

*If the UDP port is occupied, a network switch must be installed. Alternatively the **Data Distribution** program can be used. See Data distribution on page 450*

*Using a switch is recommended for local nets only, not for the ship's main network, as this may overload the Processor Unit.*

---

**Input Formats:** This area allows you to define what type of external sensor is connected to the serial or network port you selected in the **Input port** combo box.

Inputs in the following formats are available:

- GGK Positions
- GGA Positions
- Simrad90 Positions
- GGA\_RTK Positions
- Attitude
- ZDA Clock
- HDT Heading
- SKR82 Heading
- MK39 Heading
- DBS Depth (NMEA)
- DBT Depth (NMEA)
- EA500 Depth
- ROV Depth
- Height (special purpose only)

Refer to the Datagram Formats in the appropriate user documentation for a description of these formats.

**Restrictions to sensor input**

A number of restrictions apply to the selection of the PU (Processing Unit) input formats. These restrictions are integrated into the user interface and will be reflected in the enabling/disabling of check boxes for the different ports. The restrictions are as follows:

- Only one positioning system is allowed on each port, with a maximum of three positioning systems
- Positioning system 1 is by definition on COM1
- Positioning system 2 is by definition on COM3
- Positioning system 3 is by definition on COM4 or UDP2 (AUV Processing Units do not have COM4)

- Only one motion sensor is allowed on each port, with a maximum of two motion sensors
- Motion sensor 1 is by definition on COM2
- Motion sensor 2 is by definition on COM3
- A motion sensor cannot share a serial line (COM) with other sensors
- Only one stand alone heading sensor is allowed
- The Sperry MK39 MOD2 motion sensor (roll, pitch, heading) can only be used on serial line COM3
- A stand alone heading sensor using SKR80/82 format can only be used on a COM (serial line) port. This port cannot be shared by others sensors when in use
- Only one clock input (normally ZDA) is allowed plus a single 1PPS clock sync. signal. See *PU communication – Clock setup* on page 232
- Only one depth sensor is allowed (pressure sensor for ROV)
- The EA500 format can only be used on UDP2

**External Trigger:** When selected, an external trigger signal causes the echo sounder to send a ping. The Pinging on/off function must be on.


## 7.4.2 PU communication – Output setup

**Output Setup** is located under the **PU Communication Setup** tab on the **Installation parameters** display view.

**Output setup** is used to defined what datagrams to be output from the PU (Processing Unit) to the following:

- SIS raw data logging
- Raw data logging to PU disk
- User defined selection to third party systems (e.g. Quincy or HiPack)

Enabling of water column data logging to separate file is enabled from here.



## Parameters

**UDP host port:** Available options depend on system connected.

- **SIS Logging** is used by the system define what SIS raw data to log. The settings for this link should normally not be changed. Mandatory datagrams are disabled from deselecting
- **User defined** is a free format that can be set up to contain the required datagrams. By using the given Port address these datagrams can be picked up by any third party systems with access to the same network.
- **PU Logging** applies to systems where internal logging to PU disk is possible

**Port address:** Port address. Can NOT be changed.

Note \_\_\_\_\_

*Port number 2999 is reserved for internal use.*

**Log watercolumn to separate file** enables logging of water column data to a \*.wcl file. Water column data file locations is set from the **Tools→Custom→Set Parameters** menu.

See *How to log water column data* on page 142 for details.

**PU broadcast enable:** Tell the PU (Processing Unit) to broadcast its presence on the network, using port 1999. The PU will send out a broadcast datagram every second to port 1999.

**Datagram subscription on the UDP port:** The table below shows datagram subscriptions available for various multibeam echo sounders.

Datagram	Echo sounder									
	EM120	EM122	EM300	EM302	EM710	EM1002	EM2000	EM3000	EM3002	ME70
Depth	x	x	x	x	x	x	x	x	x	x
Raw range and beam angle	x	x	x	x	x	x	x	x	x	x
Seabed image	x	x	x	x	x	x	x	x	x	x
Central beams	x		x							
Position	x	x	x	x	x	x	x	x	x	x
Attitude	x	x	x	x	x	x	x	x	x	x
Heading	x	x	x	x	x	x	x	x	x	x
Height	x	x	x	x	x	x	x	x	x	x
Clock	x	x	x	x	x	x	x	x	x	x
Single beam echo sounder	x	x	x	x	x	x	x	x	x	


Datagram	Echo sounder									
	EM120	EM122	EM300	EM302	EM710	EM1002	EM2000	EM3000	EM3002	ME70
Sound Speed Profile	x	x	x	x	x	x	x	x	x	x
Runtime parameters	x	x	x	x	x	x	x	x	x	x
Installation parameters	x	x	x	x	x	x	x	x	x	x
BIST reply	x	x	x	x	x	x	x	x	x	x
Status parameters	x	x	x	x	x	x	x	x	x	x
PU broadcast	x	x	x	x	x	x	x	x	x	x
Stave display		x		x	x				x	
Water column		x		x	x				x	x
Hull unit						x				

### 7.4.3 PU communication – Clock setup

**Clock Setup** is located under the **PU Communication Setup** tab on the **Installation parameters** display view.

**Clock Setup** is used to set the PU clock based on selected input source.

Please refer to *Timing* on page 395 for detailed description about timing in SIS.



The echo sounder system has an internal clock with 1 millisecond resolution. This clock is used to time stamp all logged data. The clock will drift, typically some seconds per day, unless it is synchronized to a 1PPS (one pulse per second) input signal. The 1PPS signal will determine the clock's drift rate, and in practice reduce it to zero using a GPS receiver as source.

The clock may be set in three situations:

- 1 When the PU is initialized during start-up of PU from SIS.
- 2 When the Clock Source is changed.
- 3 When a new survey is started.

A fully correct clock is only necessary if the output data are later to be combined with other time critical data logged or created by other systems, for example an accuracy of up to one minute would be necessary to apply tidal changes.

If the timestamp supplied in the position input datagrams is to be used, it is imperative that the system clock is correctly set and that 1PPS synchronization is used.

### Parameters

**Source:** This selector is used to define the source for the synchronization of date and time. The following options are available:

- External ZDA clock (UTC time received in ZDA format)
- Active Positioning System (time stamp of position datagram)
- Operator Station
- No sync

**Offset [sec]:** The offset value is applied to the source time. Use it to offset the source time to the local time or whatever time zone you require.

**1PPS Clock Sync:** Click to turn on the 1 pulse per second external clock synchronization.

1PPS input signal is normally “resting” at a high level. Each second, a low going 100 mS-1000 mS pulse adjusts the second counter in the PU (Processing Unit). Since 1PPS is a TTL-signal, a high level at the input connector must be higher than 2.7 Vdc (the margin is then 0.3 Vdc) and a low level (during the pulse) must not exceed 0.6 Vdc (the margin is then 0.2 Vdc).


### 7.4.4 Sensor setup – Settings

**Settings** (of sensors) is located under the **Sensor Setup** tab on the **Installation parameters** display view.

Note \_\_\_\_\_

*When the Input Setup configuration is changed the Settings must be verified!*

---



## Positioning systems parameter settings

You can connect three positioning systems to the multibeam echo sounder, but only one can be active at a time. One positioning system can be connected using a network port (UDP2) instead of a serial line.

Data from all positioning systems are logged, and may all be used in post-processing. However, only the positioning system selected as active will be used in the realtime displays. (See *Active sensors parameter settings* on page 236).

For each of these positioning systems, some basic parameters must be defined.

**Positioning System Ports:** Use this drop-down combo box to choose which positioning system you wish to set the parameters for. The positioning system is thus not identified by its name, but by the port it is connected to.

The following ports are available:

- COM1 (positioning system 1)
- COM3 (positioning system 2)
- COM4 (positioning system 3)
- UDP2 (positioning system 3)

**Time to use:** Usually the system's internal time is used during logging, since the clock reference will be identical for positions and depths. Any time delay in the positioning system and the data transmission from the sensor must be taken into account. This is done by defining a fixed average position delay (see below).

If this delay is not sufficiently constant - and provided that the time stamp in the position datagram is the time when the position was valid - the input datagram's time stamp may be used. However, it must then be assumed that the multibeam echo

sounder and the positioning system clock are both synchronized with the 1PPS signal, and that any time difference between the two clocks are entered as a position delay.

Select Datagram or System:

- **Datagram:** This choice allows the use of the time stamp in the input datagram when applying positions to the realtime display.
- **System:** The multibeam echo sounder will use its own internal time stamp when applying positions to the real time display

Note

---

*Both time stamps are stored, hence the time reference can be changed or corrected in post processing.*

---

**Enable position motion correction:** When the vessel moves due to roll, pitch and heave, the antenna on the positioning system moves as well. This parameter allows the system to compensate for this movement by adjusting the values from the positioning system based on current information from the motion sensor(s).

Correct timing of the positions is very important if motion correction is to improve position accuracy.

**Position delay (sec):** This parameter is used to define the age of the position in the position datagrams.

The relative timing of vessel position data and system depth data is critical to the total achievable accuracy. The best solution is if it can be assured that the position datagrams are always received by the system with a fixed and sufficiently constant age with respect to the time of validity of the enclosed positions. This age is the position delay to be entered. Such a solution will make the use of any clock synchronization of the system with the positioning system unnecessary.

**Datum:** This parameter enables you to set the internal datum identical to what the positioning system sends to the echo sounder. This will also be logged onto the harddisk. The projection reference in the survey module must also be set accordingly.

**Log all heights:** This parameter enables height datagrams sent from the PU based on input from the GGA and GGK position input.

**Pos. qual. indicators for height acceptance:** Enter the quality indicator numbers (comma separated) that you want to interpret as accepted height observations.

### **Motion sensors parameter settings**

You can connect two motion systems to the multibeam echo sounder, but only one can be active at a time. Data from both systems will be logged. The motion system you have selected as active will be used in the real time displays. For each of these motion systems some basic parameters need to be set.

**Motion Sensor Ports:** Choose which motion sensor you wish to set the parameters for. The motion system is not identified by name, but by the port it is connected to.

The following ports are available:

- COM2 (motion sensor 1)
- COM3 (motion sensor 2)

**Roll reference plane:** The roll reference plane is used to define the reference plane against which the roll angle is measured.

Select Horizontal or Pitch/Roll Plane:

- **Horizontal:** Select this alternative if roll is measured against the horizontal plane, i.e. against the plane normal to the gravity vector. This is the convention used by the Hippy 120, often emulated by other sensors.
- **Pitch Roll axis plane:** Select this alternative if roll is measured against a plane defined as horizontal in the across-track direction, but following the vessel pitch in the along-track direction, i.e. as a rotation around the forward pointing axis of the vessel coordinate system. This is the convention usually used by inertial systems such as the POS/MV (the Tate-Bryant convention).

**Motion delay (msec):** This parameter is used to define the expected time delay of the motion data.

If the data from the attitude sensor are delayed with respect to when they were valid, this may be corrected by the system provided the delay is known. This delay may be due to filtering and/or processing time in the sensor, and should be provided by its manufacturer. Some sensors are able to compensate for such delays by a prediction, but it is not advisable to use such a feature.

### **Active sensors parameter settings**

Only one positioning system, one motion sensor and one heading sensor can be active at a time.

The selection of which system/sensor to be active is performed by selecting which input port the relevant equipment is connected to. The available choices for each system/sensor is dependant on the settings made in the Input Setup configuration of the PU (Processing Unit).

Refer to *PU communication – Input setup* on page 226 for more information.

There is a drop-down combo box for each of the system/sensor types.

#### Note

*When the Input Setup configuration is changed the Active Sensor setting must be checked.*

**Position:** Select port number of active positioning system.

**Motion:** Select port number of active motion sensor.

**Heading:** Select port number of active heading sensor.

## 7.4.5 Sensor setup – Locations

**Locations** (of sensors) is located under the **Sensor Setup** tab on the **Installation parameters** display view.

Location offset (m)	Forward (X)	Starboard (Y)	Downward (Z)
Pos, COM1:	0.00	0.00	0.00
Pos, COM3:	0.00	0.00	0.00
Pos, COM4/JDP2:	0.00	0.00	0.00
TX Transducer:	0.00	0.00	0.00
RX Transducer:	0.00	0.00	0.00
Attitude 1, COM2:	0.00	0.00	0.00
Attitude 2, COM3:	0.00	0.00	0.00
Waterline:			0.00

#### Note

*The screen layout above is an example only. Some echo sounder uses “Sonar head” instead of “Transducer”.*

In order to make correct computations, SIS must know the physical location of all sensors, including it’s transducers.

The locations must be referred to the vessel’s reference point. The location of each system must therefore be given as a forward (x), downward (z) and starboard (y) position relative to the reference point. The coordinate system assumes that the x-axis follows the vessel’s keel, and that the x-y plane is horizontal while the vessel is in normal trim.

## Parameters

**Positioning systems (Pos):** These settings are used to define the physical location of the selected positioning system’s position point, i.e. the point on the ship where the position is valid.

Note

---

*The position data you define here may however not necessarily be the physical location of the antenna. This is because settings in the positioning system's own software may redefine the location of the antenna. The xy values of the soundings are referred to the location of the active positioning system, and it is this virtual position that you must enter.*

---

The downward locations are required if the bottom is being determined with respect to a vertical datum.

The downward position will also be used if the positions are to be corrected for vessel attitude. This requires that the actual physical antenna position is entered and that the given position is at the antenna.

**Transducer array(s) / Sonar Head (s):** Use these settings to define the physical location of the centre of the face of the respective transducer arrays or sonar heads.

**Motion sensor (Attitude):** The Motion Sensor parameters allow you to define where the sensor is physically located, or where its data are valid, e.g. in case the motion sensor is programmed to calculate heave at a different location than where it is actually mounted.

**Waterline:** Enter the vessel's waterline (in normal trim) related to the vessel's reference point. The value should be an average of two measurements; one on each side of the vessel. The measurement must be made at the same alongship location as the physical location of the motion sensor.

Note

---

*If the vessel's displacement or trim changes during a survey, this value must be updated accordingly.*

---

**Depth sensor:** Position of depth sensor.

## 7.4.6 Angular Offsets for EM 1002

**Angular Offsets** (of sensors) is located under the **Sensor Setup** tab on the **Installation parameters** display view.

	Roll	Pitch	Heading
Transducer:	0.00	0.00	0.00
Attitude 1, COM2:	0.00	0.00	0.00
Attitude 2, COM3:	0.00	0.00	0.00
Stand-alone Heading:			0.00

In order to make correct observations, the system must know the physical angles between the transducers, sensors and the vessel coordinate system.

Offset angles are partly determined during installation and partly during calibration.

## Parameters

**Transducer:** Use this setting to enter the installation angles. These settings are normally entered once and for all, but if the vessel undergoes repair or maintenance etc. and the array is moved, the installation measurements must be repeated and new angles defined.

**Motion sensors (Attitude):** Use these settings to set a correction to the values received from the motion sensors. The settings are added to the values received from the sensors.

**Stand-alone Heading:** Use this setting to set a correction offset from the values received from the heading sensor. It is only allowed to enter positive values. Example: If the offset is -0.15, you must enter 359.85.

## 7.4.7 System parameters for EM 1002

System parameters is located on the **Installation parameters** view.

Gain and Angle Correction		Hull Unit Options	
BS Offset (dB)	0.0	Hull Unit Included	<input type="checkbox"/>
HiLo Freq. Gain Diff (dB)	6.0	Hull Unit Tilt Offset (deg.):	0.0
Outer beam Angle Offset (deg.):	0.0		

### Parameters - Gain and Angle Correction

- **BS (Backscatter) Offset (dB):** The acoustic backscatter strength of the bottom is calibrated in our factory, and have a typical accuracy of  $\pm 1$  dB.

However, this value may be offset from zero to serve as a correction factor, for example if there is a change with the age of the system, or if data from two different systems are going to be merged and the data from them show a systematic offset.

- **HiLo Freq. Gain Diff (dB) (HI / LO Frequency Gain Difference):** The system uses three sectors with a higher frequency (98 kHz) in the middle and a lower in the outer two (93 kHz). Depending on the actual transducer, this may result in a gain difference in the backscatter measurements. The **HiLo Frequency Gain Difference** parameter will allow you to compensate for this difference.
- **Outer beam Angle Offsets (deg):** The pointing angles of the outer beams of the EM 1002 depend on the sound speed of the transducer coating material. This parameter will allow you to add a correction for this effect. The value may need changing with transducer aging and sea temperature (a compensation for temperature is built into the system software, but it may not be 100% effective). The actual parameter value must be found by estimating the beam pointing angle error in degrees by comparing the depths measured in  $+75^\circ$  beam pointing angle with that measured with the vertical beam. This is most easily done by running two lines perpendicularly and using the roll calibration application to find the angle offset.

### Parameters - Hull Unit Options

- **Hull Unit included:** The EM 1002 may be supplied with a Hull Unit with mechanical pitch compensation. This information is obtained from the Transceiver Unit and the parameter is not changeable.
- **Hull Unit Tilt Offsets (deg):** This setting is used to compensate for a fixed tilt setting of the Hull Unit. It is only enabled for update if a Hull Unit is present.

### 7.4.8 BIST – Built-In Self Test

The **BIST (Built-In Self Test)** options provide a number of automatic tests that may be started to check the operation of the echo sounder system.

**BIST** is located on the **Installation parameters** display view.

Various test are available, and the test presented will depend on what system you have.

## Parameters

- **Clear all:** Press to clear results of previous BIST tests.
- **Run all BISTs:** Press to run all available BIST tests.

Note \_\_\_\_\_

*All tests are executed when selected.*

---

- **BIST test buttons:** Single BIST tests can be run by pressing the corresponding test buttons.

The button turns green if the test results are OK, it turns yellow if the test is not successfully carried out. The button will turn red if the test fails.


Note \_\_\_\_\_

*The test is executed when selected.*

---

- **Save:** The results of the BIST tests may be saved to file. Press **Save** to set file name and storage location.
- **PU BIST Result area:** The results are presented in this area with the following information for each test:
  - Date: Date when the test was run.
  - Time: Time when the test was run.
  - Ser. No: Serial number of the transceiver unit.
  - BIST: The number of the BIST test that has been run.
  - Result: The overall result of the test.
  - Description: A description of the test returned from the PU (Processing Unit).

EM 1002 BIST



The following tests are available:

EM 1002 BIST

0	BSP Test
2	SPRX Test
3	TRX Power Test
4	TX Power
5	SPRX/BSP Link
6	RX Channels
7	RX Noise Level
8	TX Ram
10	TX via RX
11	Calibration offsets
15	Software Date/Version
17	Reboot BSP Cards

For systems with hull unit included:

20	Hull Unit
21	Hull Unit MOSINT
22	Hull Unit servo

For description of the various tests please refer to the Maintenance Manual.

## 7.5 Runtime parameters

This section contains a description of the dialog boxes and parameter settings provided by the **Runtime parameters** frame in SIS

### Topics

- *Sounder main for EM 1002* on page 243
- *Sound speed for EM 1002* on page 246
- *Filter and gains for EM 1002* on page 250
- *Data cleaning* on page 253
- *Javad and Trimble* on page 261
- *ATH Logging* on page 261
- *Simulator for EM 1002* on page 263
- *Survey Information* on page 265

### Related operational procedures

- *How to open the runtime parameter interface* on page 116
- *How to modify the runtime parameters* on page 117
- *How to collect the sound velocity profile* on page 125
- *How to convert your sound velocity profile to SIS format* on page 126
- *How to modify and load a sound speed profile into SIS* on page 132

### 7.5.1 Sounder main for EM 1002

- Define the pingmode, the desired swath coverage and the beam spacing
- Define maximum port and starboard coverage
- Define the maximum and minimum depth for the echo sounder
- Force a desired depth

#### Parameters – Sector coverage

	Port	Starboard
Max. angle (deg.):	70	70
Max. Coverage (m):	600	600
Angular Coverage mode:	AUTO	
Beam Spacing:	EQDIST	

**Max angle (deg), port/starboard:** These parameters allow you to define the maximum swath width by setting the maximum port and starboard angles. The values are entered in degrees.

**Max coverage (m), port/starboard:** These parameters allow you to define the maximum swath width to each side by selecting values in meters. The port and starboard angles (as defined above) will then be adjusted accordingly by the system. To make use of these settings, you must set **Angular Coverage mode** to Auto.


**Angular Coverage mode:** Choose between Manual and Auto.

- **Manual:** If Angular Coverage is set to manual, the values defined as Max port and starboard angle above (in degrees) are used directly. The Max coverage port and starboard settings (in meters) are not used in this case. Be aware that the outermost beams may be lost if the angular coverage set is larger than the coverage capability at the current depth.
- **Auto:** If Angular Coverage is set to Auto, the maximum coverage (in meters) and the maximum angles will set the swathwidth limit. The most limiting of the two criteria will be used. If the system is not able to fulfil the above, it will reduce the swath width further and as a consequence nearly all the beams will be valid. You may observe this in the **Numerical display**, as the numbers of beams accepted should almost equal to the number of beams available.

**Beam spacing:** Depending on the purpose of the survey, you may define the distribution of the beams on the seafloor.

- **Equidistant:** This setting gives a uniform distribution of soundings on the seafloor, and it is the normal mode for a bathymetric survey.
- **Equiangle:** The beams are distributed with an equal angular spacing based on the angular coverage used. This gives many soundings close to the centre of the survey line, and few on the edge of the swath.
- **In-between:** The in-between spacing is intended for surveys with high priority on seabed image data. Compared to equidistant spacing, this mode gives higher density of soundings in the central part (near equiangle) of the swath, and maintains an acceptable density in the outmost parts (near equidistant).

### Parameters – Depth settings



Depth Settings

Force Depth (m): 0

Min. Depth (m): 1

Max. Depth (m): 300

Ping Mode: AUTO

**Force depth (m):** If there is a lot of acoustic interference or if the water is very aerated, the echo sounder may not find the correct depths. In order to help, you can then enter the approximate depth. This depth may be taken from your navigational charts, or from a navigation sounder elsewhere on the vessel. Forcing the depth will cause the system to set its gain and range windows accordingly, and ignore its own findings about where the bottom is.

**Min./Max. depth (m):** These parameters define the operational depth range. This range should normally be wide enough to cover all depths encountered during the survey, as only depths within this range will be accepted by the system.

A narrow range will help the system in bottom tracking under difficult conditions. In some cases it may be necessary to temporarily narrow the range to assist the system in bottom tracking. However, you must then monitor the actual depth closely, and adjust the depth window as often as required.

#### Note

---

*It is very important that valid depths are entered here when the echo sounder starts “pinging”. If the bottom depth exceeds the limits with more than 10%, the sounder will not lock. It may therefore be useful to enter larger values in the beginning to accept a more dynamic depth, even though this may slow down the initial bottom detection when the system is started.*

---

If the bottom depth exceeds the limits given here it will simply loose track. The true depth should therefore be monitored and compared with the settings during the survey.

- **Minimum depth (m):** Set the minimum limit of the depth range.
- **Maximum depth (m):** Set the maximum limit of the depth range.

**Ping Mode:** This parameter defines the operational mode of the multibeam echo sounder. You can select any of the following settings:

- Auto
- Shallow
- Medium
- Deep

During normal operating conditions, you are advised to set the ping mode to **Auto**. The system will then automatically use the most appropriate mode, and - if necessary - switch between the modes to obtain maximum coverage.

#### Parameters – Stabilization

**Pitch stabilization:** This setting is only available if a Hull Unit is installed. When pitch stabilization is selected (i.e. ON), the transducer array is mechanically stabilized to compensate for the vessel's pitch movement.

At open sea, the swath area on the bottom will move back and forth following the vessel pitch. This would lead to loss of sampling regularity, and thus also limit the vessel speed at which 100% bottom coverage is possible. To account for this effect the Hull Unit may be set to compensate for the pitch in order to stabilize the direction of the emitted vertical transmit fan. This option should thus normally be ON.

## 7.5.2 Sound speed for EM 1002

**Sound Speed** is located on the **Runtime parameters** display view.

The accuracy of the depth data obtained from the system depends on the use of a correct sound speed profile. You must ascertain that the applied profile always corresponds to the real conditions. On the average, errors in the sound speed profile is recommended to be kept below 0.5 m/s.

The screenshot shows the 'Runtime parameters' window with the 'Sound Speed' tab selected. The window has a title bar 'Runtime parameters' and a menu bar 'Runtime parameters'. Below the menu bar is a tabbed interface with tabs: 'Sounder Main', 'Sound Speed', 'Filter and Gains', 'Data Cleaning', 'Javad and Trimble', 'ATH logging', 'Simulator', and 'Survey Information'. The 'Sound Speed' tab is active. It contains three main sections:

- Sound Speed Profile:**
  - 'Use Sound Speed Profile' is checked, and the profile is set to 'default.asvp'.
  - 'Abs. coeff. files, salinity' is set to 'C:\psidata\common\vvp\_abccoeff\default'.
  - 'Abs. coeff. files, CTD' is set to 'C:\psidata\common\vvp\_abccoeff\default'.
- Sound Speed at Transducer:**
  - 'Source' is set to 'PROFILE'.
  - 'Sound Speed (m/sec.):' is set to '1500.0'.
  - 'Sensor Offset (m/sec.):' is set to '0.0'.
  - 'Filter (sec.):' is set to '60'.
- Sea temperature at transducer:**
  - 'Source' is set to 'SALINITY'.
  - 'Salinity (parts per thousand):' is set to '40'.
  - 'Temperature (deg. Celsius):' is set to '12.0'.

### Parameters – Sound speed profile

**Use Sound Speed Profile:** The Sound Speed Profile parameter allows you to select the sound speed profile file to be used in the echo sounder's depth calculations.

If you want to change to a different profile, click the **browse** button on the right-hand side (button with three dots). When the correct profile is selected, press **Use Sound Speed Profile**.

If you manually select a sound velocity profile, or a profile is received for instant use (i.e. S0x datagrams), SIS will check if the number of entry points in the profile satisfies the criteria defined in the Sound speed profile format.

#### Note

*If the profile is too big according to given criteria, a warning will be issued and the profile will not be used.*

*If SIS is running several sounders, the maximum number of allowed entry points is set according to the most restrictive echo sounder in use.*

*If the intended profile is too long, it must be thinned manually before use.*

---

**Absorption coefficient files:** When selecting a new sound speed profile, this will affect the absorption coefficient settings in the system. Each sound speed profile is associated with sets of absorption coefficient files, either based on salinity input or based on CTD input. The files may already exist, or they may be created at the moment new input of salinity or CTD information is given. Salinity is input in the **Filter and Gains** tab in the **Runtime parameters** frame.

New input of CTD based absorption coefficients will normally be given through the S0X datagrams. Input of salinity or CTD will create new directories for the Absorption coefficient files. The paths are shown in the **Sound Speed** tab as

- Abs. coeff. files, salinity
- Abs. coeff. files, CTD

#### Note

---

*A user provided sound velocity profile (with a user defined name) does not normally have a set of associated absorption coefficient files initially. The files will therefore be generated automatically based on the current salinity value. The name of the files will contain salinity as a part of the file name, and this will show up in the salinity text field. In this case the Sound Speed Profile text field will show the original user selection.*

*If a datagram of format S00, S01, S02, S03, S04, S05 or S06 is received this implies that the data should be used immediately. The Absorption coefficient files field are updated automatically. The Use Sound Speed Profile text field will be updated with the name of the new sound velocity profile. In the case of a S00 datagram it will contain salinity as part of the name.*

---

#### Parameters – Sound Speed at Transducer

When the sound speed in the surface area is rapidly changing with time and position, it is recommended to install a sound speed sensor close to the transducer face. This particularly applies to installations with tilted sonar head(s).

If the sound speed value at the transducer derived from the sound speed profile deviates too much from the probe or manual values this will be indicated in the Numerical display (Tr. svp and Tr. sensor).

**Source:** Select the source for the Sound Speed at Transducer. Choose between Manual, Profile and Sensor/Probe.

- **Manual:** The echo sounder system will use the sound speed you define.

#### Caution

---

*The manual setting is intended for experienced operators only!*

---

- **Profile:** The system will use the sound speed profile to derive the sound speed near the transducer/sonar head. If no matching depth is found in the profile, an interpolated value is used.
- **Probe:** The system will use a filtered sound speed value derived from the sound speed sensor at the transducer. The filter is configured as described below. This option will only be available if the sound velocity probe is used.

#### Note

---

*Please note that the sensor must be enabled from the External Sensor setup.*

---

**Sound Speed (m/s):** Set the sound speed at transducer directly to a fixed value. This function is only available if **Manual** is selected.

**Sensor Offset (m/s):** This parameter is used to set a correction offset if Source is set to **Probe**. The offset will be added to the used sound speed values.

#### Note

---

*When a new profile is taken into use, always set the offset so that the sensor value is the same as that in the profile at the transducer depth. This is most easily done using the values from Numerical display.*

---

**Filter(s):** The length of the filtering of the sound speed sensor data can be selected. This also sets the update rate, i.e. how often a new sound speed value derived from the filter is set.

The filter is a median filter. Sound speed values outside 1300 to 1800 m/s and temperature sensor values outside -5°C to +45°C are removed before the filter is run.

### Sea temperature at transducer

The transducer has a coating with a sound speed which differs significantly from water sound speed. As electronic beam-steering is used for all beam angles larger than 50°, outer beam pointing angle accuracy is dependent on the coating sound speed being known to the system. As this sound speed is temperature dependent, the coating temperature must be known to the system. To give the system the coating temperature, a sound speed probe at the transducer depth may be equipped with an additional temperature sensor. The temperature sensor may otherwise be manually set or alternatively be derived from the sound speed if the salinity is known. The latter is recommended in open water where salinity does not vary, otherwise the use of a combined sound speed/temperature probe is recommended.

**Source:** Select the source you want to derive temperatures from.

- **Sensor:** The read-out from the temperature sensor is used.
- **Salinity:** When Source is set to **Salinity**, the salinity value you enter here will be used together with sound speed at transducer to calculate temperature.
- **Manual:** The sea temperature entered will be used.

### Related topics

- *Numerical display* on page 62
- *Filter and gains for EM 1002* on page 250
- *External sensors* on page 295
- *Sound speed profile format* on page 434

- *Implementation of absorption coefficients* on page 401
- *Handling of SSP datagrams* on page 431

### 7.5.3 Filter and gains for EM 1002

**Filter and Gains** is located on the **Runtime parameters** display view.

The screenshot shows the 'Runtime parameters' window with the 'Filter and Gains' tab selected. The window is divided into two main sections: 'Filtering' and 'Absorption Coefficient'. In the 'Filtering' section, 'Spike Filter Strength' is set to 'MEDIUM', 'Range Gate' is set to 'NORMAL', and the 'Slope' checkbox is checked. In the 'Absorption Coefficient' section, 'Source' is set to 'Salinity', 'Salinity (parts per thousand)' is set to '35', '95.0 kHz' is set to '30,000', and 'HiLo Freq. Absorption Ratio' is set to '104'. There is also a 'Normal incidence sector' section with 'Angle from nadir (deg.)' set to '15'.

#### Parameters – Filtering

There is always a small risk of false detections in a multibeam echo sounder. This is due to external factors such as fish shoals, acoustical interference from other systems, passing over vessel wakes, etc. According to bottom conditions, you can apply the included filters to assist the system in discriminating against erroneous measurements. It is recommended to use different filter settings than those recommended only if the occurrence of false detections is higher than expected.

The recommended settings are:

- **Spike Filter Strength:** Medium
- **Range gate:** Normal
- **Slope:** On

The bottom detection is performed in two passes in each ping. Filtering is performed after every pass.

- The first pass is done on all beams individually.
- The second pass is done only on beams which lack valid detection. However, the system then uses relaxed acceptance criteria within range windows derived from neighbouring beams with accepted detection.

It is always beneficial to eliminate erroneous measurements before post processing. In addition, if a false detection in a beam is eliminated in the first pass, a valid detection may be acquired in the second pass.

**Spike Filter Strength:** Choose between *OFF*, *WEAK*, *MEDIUM* and *STRONG*.

This is used to define to what degree a non-smooth bottom is to be accepted. The filter remove beams with depths that deviate too much from a smoothed bottom profile as derived from the detected beams. The stronger filtering, the less deviation is accepted.

If you select OFF, no filtering will take place.

**Range Gate:** Choose between *SMALL*, *NORMAL* and *LARGE*.


When the system detects the bottom, it will perform the search within a predefined depth window, where the depth limits are based on the information from the previous pings. The range gate setting is used to determine the size of this window.

If the depth varies considerably (more than 10%) it may be useful to select a large range gate, but this may also increase the chance for false echoes from side lobes, interference or other noise sources.

Selecting a large range gate may reduce the ping rate slightly when operating in shallow waters.

**Slope:** With this filter enabled, the system checks for bottom slopes that tilt inwards. These slant towards the vessel, and they are removed because the filter requires that the athwartships distance increases for every beam from the centre. Such detections are normally false, and after removal a new bottom detection is performed searching for a value with increased range

The slope filter should normally be enabled.



#### Parameters – Absorption coefficient

The absorption coefficient depends upon depth, water temperature, salinity and frequency. A correct value is important with respect to the validity of the bottom backscatter data measured by the system.

The absorption coefficient as a function of the depth must therefore be calculated for the frequency used by the echo sounder.

**Source:** There are three alternatives;

- **Salinity** – absorption coefficient based on salinity input.

If the source is set to salinity, the average absorption coefficient is calculated using the current sound profile (to find the temperature profile), the depth based on the previous pings and the specified average salinity. The average absorption coefficient will then be calculated by SIS for the relevant frequency and it will be updated and displayed with changing depths. If the salinity in the water is constant, this is the recommended setting.

- **CTD Profile** – absorption coefficient based on profile input.

The absorption coefficient can be calculated from a sound speed profile that includes information necessary to calculate an absorption profile.

The sound speed input datagram (SSP) must be used. When using a CTD profile from an SSP datagram, the absorption coefficient profile will automatically be calculated by SIS for the required frequencies.

It is also possible to specify the absorption coefficient directly in the SSP datagram, but then one datagram must be made for each frequency used by the echo sounders (i.e. the full range of 12, 31.5, 60, 70, 80, 90, 95, 100, 200 and 300 kHz), and the frequency must be specified in each datagram. These datagrams must have the same acquisition date and time and must be sent with no more than 10 seconds interval.

Using this CTD Profile option, which will increase the accuracy of the bottom reflectivity data; SIS will calculate the average absorption coefficient through the water column. The absorption coefficient values displayed will change continuously depending upon the depth.

- **Manual** – manually selected absorption coefficient

It is possible to manually specify the absorption coefficient for the relevant frequency. This must be the average absorption coefficient for the water column.

**Salinity (parts per thousand):** If the source is set to Salinity, the average salinity can be entered in this field.

**<frequency> kHz:** If the source is set to Manual, you may supply an absorption coefficient for the stated frequency. This frequency is as follows for the different echo sounders:

EM 120 / EM 122	12.0 kHz
EM 300 / EM 302	31.5 kHz

EM 1002	95.0 kHz
EM 2000	200.0 kHz
EM 3000	300.0 kHz
EM 3002	300.0 kHz

If the source is set to Salinity or CTD, the frequency field is disabled (greyed), but it will show the current value of the absorption coefficient (dB/km) used for the frequency.

**HiLo Freq. Ratio:** Because the EM 1002 uses two different frequencies (93 and 98 kHz), the absorption coefficient will vary slightly (for example 30 dB/km for 93 kHz, 31.2 dB/km for 98 kHz). The ratio of the HI/LO frequencies is to be set in this field.

#### Parameters – Normal incident sector

**Angle from nadir [deg.]:** This value is used to define the angle at which the bottom backscatter can be assumed not to be affected by the strong increase at normal incidence. The optimum crossover angle will vary with the bottom type.

For seabed imaging, it is important to adjust this angle so that a minimum of angle dependent amplitude variation is seen. This is to give best use of its dynamic range. The bottom backscatter strengths in the ping display are not affected by this setting.

### 7.5.4 Data cleaning

The **Data Cleaning** tab is located under the **Runtime parameters** display view.

The RTDC (Real Time Data Cleaning), uses rules to process the echo sounder data. A rule is a set of parameters that controls the algorithms used in the processing.

Seabed image processing in the Grid Engine may also be set up from the **Data Cleaning** frame

#### Note

---


*The Real Time Data Cleaning module does not delete any depths, but flags depths that are invalid according to the rules. You have full control of this processing at all times.*

---

The data cleaning interface is organized in a basic setup display and an advanced setup display.

#### Selecting predefined data cleaning levels

The basic setup allow you to choose the data cleaning level by a simple selection from a range of predefined levels.




**Slide selector:** Used to select the level of data cleaning simply by using a slider within a range going from **None** to **High**. The range consists of five levels where each level is identified by a rule set predefined by Kongsberg Maritime. The rule sets are named *AUTOMATIC1*, *AUTOMATIC2* up to *AUTOMATIC5*. When a level has been selected the corresponding rule set is sent to the Grid Engine where the RTDC operation is performed.

**Rule set:** A pull down list containing all the predefined rule sets and, in addition, any custom made rule sets defined by the operator using the advanced setup display. See below. When a rule set has been selected it is made active and it is transferred to the RTDC module.

**Advanced....:** When this button is pressed the basic setup is replaced with an advanced setup allowing you to define new rule sets and modify or delete existing rule sets.

## Advanced data cleaning



The RTDC (Real Time Data Cleaning) module processes the data in real time using two different kinds of processing, ping based and grid based processing. Ping based processing uses a buffer of the last pings to process current ping, also known as line-based processing. Grid based processing uses all points from all lines, current and all previous, to process the data in one grid cell. Various parameters are set to control these processing types.

---

**Note**

*The real time data cleaning uses additional parameters which are not available to the user.*

---

The advanced setup is organized with four different groups of rule parameters (ping processing, DTM processing, grid processing and seabed image processing) and one group for rule set administration/handling.

**Rule set:** A pull down list containing all rule sets, both predefined by Kongsberg Maritime (i.e. the rule sets within the 'None' to 'High' range) and custom made rule sets as defined by the operator. The parameter values for the selected rule set are shown in the parameter fields. I.e. by selecting a rule set, it's parameter values may be inspected or changed. Note however that the rule set is not automatically made active. Use the **Apply** or **OK** buttons to activate the parameter settings.

**Delete:** Delete the current rule set.

---

**Note**

*Predefined rule sets (i.e. the rule sets within the "None" to "High" range defined by Kongsberg Maritime) or the current active rule set, can not be deleted. A warning is issued on an attempt to delete such a rule set.*

---

**Save as:** When pressed a new rule set is created based on current rule set and parameter values. A rule set name must be given in the text field. The new rule set is made active by pressing **Apply** or **OK** and transferred to the RTDC module.

---

**Note**

*The names of the predefined rule sets are not legal names for saving. A warning is issued on an attempt to use such a name.*

---

**OK:** When pressed current settings will be saved to current rule set and the Advanced setup will be closed.

**Note**

*Pre-defined rule sets can not be changed. **Save As** must be use to make changes.*

**Apply:** When pressed current settings will be saved to current rule set.


**Note**

*Predefined rule sets can not be changed. **Save As** must be use to make changes.*

**Cancel:** When pressed the advanced setup is closed without any changes. If **Apply** was pressed any changes since will not take effect.


### Ping processing rules

Ping-based processing, flags wrong depths as early as possible in the processing chain. Ping processing is performed right after the depths arrive into the RTDC module. The **Time** rule and the **Overhang** rule use the current ping only.



- **Time rule:** This rule flags out beams where the time range is bigger than the time difference between two pings. This is illustrated in the figure below.


*Figure 16 Time rule*



If the rightmost beam has a travel time longer than the time difference between the current (n+1) ping and the previous, that beam is flagged out.

- **Overhang rule:** This rule flags beams that create an overhang situation, illustrated in the figure below.

*Figure 17 Overhang rule*



It is not unambiguously determined which beams to flag to remove the overhang. E.g. in the figure, it is possible to flag either the dotted beam or the beam to the left of the dotted beam. The strategy in SIS is to consider the alternatives that imply flagging the fewest beams, and to keep the points that most likely define the seabed by minimizing the distances between the depths in the ping. If necessary, more than one beam is flagged to remove the overhang.

### DTM processing rules

When the gridding starts, the operator has already defined the minimum grid cell size for the processing grid. However, the RTDC module checks if it needs to redefine this grid. It can do so by collapsing several grid cells into larger grid cells called **Cell Processing Units**. How many cells to process together is dependent on the median depth of the cells and the parameter Split factor.

DTM processing rules	
Min. no. points	8
Split factor	0.200
Remove cells	<input type="checkbox"/>
Surface fitting	
Polynomial order	1
Tukey constant	6.000
Max. iterations	10
Conv. criterion	0.010

The DTM and grid processing rules are applied to all depths in each grid cell. A grid cell defines an area, and all depths in this area are processed together regardless of the survey line they belong to. Every time a new depth is added to the grid cell, all depths (old and new) in the grid cell are reprocessed. Previous flagged out depths may be set to valid and vice versa during this process.

- **Min. no. points:** The parameter Min. no. points defines number of points in a grid cell. If a cell has fewer than this number of depths, all depths will be flagged out if the check button **Remove cells** is enabled.
- **Split factor:** Defines how many cells to process together. The value depends on the median depth of the cells.
- **Remove cells:** The parameter Min. no. points defines minimum points in a grid cell. If a cell has fewer points than the minimum number defined, all depths will be flagged out if this check button is enabled.
- **Surface fitting:** Sets parameters for a best fit plane. These parameters are discussed in detail in *Real time data cleaning* on page 389.
  - **Polynomial order:** This parameter controls the shape of the surface. This parameter is normally set to 1. Setting the polynomial order to 2 may give a better surface, but requires significantly more processing power. 3 may be used in very difficult terrain.
  - **Tukey constant:** This parameter controls the weight each point is given. Increasing this value means that more points will be considered into the solution, but the process will be slower.
  - **Max. iterations:** This parameter controls how many times the Tukey algorithm will try to find a solution. 1 means that there will be only one pass. After 3 passes the surface is normally well defined. The search for a solution will stop when the algorithm has tried Max. iterations times.
  - **Conv. criterion:** This parameter will stop the Tukey algorithm when the change in the results from the current and the previous run is very small. Only points with weight are considered, so the Tukey constant will have an influence on this.

## Grid processing rules

Grid processing rules

☐ Residue depth rule  
Factor: 0.050

☐ Residue vertical error rule  
Factor: 1.000

☐ Residue avg. vertical error rule  
Factor: 1.000

☐ Residue std. rule  
Factor: 2.000


☐ Grazing angle rule  
Min. angle: 20.000

When the surface fitting for each Cell Processing Unit has been performed, points can be flagged out based on the following rules:

- **Residue depth rule:** Each depth in the Cell Processing Unit is multiplied with a Factor. The result is a limit, and if the residue is larger than this limit, the point is flagged out. This rule will adapt to changing depths, the factor is recommended set approximately to the accuracy of the echo sounder.
- **Residue vertical error rule:** Each depth has a vertical error estimate. This error estimate is multiplied with Factor and the result is a limit. If the residue is larger than this limit, the point is flagged out. This rule is also adaptive because the vertical error will change with the range and beam pointing angle.
- **Residue vertical avg. error rule:** In each cell the average vertical error is calculated, and the average vertical error for the Cell Processing Unit is then calculated. Further, a limit is calculated from the average vertical error in the Cell Processing Unit multiplied with Factor. If the residue is larger than this limit, the point is flagged out. Note that it is the average vertical error for the Cell Processing Unit that is used, not the cell's value.
- **Residue std. rule:** The standard deviation of the residue is also calculated. This is the standard deviation in the Cell Processing Unit, not the cell. A limit is set by multiplying Factor to this standard deviation. Residue larger than the limit are flagged out.
- **Grazing angle rule:** For each depth the angle between the beam and the bottom surface is calculated. Then the parameter **Min. angle** can be set to flag out all depths where the angle is less than this limit.

## Seabed Image processing

When **Seabed Image Processing in GridEngine** is selected the seabed image data is also sent to the GridEngine and a seabed image mosaic is created.



## Parameters – Seabed Image Processing

- **Grid size factor** is used to set the size of the sonar grid cells relative to the processing grid cells. E.g. if **Grid size factor** is set to 4, there will be 4 sonar grids for each processing grid.
- **Merger type** determines what action to be taken when more than one line fills a cell:
  - **Average** will calculate the average sidescan values for all passings over a cell
  - **Last Wins** will use last value only
- **Interpolator type:** Sometimes data is missing in an area. This can be filled with data from the surroundings using an interpolator. The interpolator type used is **Top Hat**.
- **Interpolator radius** determines the distance from an empty point in terms of number of cells that will be used in the interpolation. The less distance, the less interpolation will be done.
- **Fill in only** determines the interpolation to be carried out. If enabled, empty points only will be filled. If not enabled, the entire dataset will be smoothed.

## Related operational procedures

- *How to display seabed imagery data in the Geographical view* on page 138


## More information

- *Real time data cleaning* on page 389

### 7.5.5 Javad and Trimble

**Javad and Trimble** are located on the **Runtime parameters** display frame.

The **Javad and Trimble** settings are used to configure GPS raw data logging when GPS receiver is either of type Javad or Trimble.



#### Parameters - Javad and Trimble setup

- **Use logged files directory:** This parameter allow you to select where to store Javad or Trimble GPS raw data. To specify the directory, use the browse button [...] to find or make the relevant directory. When the directory has been specified the logging area must be confirmed by pressing the **Use logged files directory** button again. The text field will change from yellow to normal background colour when applied.

#### Note

---

*Note that the Javad/Trimble directory initially has a default setting. It is initially shown in the text field and it is also entered when the browse button is pressed.*

---

- **Logging on:** This tick button is used to turn Javad or Trimble logging on or off. Logging is on when ticked.
- **Height on:** This tick button is used to turn fixed height on or off. Fixed height is on when ticked.

#### Note

---

*The Use logged files directory operation also transmits the **Logging on** status to Javad/Trimble. In the same way the **Logging on** operation transmits the directory information. The **Height on** works independently of the other two operations.*

---


#### More information

- *Javad and Trimble details* on page 419

### 7.5.6 ATH Logging

**ATH (Applanix True Heave) Logging** is located on the **Runtime parameters** display frame

The **ATH Logging** settings are used to configure raw data logging from the Applanix POSMV True Heave system.




---

#### Note

*ATH logging requires very accurate timing in the PU and it is recommended used only if ZDA clock and 1PPS is interface.*

*The SIS ATH process is designed to log the POSMV output on port 5602. A network connection between the POSMV and SIS must therefore be established. Please use the second network card in the HWS for this purpose, not the one connecting the HWS and the PU.*

---

### Parameters – ATH logging setup

- **Start Applanix POSMV TrueHeave logging:** This parameter is used to enable or disable the ATH logging. Logging is enabled when the box is ticked. Note that the **Apply** button must be pressed in order to activate the selection.
- **Path field and browse button:** This parameter is used to select where to store the logged ATH data. To specify the directory, use the browse button [...] to find or make the relevant directory. Note that the directory text field can not be edited manually. To activate the directory selection the **Apply** button must be pressed. A default directory is set initially.
- **Interval for new line (min.):** This parameter sets the size of each logged file in terms of duration. The legal range is 1-3600 minutes. Note that the **Apply** button must be pressed in order to activate the selection.
- **Apply and Cancel buttons:** Apply is used to confirm and activate the set parameters. Cancel is used to reset any changes before Apply is pressed.

---

## Note

*When one or more parameters are changed the background colour of the changed element(s) will turn yellow. When the change has been activated, by pressing the **Apply** button, the default background colour is returned.*

*The ATH logging process will store data continuously. Because true heave is delayed, please wait three minutes after the last survey line before SIS is shut down. Also remember to turn off ATH logging if no survey lines are logged.*

---

The naming format of the logged files stored by the ATH logging process is as follows:

ATH\_YYYY\_MM\_DD\_SSSSSS\_.ath

Where

- YYYY\_ = Year (four digits)
- MM\_ = Month (two digits)
- DD\_ = Day (two digits)
- SSSSSS\_ = Seconds since start of week (six digits)

e.g.: ATH\_20060915\_123456.ath

## 7.5.7 Simulator for EM 1002

**Simulator** is located under the **Runtime parameters** frame.

### Parameters – Simulator setup

**Enable Simulation:** Select this parameter to enable simulation mode in the echo sounder.

**Simulator min. depth (m):** Set the minimum depth for simulation.

**Simulator max. depth (m):** Set the maximum depth for simulation.

## Note

*The simulation generates range samples only. All other inputs to the PU (Processing Rack in the Transceiver Unit) must be supplied via the normal PU input ports. Most important is the position data and roll, pitch and heave (i.e. attitude data).*

**Step along (%):** The change in depth between each ping given in percent. The depth will vary within the set min/max range.

**Slant across (deg.):** The tilt of the sea bottom across track in degrees.

Figure 18 Step along





Figure 19 Slant across




## Parameters – Beam no. for Scope Display

**Beam no.:** Set beam number to be displayed in the **Scope Display**. Set beam number to zero (0) if you want to turn off this feature.

**Stave no.:** Set the stave number to be displayed in the **Stave Display**. Set stave number to zero (0) if you want to turn off this feature.

### 7.5.8 Survey Information

**Survey Information** is located under the **Runtime parameters** frame. The **Survey Information** tab displays survey parameters for the active survey. The information is automatically selected.



The screenshot shows a dialog box titled "Survey Information". It contains several input fields and a text area. The fields are: "Time created" with the value "2008-9-30 13:41:20", "User" with "SIS user", "Grid cell size [m]" with "1.60", "Number of cells:" with "64", "Projection" with "UTM32N\_WGS84", and "From template" with "Default". The "Survey Comment" field is a text area containing the text: "Automatic created survey", "Date: 20080930, time: 134120", "Projection: UTM32N\_WGS84", and "Number of cells: 64".

Field	Value
Time created	2008-9-30 13:41:20
User	SIS user
Grid cell size [m]	1.60
Number of cells:	64
Projection	UTM32N_WGS84
From template	Default
Survey Comment	Automatic created survey Date: 20080930, time: 134120 Projection: UTM32N_WGS84 Number of cells: 64

#### Note

---

*The Survey Information for GPS do not show the Grid cell size and Number of cells:*

---

For more information about **Survey parameters** see .


#### Parameter references

- *Survey parameters* on page 216

## 7.6 SIS parameters – Set parameters

This section contains a description of the dialog boxes and parameter settings that are used to control the behaviour of SIS.

These parameters are all found from the main menu by selecting **Tools→Custom...→Set Parameters**.



Select a topic on the branch in the tree to the left, and the window to the right will expand.

Select this topic	To
Ship	Define the appearance of the ship in the Geographical view
Error model parameters	Define estimated errors in the observations
Advanced display options	Change display options – for internal and/or advanced use only
APOS	Relay position computed by APOS software to SIS
Positions	Define masks for position computation
Turn parameters	Control how to generate turns between planned lines
Passwords	Set passwords to use in SIS
Display	Define automatic screen dumps, automatic start of echo sounder and various display parameters
Logging	Define logging parameters. Select grid engine (GridEngine/CUBE)
Autopilot	Set autopilot parameters
Sound speed	Set sound speed masks
Network licence	Identify your license server

## 7.6.1 Ship parameters

Parameter	Value	Type
Fill (1) or do not fill (0) the ship symbol	0	Integer
Position marker line width in pixels	3	Integer
Position marker spear length in cm (on screen)	1.6	Float
Position marker body length in cm (on screen)	0.4	Float
Minimum length of ship hull in cm (on screen)	0.5	Float
Distance from reference point to the keel of the ship in cm	300	Integer
Distance from reference point to the deck of the ship in cm	200	Integer
Length of the bow spear in cm	850	Integer
Distance from reference point to starboard side of ship in cm	500	Integer
Distance from reference point to port side of ship in cm	500	Integer
Distance from reference point to stern of ship in cm	2000	Integer
Distance from reference point to bow of ship in cm	2000	Integer

Note: Close and reopen the geographical view to effectuate.

OK Exit Help

It is recommended to set the appearance of the ship to visualize the actual size of your ship. When the display is zoomed out beyond a set limit, the ship will appear as a position marker, i.e. a triangle, with a spear. The following ship parameters can be set:

- Fill
- Line width in pixels
- Position marker spear length – the length of the spear, in cm on the screen, when the ship is displayed as a position marker
- Position marker body length – the size of the position marker (triangle base and length) when the ship is displayed as a position marker
- Minimum length of ship hull – the scaled size of the ship, in cm on the screen, where the position marker will take over at further zooming
- Distance from reference point to the keel, to the deck, to starboard, to port, to stern and to bow – the actual size that defines your ship. Input the values in cm. E.g. if the distance from the reference point to the stern is 40 meters, 4000 centimetres must be entered.
- Length of the bow spear – the bow spear is a imaginary line in front of the ship to assist in steering it straight.

Note

*The geographical view needs to be closed and reopened to effectuate any changes.*

Note

*The ship size will be scaled according to actual scale in the geographical view. The position marker size will remain unchanged.*


Note

*When a projection with scale factor is applied, e.g. UTM projection, the ship size will be scaled accordingly.*

Note

*Enter the values of the parameters according to the type shown for each field, i.e. integer number, float number or text.*

7.6.2 Error model parameters




Enter the error estimates for the attitude sensor, SVP and tide. The error estimate values refers to the Total Propagation Error described in *Real time data cleaning* on page 389. The values are specific to the sensor types and must be set according to the system specifications. These parameters are used in calculating the error estimate for the depth values.

Note

*Parameters will be updated when a new survey is started.*

### 7.6.3 Advanced display options



#### Note


*These parameters are for Kongsberg Maritime internal use and for advanced users only. Erroneous parameter values may cause memory overload situations in SIS.*

- Threshold for updating the reference point in cm. This parameter is for test/debug purposes.
- Maximum northward auto region size in cells. Sets the maximum size of the grid in the northward direction in number of cells.
- Maximum eastward auto region size in cells. Sets the maximum size of the grid in the eastward direction in number of cells.
- Maximum northward fixed region size in cm. When “Enable auto size grid region” is not enabled, this parameter sets the maximum size of the grid in the northward direction in cm.
- Maximum eastward fixed region size in cm. When “Enable auto size grid region” is not enabled, this parameter sets the maximum size of the grid in the eastward direction in cm.
- Enable grid region follow ship. Determines where the restricted region is displayed in the view. When disabled, the restricted region is displayed in the centre of the view.
- Enable Auto size grid region. Enables the grid region auto size function. Should always be enabled.
- Enable grid region restriction. Enables the grid region restriction. Should normally be enabled.

#### Note

*The geographical view needs to be closed and reopened to effectuate any changes.*

## 7.6.4 APOS



APOS is a Kongsberg Maritime acoustic positioning operating station - a computer with a Windows based operating software. Position computed by APOS based on reference to a fixed transponder on the seabed can be relayed to SIS and be used as position reference for the echo sounder. To enable the use of APOS positions, the following procedure must be used (Windows platform only)

- 1 Run **findDDSPort** from a command prompt window to find the UDP port where the APOS positions are sent to  
Use that port and the SIS PC's IP address when configuring APOS
- 2 Enter the Transponder ID in the text field as shown in the figure above
- 3 Open the **Installation parameter** frame for the desired echo sounder and under "Input Setup – Port Settings" enable GGA on UDP2. On "Sensor Setup", select UDP2 as the active position system
- 4 Enable GGA on UDP2 from **Input setup**→**Port settings**
- 5 Select **UDP2** as active position system from **Sensor setup**


Note

---

*SIS needs to be restarted to effectuate any changes.*

---

## 7.6.5 Positions



The following masks related to position input can be set:

- Max age for ROV depth datagram (sec.). Time before a missing ROV depth input datagram to the echo sounder (PU) is flagged in the numerical display. Must never be set to 0.
- Dead reckoning on or off. (off=0, on=1). If position input stops the dead reckoning feature will calculate predicted positions for a preset time interval before stopping. The predicted positions are based on the two last positions received and the (still) incoming heading, if available. If not, the last heading will be used
- Position jump filter on or off. (off=0, on=1). This filter is used to remove single spikes in the position input. If a position spike occur this position is disregarded and a predicted position used instead. This predicted position is based on the two previous (legal) positions and the heading.
- Time difference too big (sec): If the time difference between the timestamp and the time in the clock datagram is bigger than this value, an error is generated.
- Change in time difference too big (millisec): There is always a time difference between the timestamp and the time in the clock datagram. However, this time difference is expected to be almost constant. If there is a sudden change in the difference, an error is generated.
- Position quality too low (error) (cm): Lowest acceptable limit for the computed position quality (see position datagram output in the corresponding echo sounder manual).
- Position quality too low (warning) (cm): Warning limit for the position quality.

- Too few satellites: Lowest number of satellites before an error is generated.
- Few satellites: Lowest number of satellites before a warning is generated.
- Error position jump (m/s): Highest possible speed of the ship. This is used to generate error messages for position jumps.
- Suspicious position jump (m/s): Warning message is generated when position jump exceeds this limit.


Note

---

*SIS needs to be restarted to effectuate any changes.*

---

## 7.6.6 Turn parameters



These parameters are used to control how generate turns from one planned line to the next in the SIS planning module

- Lead in: Extend each planned line to allow the ship to stabilize before entering the survey line.
- Turn radius: The minimum turn radius in meters that the ship can do.

Note

---

*SIS needs to be restarted to effectuate any changes.*

---

## 7.6.7 Password

The screenshot shows the 'Set parameters in SIS' dialog box with the 'Passwords' section selected in the left-hand tree. The right-hand pane contains the following parameters:

Parameter	Value	Type
Password for installation menu, valid as long as the frame is shown	simradN	Text
Password for installation menu, valid once	simrad0	Text
If 1, Installation menu is password protected	0	Integer

Below the parameters, a note states: "Note: Please restart SIS to effectuate." At the bottom of the dialog are buttons for 'OK', 'Exit', and 'Help'.

The **installation parameters** may be password protected. These parameters control the use of passwords in SIS.

- Password for installation menu, valid as long as the frame is shown
- Password for installation menu, valid once
- If 1: Installation menu is password protected: Set this parameter to 1 to enable the use of passwords, 0 to disable

**Note**

*SIS needs to be restarted to effectuate any changes.*

## 7.6.8 Display

The screenshot shows the 'Set parameters in SIS' dialog box with the 'Display' section selected in the left-hand tree. The right-hand pane contains the following parameters:

Parameter	Value	Type
Automatic start of echo sounders (0=off, 1=on)	0	Integer
Helmsman Survey folder. Empty if same as SIS		Text
Turn off gridding, (1= OFF) (Active at new line)	0	Integer
Auto Screen dump interval (sec.)	0	Integer
Auto Screen dump file (full path)		Text
1 = Use Geodesy library for heading and distance, 0 = Use internal math.	1	Integer
Max number of pings in realtime depths tail	250	Integer
Default Font Size in the Helmsman Display	30	Integer
Minimum size of grid cell on screen (0.1 - 1.0 mm)	1.0	Float

Below the parameters, a note states: "Note: Please restart SIS to effectuate." At the bottom of the dialog are buttons for 'OK', 'Exit', and 'Help'.

The **Display** parameters can be set as follows

- Automatic start of echo sounders (0=off, 1=on). When enabled SIS will automatically start the echo sounder if no changes since last run is detected.
- Helmsman Survey folder. Empty if same as SIS.

If the Remote Helmsman run on a separate computer, the survey folder on the SIS computer where the shiptrack and coverage files are stored, has to be shared and mapped on the remote PC. If the folder is mapped to a different drive letter on the Helm PC, the folder has to be set. The format of the folder name has to be "Drive Letter":\sisdata\grids or the complete folder name in front of the survey name. If the folder is g:\sisdata\grids on the SIS PC and accessible as h:\sisdata\grids on the Helm PC, you must enter h:\sisdata\grids.

- Turn off gridding – it is possible to turn gridding off when logging data.
- Auto screen dump interval (in seconds) defines how often a screen dump of the SIS GUI is performed
- Full path and name of screen dump. File default extension is .gif. The file is updated with the interval defined above. The file is readable by e.g. a WEB application for periodic display
- Geodesy library or internal math. Calculate distances on the ellipsoid (geodesy) or on the plane (pythagoras).
- Max number of pings in realtime depth. The length of the realtime depth tail behind the ship in the geographical view.
- Default Font Size in the Helmsman Display. Control the font size in the Helmsman Display, both the display in SIS and the display in the Remote Helmsman application.
- Minimum size of grid cell on screen defines how small a grid cell can be presented when zooming. When zooming exceeds this limit neighbouring grid cells will be merged.

Note

---

*SIS needs to be restarted to effectuate any changes.*

---

## 7.6.9 Logging

The screenshot shows the 'Set parameters in SIS' dialog box with the 'Logging' tab selected. The parameters are as follows:

Parameter	Value	Type
Log error estimate to file. (0=off, 1=basic format, 2=ext. format)	0	Integer
SVP change should generate new logged line. Yes = 1, No = 0	0	Integer
Water column disk. (Default: Raw data disk.)		Text
Eiva compatible start/stop datagram = 1. SIS default = 0	0	Integer
Enable(1) or disable(0) support for rawdata logger.	0	Integer
Hotkey for Ping on/off	F10	Text
Hotkey for New line	F5	Text
Hotkey for logging on/off	F2	Text
Save all depths in grid if set to 1, save selected depths if set to 0	0	Integer
Indicate if SeaBec is in use (1=on, 0=off)	0	Integer
Gives current data cleaning method, 1-GridEngine, 2-CUBE	1	Integer
Interval for line counter in sec.	1800	Integer

Note: Please restart SIS to effectuate.

Buttons: OK, Exit, Help

The following **logging** parameters can be set:

- Log error estimate to file (0=off, 1=basic format, 2=ext.format)

This option is only available when importing raw data into SIS. There are two possible formats:

- basic format: the simple format which outputs: Beam number, horizontal error and vertical error.
- extended format: a more complete format which outputs: Beam number, latitude[degrees], longitude[degrees], north[cm], east[cm], depth, horizontal error[cm] and vertical error[cm]

At the top of the file, a header is written, explaining the format of the file: The TPE files are placed on the same disk as the grids in the folder sisdata/surveyName/sf and are named lineNumber\_date\_time.tpe (0010\_20060907\_130302.tpe

- SVP change should generate new logged line. Yes=1, No=0

Automatic creation of new logged line when a new SVP is activated. A new sound velocity profile is activated either when the user manually select it from **Runtime Parameter**→**Sound Speed** or when an SSP datagram for immediate use (S00 - S06) is received by SIS.

- Water column disk. (Default: raw data disk)

It is possible to log the separate water column files to a separate disk instead of using the same location as for the raw data (‘.all’) files. This will prevent fragmentation of both the raw data files as well as the water column files.

- Eiva compatible start/stop datagram = 1. SIS default = 0.

Eiva is a third party Remote Helmsman that requires a different start/stop identification than SIS Remote Helmsman uses.

- Enable/Disable support for raw data logger in PU.

Raw data logging can be performed by the PU itself to a local hard disk in parallel with the logging operation in SIS.

- Selection of hotkeys for pinging/logging/new-line.
- Indicate if SeaBec is in use (1=on, 0=off): Normally set this to 0. This can be used to turn on Single Beam Seafloor classification if a license is found
- Gives current data cleaning method, 1=GridEngine, 2=CUBE: This parameter controls if SIS shall use GridEngine or CUBE to generate terrain models.
- Interval for line counter in sec.: Control when new survey lines are automatically generated.

#### Note

---

*SIS needs to be restarted to effectuate any changes.*

---


## Related operational procedures

- *How to log water column data* on page 142
- *How to enter survey parameters* on page 102

## Related topics

- *Hotkeys* on page 43

## 7.6.10 Autopilot



The following **Autopilot** parameters can be set:


- NMEA version to use determined by readability in the autopilot system
- Heading M or T defines whether
- XTE factor: the XTE value in the NMEA APB datagram is multiplied with this factor. This can cause the autopilot to react more quickly, but it can make the ship oscillate along the line. This factor must be used with care.

Note \_\_\_\_\_

*SIS needs to be restarted to effectuate any changes.*

---

## 7.6.11 Sound speed



The following **sound speed** parameters can be set:

- Micro SV format (1) or Smart Probe format (0) defines what format the probe uses


- Enable/disable automatic start of Sound Speed Editor
- Too big difference between sound speed at transducer from profile and probe – limit for error generation
- Big difference between sound speed at transducer from profile and probe – limit for generation of warning

Note \_\_\_\_\_

*SIS needs to be restarted to effectuate any changes.*

---

## 7.6.12 Network licence



The following **network licence** parameters can be set:

- Port number of licence server
- IP-address of licence server

Note \_\_\_\_\_

*SIS needs to be restarted to effectuate any changes.*

---

## 7.7 File menu parameters

The **File** menu gives you the following choices:


- *Import/Export* on page 278
- *Export xyz file* on page 286
- *Remove survey* on page 287
- *Save settings* on page 287
- *Save settings as...* on page 287
- *Delete settings* on page 288
- *Set startup settings* on page 288
- *Export PU parameters* on page 289
- *Import PU parameters* on page 290
- *Export user settings...* on page 291
- *Import user settings...* on page 292
- *Create CUBE grid* on page 292
- *Quit* on page 293

### Related operational procedures

- *How to enter survey parameters* on page 102
- *How to export survey results after a survey* on page 167
- *How to exit the SIS software* on page 168
- *How to shut down the operator station* on page 168
- *How to shut down the Processor Unit (PU) or the Transceiver Unit* on page 168

### 7.7.1 Import/Export

The **Import/Export** dialogue is accessed from the **File** drop-down menu.



The following options are available in the Import/Export dialogue:

- **Data types:** The following data types can be imported:
  - 3D Models: The user can import AutoCAD (\*.dxf), Inventor (\*.iv) or VRML (\*.wrl)
  - Surveys: The user can import either raw data files or already gridded data

**Note**

*It is possible to reprocess data based on user defined rules if importing raw data files.*

- KSGPL: The user can import background KSGPL files (\*.bgksgpl)
  - Background Images: Imports background images
- **Import:** Press this button to import data/gridded survey
- **Raw Data Files:** Import raw data files
- **Background grid from file:** Create a background grid
- **Export Selected:** Press this button to export data (more details below)

- **Remove Selected:** Loaded or set to be loaded data can be unloaded by selecting the listed data items to the right and clicking this button

Note \_\_\_\_\_

*No files will be deleted on disk even if e.g. a survey has been reprocessed.*

*KSGPL background data can not be unloaded*

---

- **Undo All:** Undo actions

Note \_\_\_\_\_

*No files will be deleted on disk even if e.g. a survey has been reprocessed*

---

- **Delete Processing Data:** A gridded survey consist of many different file types. One of these types is called **Processing Files**. These files are used internally when creating a new grid or adding to an existing one. The files may use a lot of memory and hard disk space, but are generally not needed if the survey is closed and used for visualisation only. Thus, the Processing Data can be deleted. This is done by selecting the loaded surveys to be handled and pressing the **Delete Processing Data** button.
- Press **OK** to apply
- Press **Cancel** to abort

### Data types

Depending on your selected **data type** pressing the **Import** button will launch the different import dialogue boxes:

- **3D Models:** Browse for the wanted 3D model file(s). Please wait some time to allow the 3D model to be processed. This may take a while depending on the size of the file. The imported 3D model(s) will be listed to the right if successfully processed/loaded.
- **Surveys (already gridded):** Browse for the directory where the already gridded survey is located.

Note \_\_\_\_\_

*The grid may fail to be loaded if the GridEngine is not running or if a valid license is not present.*

---

- **KSGPL:** Browse for a KSGPL background file.

- **Background Images:** Background images can be imported by selecting **Background Images** and pressing the **Import** button. This will launch a dialog box where you can import a **GeoTIFF** file. This is an ordinary TIFF image file with the geo-reference information in the TIFF file header, which also will be shown on the screen.
- **GeoTIFF Support:** Support for GeoTIFF files is summarized in the table below. ESRI world are not supported. Max file size is limited by available memory.

TIFF Tag Name	Support Values
PhotometricInterpretation	Grayscale, RGB, and Palette
Samples PerPixel	1, 2, 3 and 4
BitsPerSample	8
PlanarConfig	Chunky format (contiguous)
Compression	Uncompressed and LZW

#### Note

*A background image can only be imported when a survey is loaded.*

*The Delete Processing Data and the Background Images will only be enabled if at least one of the given surveys is linked to Processing Data.*

- Press **OK** to apply
- Press **Cancel** to abort

### Raw Data files

Raw data files can be reprocessed/gridded with different settings.

**Raw Data Files**

Import Raw Data Files

Survey Name:

Existing Surveys:

Select survey-template:

Comment:

Raw data path:

Tide File:


Geoid File:

Grid Folder:


User:

Projection:

- Import Raw Data Files field
  - **Survey name:** Give a name of the survey to be gridded.
  - **Existing Surveys:** Import raw data into a selectable existing survey. GridEngine parameters, projection, grid folder and user will be given by the existing survey and your raw data will be imported as defined by this.
  - **Select survey-template:** Select predefined selection of frames to open
  - **Comment:** Write your own comment for the survey in the text field.
  - **Raw data path:** Browse for the directory containing your raw data files to be processed. The files contained in this directory will be listed in the list box below. From this list raw data files can also be added one by one by pressing the **Add raw data files** button.




File	Size	Date
0_20070823_080517_simrad_echo.all	209418670	20070823 08:05:17
1_20070823_084340_simrad_echo.all	132801210	20070823 08:43:40
2_20070823_090334_simrad_echo.all	87129014	20070823 09:03:34
3_20070823_092135_simrad_echo.all	178632078	20070823 09:21:35
4_20070823_095135_simrad_echo.all	153245244	20070823 09:51:35
5_20070823_102135_simrad_echo.all	179939630	20070823 10:21:35
6_20070823_105135_simrad_echo.all	103307956	20070823 10:51:35
7_20070823_112351_simrad_echo.all	21530398	20070823 11:23:51
8_20070823_113022_simrad_echo.all	57965816	20070823 11:30:22

Add raw data files: 

- **Tide File:** Browse for tide file to be used, if any.
- **Geoid File:** Browse for geoid file to be used, if any.
- **Grid Folder:** Select where to store the survey files when imported and gridded.
- **User:** Select a user from the combo box. To add new user(s) select **User handling** in the **Survey administration** frame.
- **Projection:** Select a projection from the drop-down combo box. If a projection already has been set in the **New survey** frame, this field is greyed out.

- GridEngine Parameters field



- **Depth variable:** Which depth value to be processed
  - **Number of cells:** Number of cells in one sub grid used by the GridEngine. The numbers of cells must be a power of 2 and between 16 and 512
  - **Cell size (cm):** Size of each cell in the lowest (the most detailed) level of detail. Min = 10 cm, max = 15,000 cm.
  - **Processing parameters:** By pressing this button you will be forwarded to the **Real Time Data Cleaning** menu.
- Press **OK** to apply
  - Press **Cancel** to abort

**KSGPL:** Browse for the wanted KSGPL background file.


Note

---

*One KSGPL file may override any other currently loaded KSGPL data.*

*KSGPL background data can not be unloaded*

---



### Background grid from file

Data generated from **File→Export xyz** or generated from **File→Import/Export→Export selected** can be used to create a background grid. Activating the **Background grid form file** menu, brings up a file selection box where you can choose a file with the extension **DAF.xyz**. A survey will be created from the file, using the projection and grid parameters from the current survey. When created, this survey will appear in the survey list, and later be loaded using the **Import** button. The name of the survey is created from the filename.

#### Note

---

*The data in LoD 0 may appear sparse because of the resolution in the dataset. Normally LoD 1 displays the grid without “holes”.*

---

### Export of the selected data files

- 1 Select **File→Import/Export**
- 2 Select the survey data you want to export
- 3 Press the **Export...** button to launch the **Export Survey** dialogue box

**Survey name:** Name of the survey to be exported.

**Raw Data Location:** This selection applies to export of a Neptune Rule file only. Browse for the disk location where the raw data files (.all files) are stored for the survey you want to export.

**Output Type field:** Select output file format to export the data to. The options are:

- **Little Endian:** Binary PC format file.
- **Big Endian:** Binary Unix format file.
- **ASCII:** Format details are written into the file itself.
- **Neptune Rule:** Create a rule file to be imported into Neptune post-processing. This setting overrides the **Point Set** and **Variable settings** described below.
- **DAF Geo. coord:** Creates a ASCII file with geographical coordinates in DAF format.
- **DAF Contours:** Creates at an ASCII file with contour lines in DAF format.
- **Background XYZ:** Creates an ASCII XYZ-file which can be used to create background grids.

**Note**

*When exporting DAF formats the only available Point Set choices are Min, Max or Median.*

**Point Set field:** Select whether you want **all**, **valid** or **invalid** points is to be exported.

**Variable field:** Select the Depth type to export. See the **Depth settings** in the **Geographical window** and the **Geoid** chapter.

Press **OK** to apply.

Press **Cancel** to abort.

### DAF Export

When exporting either of the DAF formats, three additional Point Set variables are enabled. Select one of these to create the file. Level of Details (LoD) may also be set.

When selecting DAF Contours, you must select how to create the contours. Select from the **Depth List** or edit or create a new set.

For instance, you may choose to create contours at 1, 5, 10 and 15 meters, every 2 meters, every 5 meters and so on. The predefined sets can be altered or new ones can be added by editing the right-most **Depth List** field and pressing **New** or **Save**. Pressing **Delete** removes the selected set.

DAF contours can be displayed in Neptune and other applications that supports the DAF format.

### Related operational procedures

- *How to enter survey parameters* on page 102
- *How to import a Neptune grid to SIS* on page 135
- *How to export survey results after a survey* on page 167


### Parameter references

- *Data cleaning* on page 253
- *Projection parameters* on page 222

### Related topics

- *Export xyz file* on page 286
- *Export formats* on page 427
- *Geographical view* on page 52
- *Geoid* on page 414

## 7.7.2 Export xyz file



To export an ascii file of data from the current survey, press **File**→**Export xyz-file**.

The settings used to create the ascii xyz file are the same as used when exporting the survey.


The settings used are the **DAF Geo. Coordinates**, the **Point Set** is **Median** and the **LoD** (default setting is 0, the highest resolution). The variable **Z** is used by default. The latest value used, will be used by default.

The generated file will be placed in the grid directory of the survey (C:\sistdata\grids\<surveyname>) and the name of the file is <surveyname>\_xyzZ.DAF.xyz where **Z** is the variable used. The file is in ascii lat/long format, and can be zipped and transferred to other systems.

### 7.7.3 Remove survey


Surveys can be permanently deleted from the database. Logged data is not affected.

**File→Remove survey from database**



### 7.7.4 Save settings

**Save Settings** is accessed from the **File** drop-down menu. It will automatically save the current frame settings. If the current frame settings cannot be saved under the chosen name, you are prompted to use the **Save settings as...** option.




### 7.7.5 Save settings as...

The **Save Settings As...** is accessed from the **File** drop-down menu. You can choose to save different frame setting combinations by giving them different names.

Press **Accept** to add the new frame setting.

Press **Cancel** to abort.



### 7.7.6 Delete settings


The **Delete Settings** is accessed from the **File** drop-down menu.

This is used to delete one of your predefined frame setting combinations.

**Setting Name:** Select the survey setting to be deleted.

Press **Accept** to add the new frame setting.

Press **Cancel** to abort.




### 7.7.7 Set startup settings

You can choose the default start-up window settings:

**File→Set Startup Settings.**

When SIS starts up, the selected window set will be used.



### 7.7.8 Export PU parameters


The **Export PU parameters...** operation is accessed from the **File** drop-down menu.

It is used to save the Installation and Runtime parameters for the current echo sounder to file in an ASCII readable format.

The file may later be imported whereby the saved settings are restored.

The file name and storage location can be specified in the pop-up window displayed when **Export PU parameters...** is selected. A default storage location for such files is defined by SIS, but you are free to choose another location.

The default file extension is **.txt**, but any user defined extension is allowed.



---

#### Note

*It is recommended that the parameters for an echo sounder is saved as soon as the initial configuration (i.e. installation and runtime parameters) has been completed and stored in the database.*

*The saved parameters file can be edited. However, this is not recommended and must only be performed by users with intimate knowledge of SIS.*

---


#### Related topics

- *Current echo sounder* on page 33
- *Import PU parameters* on page 290
- *Installation parameters* on page 226
- *Runtime parameters* on page 243

### 7.7.9 Import PU parameters

The **Import PU parameters...** operation is accessed from the **File** drop-down menu.

It is used to read a previously saved parameters file for a specific echo sounder and restore the parameter settings for this echo sounder to the same status as when the file was saved.



The import operation can be performed without consideration of which echo sounder is currently set as active or whether the relevant echo sounder is started or even detected on the network.

#### Note

*The echo sounder will not be automatically updated with imported settings. Only the database (SISDB) will be updated. It is therefore necessary to manually initiate an update of the echo sounder (PU) by starting it (if not previously started) or by using the Installation Parameters - or the Runtime parameters frame.*

The file name and storage location of the PU parameter file can be specified in the pop-up window displayed when Import PU parameters is selected.

The Import PU parameters operation is typically used to avoid having to re-enter all set-up parameters manually after reinstalling SIS and the database.

When importing PU parameters a pop-up dialog box will be used to allow you to specify another serial number to replace the serial number in the imported file. This will effectively allow you to copy a parameter setup from one configuration to another e.g. when replacing/changing a main sonar head.

**Note**

*Remember to save the parameters if changing serial number.*

---

**Related topics**

- *Current echo sounder* on page 33
- *Export PU parameters* on page 289
- *Installation parameters* on page 226
- *Runtime parameters* on page 243


**7.7.10 Export user settings...**

The **Export User settings...** operation is accessed from the **File** drop-down menu.

It is used to save current database settings for later retrieval.

The following **Export selections** can be made:

- **User parameters:** Stores the entries set in the **Set Parameter** menu
- **Datagram subscription:** Stores a list of the datagrams subscribed to in current database settings
- **Survey template:** Stores the survey definition
- **Projections:** Stores the name and definitions for selected projection
- **Frame settings:** Stores current frame setting definitions




### Related topics

- *SIS parameters – Set parameters* on page 266
- *Frame toolbars parameters* on page 169
- *Survey parameters* on page 216
- *Projection and datum parameters* on page 308

### 7.7.11 Import user settings...

The **Import User settings...** operation is accessed from the **File** menu.

It is used to restore earlier exported database settings.



The following **Import selections** can be made:


- **User parameters:** Restores entries set in the **Set Parameter** menu
- **Datagram subscription:** Restores the datagrams subscribed to
- **Survey template:** Restores survey definition
- **Projections:** Restores projection
- **Frame settings:** Restores frame settings

### Related topics

- *SIS parameters – Set parameters* on page 266
- *Frame toolbars parameters* on page 169
- *Survey parameters* on page 216
- *Projection and datum parameters* on page 308

### 7.7.12 Create CUBE grid

When logging is completed, a **CUBE grid** may be generated:  
**File**→**Create CUBE grid**.



The same survey template from which the current survey was created, is set as default. The first tide and geoid file, found in the raw data folder, is displayed in the menu. The buttons at the right hand side can be used to browse for other tide and geoid files.

Pressing the OK button starts the processing, and a progress box appears. The whole SIS application is locked while the CUBE grid is generated and as long the **Create CUBE Grid** box is active. The **Create CUBE Grid** box will be visible for a while, after the SIS progress box disappear, to complete the necessary calculations.

If the CUBE grid is to be shown, SIS must be set to CUBE mode. Start **Set Parameters** from the **Tools**→**Custom** menu, select **Logging** and set the data cleaning method to **CUBE**. SIS has to be restarted, and no echo sounders have to be started before the grid is imported to SIS.

### Parameter references

- *Logging* on page 274

### Related topics

- *CUBE* on page 375

## 7.7.13 Quit

**Quit** is accessed from the **File** drop-down menu.

This will shut down the SIS program without any further confirmation of your choice.

The SIS program can also be shut down by using the **Close** button on the right hand side of the SIS title and info bar (i.e. upper right corner of the SIS application window).

### Note

*Closing down may take some seconds. Do not try to restart SIS until the SIS application window has disappeared.*

### Related operational procedures

- *How to exit the SIS software* on page 168
- *How to shut down the operator station* on page 168

- *How to shut down the Processor Unit (PU) or the Transceiver Unit on page 168*

## 7.8 Tools menu parameters

The **Tools** drop-down menu gives you the following choices:

- *External sensors* on page 295
- *Instrument combinations* on page 302
- *Remove instruments* on page 303
- *C-MAP – Licence administration* on page 304
- *AutoCalib Wizard* on page 305
- *SeaCal results* on page 306
- *Extract IFF* on page 306
- *Custom menu* on page 94

### Related operational procedures

- *How to save data* on page 142
- *How to define a new projection and datum transformation* on page 107
- *How to enter the waterline* on page 122
- *How to collect the sound velocity profile* on page 125
- *How to convert your sound velocity profile to SIS format* on page 126
- *How to modify and load a sound speed profile into SIS* on page 132
- *How to run the PU simulator* on page 164

### 7.8.1 External sensors

**External sensors** is accessed from the **Tools** menu.

This is where you define the interfaces to your external sensors that are attached directly to the Hydrographic Work Station (HWS) computer or sensors sending their data on Ethernet to the HWS computer.

Note \_\_\_\_\_

*Interfaces to external sensors that are attached to the Processing Unit (PU) are defined in the **Installation parameters**.*

---

**External sensors**

**Input Setup**

Sound Velocity Probe  
Probe available ☐ Port   
Probe type

Real time Tide  
Port   
Realtime Tide avail ☐

SVP Logger  
SVP Logger avail ☐ Port

Barometer  
Barometer avail ☐ Port

Geodimeter  
Geodimeter avail ☐ Port

Echosounder

**Heading**  
Sensor name  Serial ☐ Port  Ethernet ☐ IP addr.  Port addr.   
Add  Compass deviation file:  ...

**Position**  
Sensor name  Serial ☐ Port  Ethernet ☐ IP addr.  Port addr.   
Position delay (sec.):   
Add  Location offset (m) Forward (X)  Starboard (Y)  Downward (Z)

**Output Setup**  
Auto Pilot ☐ AP Port   
Auto Pilot avail ☒ COM1


Dyn Pos  
Dyn Pos avail ☐ Dyn Pos Port

Depth below keel  
Port   
Depth below keel avail ☐

Port   
Baud rate:   
Data bits:   
Stop bits:   
Parity:

Waterline(m), Downward (Z)

OK CANCEL




## Input setup

- **Sound Velocity Probe type**

The following choices are available:

- SV (C) - only sound velocity
- SV&T (C+T) - sound velocity and temperature
- SV&T (C+P) - sound velocity and pressure (pressure not significant)
- Ext. datagrams (C+T) - sound velocity and temperature

See format description in *External datagram (C+T) format* on page 439




## Sound speed sample frequency rate

The sample rate expected from the sound velocity sensors (SV, SV&T, SV&P) is 10 Hz. The sample rate of the external datagrams is 1 Hz.


These rates are used in the sound speed filtering. For more details on filtering see the **Sound Speed** entry in the **Runtime parameters** setup.

- **Real time tide:**



SIS can receive real time tide information on serial lines. Select **Realtime Tide available** and set the communication parameters for the selected line.

- **Heading parameters:**




The screenshot shows a software window titled "Heading". It has several input fields and controls:

- Sensor name:** A dropdown menu with "Seapath" selected.
- Serial:** A checkbox that is checked.
- Port:** A dropdown menu with "COM1" selected.
- Ethernet:** A checkbox that is unchecked.
- IP addr.:** An empty text input field.
- Port addr.:** An empty text input field.
- Add:** A button located below the "Sensor name" field.
- Compass deviation file:** A text input field followed by a browse button (three dots).

- **Sensor name:** Display name
- **Serial/Port:** When serial interface is enabled the com port number must be set
- **Ethernet/IP address/port:** When ethernet interface is enabled IP address and local port number must be set
- **Add:** Must be pressed for each system you configure
- **Compass deviation file:** Use the browse button (three dots) to find the desired file.

- **Position parameters:**



The 'Position' dialog box contains the following fields and controls:

- Sensor name:** A dropdown menu with 'RTK' selected.
- Serial:** A checked checkbox.
- Port:** A dropdown menu with 'COM3' selected.
- Ethernet:** An unchecked checkbox.
- IP addr.:** A text input field.
- Port addr.:** A text input field.
- Position delay (sec.):** A text input field with '0.0'.
- Forward (X):** A text input field with '0.0'.
- Starboard (Y):** A text input field with '0.0'.
- Downward (Z):** A text input field with '0.0'.
- Location offset (m):** A text input field with '0.0'.
- Add:** A button.

- **Sensor name:** Display name
- **Serial/Port:** When serial interface is enabled the com port number must be set
- **Ethernet/IP address/port:** When ethernet interface is enabled IP address and local port number must be set
- **Position delay (sec):** Enter any known position delay.

The accuracy of the position sensor is vital for the data accuracy, and it is therefore important that the relative timing of vessel position data and system depth data is correct. To define the duration of life of the positioning system input data, you can enter a position delay.

A position delay is required if the position that is output on the port applies to an observation that was done a significant number of seconds ago. The position delay may be significant for systems where the internal computation and processing of the position takes time.

- **Add:** Must be pressed for each system you configure
- **Location offset (m):** Use the text fields to enter the location of the GPS antenna relative to the vessel's reference point.

#### *Caution*

*The positioning system may have internal offset parameters set. Make sure that the antenna offsets are not applied both in the position system and in SIS.*

- **SVP Logger**




The 'SVP Logger' dialog box contains the following fields and controls:

- SVP Logger available:** A checked checkbox.
- Port:** A dropdown menu.

Selects a serial line and sets the parameters. The SVP Logger is started from the SVP editor..


- **Barometer**



The Barometer configuration dialog box has a title bar 'Barometer'. It contains a checkbox labeled 'Barometer avail' which is currently unchecked. To the right of the checkbox is a dropdown menu labeled 'Port'.

Set if barometer input is available and select HWS input port (serial line).

- **Geodimeter**




The Geodimeter configuration dialog box has a title bar 'Geodimeter'. It contains two checkboxes: 'Geodimeter avail' (checked) and 'Echosounder' (unchecked). To the right of the 'Geodimeter avail' checkbox is a dropdown menu labeled 'Port' with 'COM1' selected. To the right of the 'Echosounder' checkbox is a dropdown menu with 'EM3002\_888' selected.

This setting applies if a Geodimeter position system is being used. Set whether a Geodimeter is available, select HWS input port (serial line) and select the echo sounder where the position input is to be sent to.

## Output setup

- **Auto Pilot parameters:**



The Auto Pilot configuration dialog box has a title bar 'Auto Pilot'. It contains a checkbox labeled 'Auto Pilot avail' which is checked. To the right of the checkbox is a dropdown menu labeled 'AP Port' with 'COM1' selected.

Select **Auto Pilot available** if you want data to be sent to the auto pilot. Choose a serial line from the combo box.

Enabling or disabling of NMEA APB output is done in the **Show/Hide** menu of the **Helmsman display**. See *Helmsman display – Show/hide* on page 191


- **Dyn Pos parameters:**



The Dyn Pos configuration dialog box has a title bar 'Dyn Pos'. It contains a checkbox labeled 'Dyn Pos avail' which is unchecked. To the right of the checkbox is a dropdown menu labeled 'Dyn Pos Port'.

Select **Dyn. Pos. available** if you want data to be sent to the dynamic positioning system. Choose a serial line from the combo box.

- **Depth below keel:**



The **Centre depth output** is always sent as a NMEA DPT datagram on UDP to port number 4310. The NMEA depth output from SIS is coded. The two aa's in the string \$aaDPT are set according to sounder type, see table below.

If depth below keel is selected in the External sensor user interface the NMEA datagram is sent out to the selected serial line.

Echo Sounder Model	NMEA String
EM 2000	\$KADPT
EM 3000	\$KBDPT
EM 3002	\$KCDPT
EM 1002	\$KDDPT
ME 70	\$KJDPT
EM 710	\$KEDPT
EM 300	\$KFDPT
EM 302	\$KHDPT
EM 120	\$KGDPT
EM 122	\$KIDPT

### Other parameters

- **Port:** Choose the port you want to set communication parameters for
- **Baud rate:** 1200, 2400, 4800, 9600 or 19200
- **Data bits:** 7 or 8
- **Stop bits:** 1 or 2
- **Parity:** None, Odd or Even.

## Waterline

Enter the vessel's waterline vertical location (in normal trim) in the vessel's reference coordinate system. It is recommended to use an average of two measurements; one on each side of the vessel. The measurement must be made at the same alongship location as the physical location of the motion sensor.

### Note

---

*If the vessel's displacement or trim changes during a survey, the Waterline value must be updated accordingly.*

---

## Related operational procedures

- *How to setup the input from external sensors* on page 120
- *How to setup the output to external sensors* on page 122
- *How to enter the waterline* on page 122
- *How to use SVP Logger* on page 127

## Parameter references

- *Sound speed for EM 1002* on page 246

## Related topics

- *SVP Editor* on page 318
- *Barometer input* on page 457
- *External datagram (C+T) format* on page 439
- *Helmsman display view* on page 63

## 7.8.2 Instrument combinations

**Instrument combinations** is accessed from the **Tools** menu.

Through the **Instrument combination** you may add interfaces to equipment that does not communicate through the echo sounder PU and does not broadcast on the Ethernet.

**Add instruments**

GPS + Compass ☐ Name  Id\_no

SBES + GPS + Compass ☐ Name  Id\_no

Existing instruments

Type	Name	Id no
GPS	TEST	508

OK CANCEL Apply Help

The equipment can be GPS, compass or single beam echo sounder (SBES) type equipment.

You have to give the instrument an ID number. This number must be unique for each type of equipment. The ID number is treated the same way as the serial number for equipment with a PU (Processing Unit).

After the instruments are registered they will appear in the **Not Started** combo box and the **Current echo sounder** combo box on the main toolbar.

### Add instrument parameters

**GPS + Compass:** Give the new instrument a name and an ID number to GPS and compass type equipment

**SBES + GPS + Compass:** Give the new instrument a name and an ID number to SBES, GPS and compass type equipment


**Existing instruments:** A list of the instruments that have been defined.

### Related topics

- *Remove instruments* on page 303
- *Echo sounder – Not started list* on page 32
- *Current echo sounder* on page 33

## 7.8.3 Remove instruments

The **Remove Instruments** is accessed from the **Tools** menu. Select the instrument you want to remove, and press **OK**.



### 7.8.4 C-MAP – Licence administration


C-MAP is accessed from the **Tools** menu and contains the following administrative sub menus:

- **LicenceAdm** – giving you the opportunity to administrate the C-MAP licence in SIS
- **GDBAdmin** – for administration of the C-MAP database
- **Update charts** – administration of C-MAP chart updates

#### LicenceAdm

Note

*C-MAP licensing is not included in standard SIS delivery and must be ordered separately.*



The following options for C-MAP Licence Administration are available:

- **Add License manually:** You may enter your license manually by entering the alphanumeric string in the **License string** text field. The license string is issued by C-MAP Norway.
- **Get expired licenses:** Press this button to see whether earlier versions of C-MAP have been installed and when the subscription date exceeded.  
May be of interest for C-MAP trouble shooting.
- **License list:** Gives you an overview of the C-MAP licenses, i.e. zones, that your system subscribes to.
- **Add license from file:** You will normally have received your C-MAP license both as an alphanumeric string and contained in a file. The file is by default named **PASSWORD.USR**. Browse for this file and press **OK** to apply.
- **License order:** This view gives you an overview of what licenses your system subscribes to.

### Related topics

- *C-MAP CM-93/3* on page 354
- *C-MAP detail level* on page 37
- *Geographical – C-MAP manipulation mode* on page 183

## 7.8.5 AutoCalib Wizard

Before running the **AutoCalib Wizard**, ensure that the survey you want to run the calibration on is loaded, and that the raw files are available.

From the **Tools** menu, select **AutoCalib Wizard...** to start the calibration process. The **AutoCalib Wizard window** will appear, and a further set of dialogue boxes will be available. Respond to them according to how you want to run the calibration.



After the last dialogue box has been displayed, the calibration process will start in the background. You may continue working while the process is running. When the process is finished you will be prompted to open the result file and inspect the result. You can also open the file and inspect the result later by selecting **Tools**→**SeaCal Results**. (The SeaCal program is used by AutoCalib.) The results may be applied to the echo sounder's installation parameters or saved to a file for later use. If you want to apply the result, you must open the **Installation Frame**, and press **OK** to activate the result, as when storing the manual calibration values.

### **Related topics**

- *Calibration parameters* on page 213
- *Seacal auto calibration* on page 214
- *SeaCal results* on page 306
- *SeaCal* on page 335

## **7.8.6 SeaCal results**

The **SeaCal Results** is accessed from the **Tools** menu.

Use this option to browse for and open SeaCal result files (\*.res).

### **Related topics**

- *Calibration parameters* on page 213
- *Seacal auto calibration* on page 214
- *AutoCalib Wizard* on page 305
- *SeaCal* on page 335

## **7.8.7 Extract IFF**

The **Extract IFF** is accessed from the **Tools** menu. From this menu, **Position**→**All** and **Position**→**New** can be chosen.

**Position**→**All** will create **Intermediate File Format** files of all position datagrams in the survey lines. **Position**→**New** will extract positions from new files not previously processed.

The positions can be colour-coded by the quality indicator in the GGA datagram. The quality factor will identify where the position quality is based on 2D or 3D GPS position determination, i.e. where a valid height is computed or not.

### **Note**

---

*Logging must be Off for the IFF functionality to be activated*


---

The quality factor of the positions can be view in the **Geographical** view. **Processed positions** must be selected from the **Option** button in the Geographical view, see *Options* on page 170.

### 7.8.8 Configure...

The **Configure...** item is accessed from the **Custom** sub-menu found in the **Tools** main menu.

The Configure dialogue box is used to manage existing applications in the **Custom** sub-menu. It is possible to add, hide or delete applications, or change the sequence in which they appear in the Custom sub-menu. Note that it is not possible to delete any of the factory defined applications.



A new application is added by pressing the **Add** button in the dialogue box. Fill in all text fields marked in yellow. Press the **Apply** button to add the new application to the Custom sub-menu.

Program arguments can be added, e.g. a text file if the application is a text editor.

Click the **Hide** application box to hide a console application when starting SIS. The application will then only be visible in the Task Manager.

Press the **OK** button to store changes.

Press **Esc** to cancel.

### Related topics

- *Custom menu* on page 94

## 7.9 Projection and datum parameters

When selecting **Tools**→**Custom**→**Projection setup** the Projections window opens.

The **Projection** setup must be used to define the following geodetic parameters:

- The datum your input positions refer to
- The datum you want your output positions to refer to
- The datum transformation parameters to apply to the input positions
- The projection for the plane coordinates (map coordinates)

### Note


---

*If your projection and datum transformation is already defined in SIS, you do not have to enter the Projection setup. The correct projection can be directly selected through the **Survey Administration** or the **New Survey setup** pages.*

---

This **Projection** window contains two tabs:

- The **Define projections** tab is where you define the datum transformation and projection:
  - Projection (and datum transformation) may be selected from a **PROJ.4** file, or
  - Projection (and datum transformation) may be selected from the SIS database, or
  - You may enter your datum transformation and projection parameters manually
- The **Test selected projection** tab allows you to test the selected datum transformation and projection.



### Select projection file

- **Select projection file from disk** opens a file selection box where you can select files in PROJ.4 format.

#### Note

*PROJ.4 format is a generic format for definition of projection of geographical coordinates to plane coordinates. The PROJ.4 format may also contain datum transformation parameters.*

- **Select projection in file** is then used to select the projection in the selected file. The name of the selected projection appears below.
- **Put projection into database**; a projection from the file is inserted into the database. The database tables are updated. It is not possible to change a projection if it is used by any surveys unless the user specifies it.

### Projections in the database

- **Select projection in the database**; you can also select a projection from the database. It is not allowed to change a projection used by a survey unless you specify it.
- **Write projection to file**; selected projection is stored to file in PROJ.4 format.

### Projection definition

You may input, edit or delete your own definitions of projection and datum transformation parameters by using the **New**, **Edit** and **Delete** buttons.

## Test selected projection

**Test selected projection** allow you to test the selected projection. You can choose the format of the geographical coordinates to decimal degrees, decimal minutes or decimal seconds. You can then input geographical coordinates and press **Calculate** in that window to see the projection coordinates in the window below, or vice versa.

## Available ellipsoid definitions in SIS

Ellipsoid name	Major axis (a)	Reverse flattening (rf) / Minor axis (b)	Description
MERIT	a=6378137.0	rf=298.257	MERIT 1983
SGS85	a=6378136.0	rf=298.257	Soviet Geodetic System 85
GRS80	a=6378137.0	rf=298.257222101	GRS 1980 (IUGG, 1980)
IAU76	a=6378140.0	rf=298.257	IAU 1976
airy	a=6377563.396	b=6356256.910	Airy 1830
APL4.9	a=6378137.0	rf=298.25	Appl. Physics. 1965
NWL9D	a=6378145.0	rf=298.25	Naval Weapons Lab., 1965
mod_airy	a=6377340.189	b=6356034.446	Modified Airy
andrae	a=6377104.43	rf=300.0	Andrae 1876 (Den., lclnd.)
aust_SA	a=6378160.0	rf=298.25	Australian Natl & S. Amer. 1969
GRS67	a=6378160.0	rf=298.2471674270	GRS 67(IUGG 1967)
bessel	a=6377397.155	rf=299.1528128	Bessel 1841
bess_nam	a=6377483.865	rf=299.1528128	Bessel 1841 (Namibia)


Ellipsoid name	Major axis (a)	Reverse flattening (rf) / Minor axis (b)	Description
clrk66	a=6378206.4	b=6356583.8	Clarke 1866
clrk80	a=6378249.145	rf=293.4663	Clarke 1880 mod.
CPM	a=6375738.7	rf=334.29	Comm. des Poids et Mesures 1799
delmbr	a=6376428	rf=311.5	Delambre 1810 (Belgium)
engelis	a=6378136.05	rf=298.2566	Engelis 1985
evrst30	a=6377276.345	rf=300.8017	Everest 1830
evrst48	a=6377304.063	rf=300.8017	Everest 1948
evrst56	a=6377301.243	rf=300.8017	Everest 1956
evrst69	a=6377295.664	rf=300.8017	Everest 1969
evrstSS	a=6377298.556	rf=300.8017	Everest (Sabah & Sarawak)
fschr60	a=6378166	rf=298.3	Fischer (Mercury Datum) 1960
fschr60m	a=6378155	rf=298.3	Modified Fischer 1960
fschr68	a=6378150	rf=298.3	Fischer 1968o
helmert	a=6378200	rf=298.3	Helmert 1906
hough	a=6378270.0	rf=297	Hough
intlh	a=6378388.0	rf=297	International 1909 (Hayford)
krass	a=6378245.0	rf=298.3	Krassovsky, 1942
kaula	a=6378163	rf=298.24	Kaula 1961
lerch	a=6378139	rf=298.257	Lerch 1979
mprts	a=6397300	rf=191	Maupertius 1738
new_intl	a=6378157.5	b=6356772.2	New International 1967
plessis	a=6376523	b=6355863	Plessis 1817 (France)
SEasia	a=6378155.0	b=6356773.3205n	Southeast Asiae
walbeck	a=6376896.0	b=6355834.8467	Walbeck
WGS60	a=6378165.0	rf=298.3	WGS60
WGS66	a=6378145.0	rf=298.25	WGS66
WGS72	a=6378135.0	rf=298.26	WGS72
WGS84	a=6378137.0	rf=298.257223563	WGS84

### Available projections in SIS


- UTM – Universal Transverse Mercator.

When selecting UTM you will be prompted for UTM zone and whether you are on northern or southern hemisphere

- UPS – covers the polar regions




- Mercator




You will be prompted for latitude and longitude of origin, false northing and false easting.

- Transverse Mercator (TM)




Same parameters applies to the Transverse Mercator as for the Mercator. In addition a scale factor for the central meridian must be input

- User defined – selected by number from in the static and dynamic libraries. These projections are identified by a unique number known to the user. You can choose this number in the User's projection dialogue. If this number is not implemented, the selection procedure will exit.



By selecting =1 the Gauss Krüger projection will be selected.  
See *Gauß Krüger* on page 314

- PROJ.4 definition – enables input of programmable datum transformation and/or projection parameters



The PROJ.4 style must be entered in the following format:

+init=my\_file\_with\_proj4\_projections:my\_projection

**Note** \_\_\_\_\_

*The following will fail:*

+init=c:\mydir\myfile.txt:my\_projection

*because the first : is not allowed. This means that your projection file have to be on the same disk*

---

## Support user defined projections

### Gauß Krüger

Enter User's **projection number = 1** in the dialogue window. The parameters for the projection can be controlled in a file named **projection.data** like this:

GK_AUSTRIA	GK_AUSTRIA tells Software to use Gauß-Kruger for Austria
	Transformation parameters for WGS84 to Gauss-Krüger coordinates according to Datum MGI
-603.919	Translation in x [m]
-71.656	Translation in y [m]
-433.142	Translation in z [m]
-4.377582	Scale
0.757332	Rotation in x ["]
0.334161	Rotation in y ["]
-1.604013	Rotation in z ["]
6377397.155	Major axis [m] (Bessel)
299.152815	Flattening (Bessel)
12.0	Central Meridian (Bessel)
6378137.0	Major axis (WGS84)
298.257223563	Flattening (WGS84)
4500000	Zuschlag Rechtswert
0	Zuschlag Hochwert
0	Fixed height used in projections

### Hungary

User projection number = 2. This is a projection for the Budapest area.

### Related operational procedures

- *How to define a new projection and datum transformation* on page 107

### Related topics

- *Projection parameters* on page 222
- *Projections* on page 411

## 7.10 Help menu dialogs

The **Help** drop-down menu gives you the following choices:


- *Help* on page 315
- *Build info* on page 315

- *OpenGL settings* on page 315
- *About SIS...* on page 316

### 7.10.1 Help

Help is accessed from the **Help** menu.


It will open the online-help system.



### 7.10.2 Build info

The **Build Info** message box is accessed from the **Help** menu.

It contains information about the current SIS software build.




### 7.10.3 OpenGL settings

The **OpenGL Settings** message box is accessed from the **Help** menu.


It provides the following information about the **OpenGL settings**:


- Driver information
- Display mode
- Available extensions



#### 7.10.4 About SIS...

The **About SIS** message box is accessed from the **Help** menu. It contains general information about the SIS software.



This message box can also be accessed by pressing the SIS icon on the status bar in lower right corner .

## 8 SIS UTILITIES

This chapter provides description of operation and parameter setup of utility programs related to SIS. Some are accessed directly from SIS.

### Topics

- *SVP Editor* on page 318
- *SVP Effects* on page 324
- *SmartTalk (SVP)* on page 327
- *SVP Logger* on page 332
- *SeaCal* on page 335
- *SIS Objects* on page 344
- *C-MAP CM-93/3* on page 354
- *Global event marker* on page 359
- *PU simulator and playback* on page 361
- *Create terrain models from ASCII files* on page 363
- *KSGPL* on page 365
- *How to use SIS on an AUV/ROV* on page 371
- *CUBE* on page 375


## 8.1 SVP Editor

The **SVP Editor** is used to load and edit the sound speed profiles logged in **.asvp** or **.actd** formatted files. This is a utility program to SIS and holds a number of tools to assist in creating a good sound velocity profile, including manual editing.

The main user interface for the SVP Editor is shown in figure below.

### Note

*To view the graph and the data values extend the window by dragging the window frame.*















### Main menu

The main menu of the SVP Editor holds the following selections:

- File menu, see *File menu* on page 320
- Tools menu, see *Tools menu* on page 321
- Help menu

## Buttons

Select	To
	Copy selected row in the table. This allows you to add values to the profile because a copied row can be edited.
	Delete all selected rows in the table
	Reset all selections that you have done
	Redraw the profiles. You have to use this button after selecting rows in order to identify the selected value.
	Redraw the profile using the depth scale that fills the display window. The profiles are by default drawn using 100 metres maximum depth.
	Recalculate an absorption coefficient in a cell from previous and next values in that column.
<div><b>Primary svp</b></div> <div></div>	Select your primary sound velocity profile. All loaded profiles can be selected from the pull-down menu. The primary SVP is drawn using red circles and white lines.
<div><b>Secondary svp</b></div> <div></div>	Select a secondary sound velocity profile. Showing a second sound velocity profile is useful for quality controlling the primary SVP. The secondary using blue circles and green lines.
<div>From depth </div> <div>To depth </div>	Set the start and maximum depth to be displayed. When set the display window can be scrolled up and down remaining the same relative scale.  The difference between minimum and maximum depth have to be 5 meters or more.
<div>From speed </div> <div>To speed </div>	Set the minimum and maximum speed to be displayed. The setting of these parameters can be useful to scroll the display in the speed direction.
<input checked="" type="checkbox"/> Automatic speed scale	Automatically compute the best fit for minimum and maximum speed. The <b>From speed</b> and <b>To speed</b> settings are overridden.

## The graphical display

The loaded profiles will be displayed in a graphical display having depth and sound velocity speed as vertical and horizontal axes.

## The Numerical display

The numerical table to the right shows the data from the primary svp. You can at any time change the values in this table. Press **Return** to see the effects in the profile.

When selecting a value in the profile, the row in the table will be selected as well. Note that the table may be too big to fit in the window. You may have to scroll the table to see the selected row.

## File menu

- **Open:** Open a .asvp or .actd file and make the profile primary
- **Open in editor:** Open selected file in a separate raw editor program
- **Save as:** Save the primary svp with a name of your choice
- **Save primary svp:** Save the primary svp to its original file.

Note \_\_\_\_\_

*The original file will be overwritten.*

---

- **Send primary svp to echo sounder:** Information about the primary svp is sent to SIS where all mean absorption coefficients are recalculated using the depths found in the .asvp file

Note \_\_\_\_\_

*The svp must be selected in the Sound Speed frame in the Runtime parameters view, for active use.*

---

- **Close primary svp:** Close primary svp and remove it from the editor. Note that it will not be saved.
- **Close all:** Close all profiles and remove them from the editor. Note that the profiles are not saved.
- **Exit:** Exit the program. Note that unsaved profiles are not saved.

### Tools menu

- **csv2asvp:** Launch the program **csv2asvp** which helps you to convert data from the AML Smart Probe logged in **.csv** files using the program SmartTalk. The output from **csv2asvp** is **.asvp** files which can be edited in SVP Editor.
- **SVPLogger:** The SVPLogger (formerly Morse) logs data from the AML and the Morse sound speed sensors. Please see the help file (press the **Help** button) in the SVPLogger for details.

#### Note

---

*The correct communication parameters for the serial line connecting the SVP probe to the HWS must be set from the external sensor menu: **Tools**→**External sensors**.*

---

- **Extend profile:** The profile will be extended down to 12,000 meters. Note that the profile must be continuous for this operation to be carried out. If not all depths in the profile are ascending, the rows where the depth is equal or above the previous row will be selected. You can then press **Delete rows** and delete them. Now this operation can be carried out. Extending an **.actd** file may require manual work to verify that the extended values are correct.
- **Extended profile...:** The current profile can be extended with a values read from file.

#### Note

---

*The profiles must be of the same type, i.e. they must all be without absorption coefficient files. A warning is given if svp's of different types are used.*

---

#### Note

---

*Extending actd files may require manual work to verify the extended values are correct.*

---

- **Thin profile:** Thin the profile by removing some points. You have to enter a thinning factor (0.01 to 3.0). The smaller the factor, the less thinning will be done. The results from the thinning is then presented in a table, see the figure below. Note that this operation requires that the profile is extended.
- **Replace primary with data from secondary:** If the primary svp contains depths from 0 to 12,000 meters and the secondary contains data from 0 to 100 meters, the values from 0 to 100 meters in the primary svp will be replaced with the data from the secondary svp.
- **Check profile:** Check that the primary sound speed profile not contains upwards bends in the depth

- **Check profile automatic:** Automatic check for depth bends.

## Thinning results table

The thinned primary svp is written to a file with **thinned** appended to the filename of the primary svp. The **thinned** profile is then automatically read into SVP Editor.

The **Thinning results table** shows the results from using the original and the thinned profile. Each table has selected beam pointing angles as columns and selected depths as rows. The approximate depth used is listed in the column to the left.

Note that the depth used in the calculations will differ from this depth because the raypath routine requires time as input, and the time is computed from the depth and the average sound speed in the profile, which will be different from the true profile.

Results of thinning										
Warning threshold (m)		0.1		First table is depth differences (m)		Second table is horizontal differences (m)		Print...		OK
Depths/Beam a.	0.0	10.0	20.0	30.0	40.0	50.0	60.0	70.0	80.0	
5.0	4.914,91	4.914,91	4.914,91	4.914,91	4.914,91	4.914,91	4.894,89	4.874,87	4.744,74	
10.0	9.99,9	9.99,9	9.99,9	9.87,9,87	9.83,8,83	9.76,9,76	9.69,6	9.14,9,13	6.75,6,76	
20.0	19.99,19,98	19.98,19,98	19.94,19,94	19.86,19,86	19.71,19,71	19.43,19,43	18.78,18,78	16.72,16,71	-99,99	
50.0	50.26,50,24	50.22,50,22	50.09,50,09	49.83,49,83	49.36,49,36	48.42,48,42	46.29,46,28	39.43,39,41	-99,99	
100.0	100.7,100,68	100.61,100,62	100.34,100,34	99.78,99,79	98.76,98,76	96.74,96,74	92.14,92,13	77.26,77,23	-99,99	
200.0	201.58,201,57	201.41,201,41	200.83,200,84	199.89,199,89	197.56,197,57	193.39,193,38	183.83,183,82	152.93,152,87	-99,99	
500.0	504.82,504,82	504.82,504,82	503.22,503,22	500.04,500,05	494.18,494,18	482.79,482,79	457.38,457,36	378.35,379,27	-99,99	
1000.0	1011.79,1011,8	1008.38,1008,...	1001.57,1001,...	988.88,988,88	963.83,963,82	905.82,905,8	708.68,708,6	-99,99		
2000.0	2026.11,2026,...	2018.95,2018,...	2004.72,2004,...	1978.26,1978,...	1926.42,1926,...	1808.19,1808,...	1420.16,1420,...	-99,99		
4000.0	4082.51,4082,...	4064.38,4064,...	4028.42,4028,...	3961.9,3961,9	3832.86,3832,...	3545.31,3545,...	2682.73,2682,...	-1,-1		
6000.0	6184.02,6184,...	6148.91,6148,...	6079.37,6079,...	5951.13,5951,...	5703.8,5703,79	5160.26,5160,...	3612.4,3612,36	-1,-1		
8000.0	8334.33,8334,...	8275.16,8275,...	8158.13,8158,...	7942.83,7942,...	7529.66,7529,...	6631.47,6631,...	-1,-1			
11000.0	11658.4,11658,...	11547.26,1154,...	11327.95,113,...	10926.22,109,...	10161.59,101,...	-1,-1	-1,-1	-1,-1		
Depths/Beam a.	0.0	10.0	20.0	30.0	40.0	50.0	60.0	70.0	80.0	
5.0	0.0	0.87,0,87	1.79,1,79	2.84,2,84	4.12,4,12	5.86,5,86	8.51,8,51	13.5,13,5	27.87,27,87	
10.0	0.0	1.76,1,76	3.64,3,64	5.77,5,77	8.38,8,39	11.91,11,92	17.31,17,31	27.44,27,44	56.24,56,24	
20.0	0.0	3.59,3,59	7.42,7,42	11.76,11,76	17.09,17,1	24.28,24,28	35.29,35,28	55.94,55,95	-99,99	
50.0	0.0	9.08,9,08	18.75,18,75	29.73,29,74	43.22,43,22	61.38,61,38	89.28,89,2	141.47,141,48	-99,99	
100.0	0.0	18.23,18,23	37.63,37,63	59.69,59,69	86.75,86,76	123.21,123,22	179.06,179,07	284.02,284,03	-99,99	
200.0	0.0	36.53,36,53	75.47,75,4	119.6,119,61	173.82,173,83	246.87,246,89	358.79,358,81	569.11,569,15	-99,99	
500.0	0.0	91.89,91,81	189.49,189,49	300.54,300,54	436.69,436,69	619.91,619,93	900.06,900,09	1424.74,1424,...	-99,99	
1000.0	0.0	184.42,184,42	380.68,380,69	603.87,603,88	877.67,877,69	1246.63,1246,...	1812.08,1812,...	2875.67,2875,...	-99,99	
2000.0	0.0	369.79,369,8	763.3,763,3	1210.7,1210,71	1759.37,1759,...	2498.21,2498,...	3629.04,3629,...	5751.44,5751,...	-99,99	
4000.0	0.0	751.13,751,14	1550.25,1550,...	2458.38,2458,...	3571.03,3571,...	5066.66,5066,...	7347.07,7347,1	11580.21,115,...	-1,-1	
6000.0	0.0	1150.02,1150,...	2373.15,2373,...	3762.22,3762,...	5461.98,5461,...	7741.38,7741,4	11199.57,111,...	17536.64,175,...	-1,-1	
8000.0	0.0	1568.39,1568,...	3235.82,3235,...	5127.8,5127,81	7439.05,7439,...	10528.73,105,...	15186.05,151,...	-1,-1	-1,-1	
11000.0	0.0	2236.59,2236,...	4612.44,4612,...	7303.13,7303,...	10578.49,105,...	14928.28,149,...	-1,-1	-1,-1	-1,-1	

In the first table the depths from the two profiles are shown, and in the second table the horizontal placement is shown using both profiles.

In the text field on top you can set the difference between the two profiles to be shown. If the difference between the original and the thinned profile is larger than the values set (remember to press Return for the value to take effect), the background of the cell will be set to red.

You can save these results to file by pressing the **Print...** button.

Press **OK** to return to the SVP Editor.

**Related operational procedures**

- *How to collect the sound velocity profile* on page 125
- *How to use SmartTalk* on page 125
- *How to use csv2asvp* on page 126
- *How to use SVP Logger* on page 127
- *How to use SVP Manager* on page 128
- *How to use SVP Editor to convert an SVP file to .asvp format* on page 131
- *How to modify and load a sound speed profile into SIS* on page 132

**Parameter references**

- *Sound speed for EM 1002* on page 246

**Related topics**

- *SVP Effects* on page 324
- *SmartTalk (SVP)* on page 327
- *SVP Logger* on page 332

## 8.2 SVP Effects

This section describes the use of **SVPEffects**, a tool for displaying the beams as they go through the water.

### Topics

- *User interface* on page 324
- *What you see* on page 326

### Related operational procedures

- *How to collect the sound velocity profile* on page 125
- *How to use SmartTalk* on page 125
- *How to use csv2asvp* on page 126
- *How to use SVP Logger* on page 127
- *How to use SVP Manager* on page 128
- *How to use SVP Editor to convert an SVP file to .asvp format* on page 131
- *How to modify and load a sound speed profile into SIS* on page 132

### Parameter references

- *Sound speed for EM 1002* on page 246

### Related topics

- *SVP Editor* on page 318
- *SmartTalk (SVP)* on page 327
- *SVP Logger* on page 332

### 8.2.1 User interface

#### How to start SVPEffects

SVPEffects can be started from SIS by


- 1 Select **Tools**→**Custom...**→**SVPEffects** from the SIS main menu,  
or
- 2 Start by double clicking the file **SVPEffects.jar** located in the folder **C:\Program Files\Kongsberg Maritime\SIS\japp**

#### SVPEffects user interface

Here is the first user interface when SVPEffects starts:




The **File** menu contains the following options:




First press **File**→**Reference SVP**. This will bring up a file selection dialog where you select an asvp-formatted svp file to use as the reference sound speed profile.

For each depth in the reference svp, there will be a marker in the display.



Then press **File** →**SVP to compare**. This will again bring up the file selection dialog and you select an asvp-formatted svp file again. The plot will now be updated with the second svp.



Zoom in by pressing the left mouse button on the top-left corner, hold down the mouse button while dragging it to the lower-right corner and release the mouse button.

Zoom out by pressing the left mouse button in the lower-right corner, hold down the mouse button while dragging it to the upper-left corner and release the mouse button.

## 8.2.2 What you see

From the reference svp, the travelling times for nine beams are calculated down to every depth entry in the svp. The nine beams are 0 degrees (straight down), then 10, 20, 30, 40, 50, 60, 70 and 80 degrees to the side. The depths and the across values are calculated for each beam for each travelling time.

Then the same travelling times are used to calculate depth and across distance for all nine beams using the second svp.

In addition the two svp's are also drawn in the same plot.

Note

*There is a yellow spot at (-10,-10) which can be ignored; its there only to improve the display.*

## 8.3 SmartTalk (SVP)

**SmartTalk** is a utility program included on the SIS installation CD to log the sound velocity profile in a comma separated (.csv) format from an AML sound velocity probe.

**SmartTalk** is not a Kongsberg Maritime software.

### Related operational procedures

- *How to collect the sound velocity profile* on page 125
- *How to use SmartTalk* on page 125
- *How to use csv2asvp* on page 126
- *How to use SVP Logger* on page 127
- *How to use SVP Manager* on page 128
- *How to use SVP Editor to convert an SVP file to .asvp format* on page 131
- *How to modify and load a sound speed profile into SIS* on page 132

### Parameter references

- *Sound speed for EM 1002* on page 246

### Related topics

- *SVP Editor* on page 318
- *SVP Effects* on page 324
- *SVP Logger* on page 332

### 8.3.1 What it does

**Smart Talk** is a utility program to SIS, used configure and download data from sound velocity probes by Applied Microsystems Ltd. The program can be installed using the SIS CD.


Normally the Smart Talk program is located under C:\Program Files\SmartTalk. If the .exe file is not routed to the desktop, the Smart Talk program can be started from this location.

### 8.3.2 How it works

The following tasks can be performed from the application's main window:

- Configure instrument
- Download data
- View data
- Communication settings
- Configuration


- Sensor calibration




### 8.3.3 Configure instrument

Press the **Configure instrument** button to configure the profiler (i.e. the sound velocity sensor) prior to a sound velocity dip.

The profiler is connected to a serial port on the HWS, and it is automatically detected by the program.



Select the requested instrument from the list and press the **Configure** button to open the Configuration dialogue.




Configure the profiler. Remember to enter a file name in the **Log File** text box. When finished, press the **Program Instrument** to load the settings into the profiler.


The profiler is now ready to be disconnected and launched.

### 8.3.4 Download data

Press the **Download Data** button to download SVP data after a sound velocity dip.



Select the requested instrument from the list and press the **Select** button to open the Download Files dialogue. All files logged inside the profiler is now displayed.



Select the correct file in the Directory listing. Specify the path to where you want the file to be stored.

### 8.3.5 View data

Press the **View Data** button to load the profile and inspect it. In the View Data dialogue, press the **Load File** button to browse for and open the requested SVP file.

Time	Pressure dbars	Temperature Celsius	Sound Velocity m/s	Battery Volts
Cast 1				
10/6/2004 11:29:00:12	0.51	12.800	1489.54	12.0
10/6/2004 11:29:00:12	0.63	12.904	1491.01	12.0
10/6/2004 11:29:00:13	0.63	12.956	1491.34	12.0
10/6/2004 11:29:00:15	0.63	12.950	1490.86	12.0
10/6/2004 11:29:00:15	0.76	12.910	1490.64	12.0

Load File   Start Real Time Data   Options   **Export**   Next Cast   Previous Cast   Capture Data   Raw Data   Exit

Instrument: SvPlus 3376   Capture Data Type:  
 Total Casts: 1   Capture State: OFF  
 Total Scans: 105   Capture File:

The data is logged for both downwards and upwards movement in the water column. Press the **Export** button to open the Export File dialogue.

**Export File**

Export File Format

☐ Comma Seperated Values  
☒ Formatted Command Seperated Values  
☐ SVP-16 .REL file

Destination File Name

c:\program files\smarstalk\download\061004.csv

Export Status

Export File:


Percentage Complete

Export Files   Exit

In the **Destination File Name** text box, type the SVP file name and add the extension \*.csv. Press the **Export Files** button.

The sound velocity file includes components from both downwards and upwards SVP data in the Water column. The program **csv2asvp.jar** will split the data into two separate files automatically.

Start the program: **Tools**→**Custom**→**SVP Editor**, then from the started SVP Editor: **Tools**→**csv2asvp**. Press the **Choose file** button to browse for the SVP file. After selecting the requested file, press the **OK** button in the Message dialogue.



The file is now split into \*\_**downward.asvp** and \*\_**upward.asvp** components.

It is vital that valid sound velocity data is deeper than your surveying depth. If this is not the case, use the SVP Editor to extend the profile.

Finally the SVP data can be activated in the echo sounder. This is done in the Sound speed dialogue located under the Runtime parameters tab.

### Related topics

- *Sound velocity profile view* on page 70
- *Sound velocity profile – Show/hide* on page 200
- *Sound speed for EM 1002* on page 246
- *SVP Editor* on page 318

## 8.4 SVP Logger

**SVP Logger** logs raw data from **Morse** and **AML SVP** sensors and converts the data to .asvp format

### Related operational procedures

- *How to collect the sound velocity profile* on page 125
- *How to use SmartTalk* on page 125
- *How to use csv2asvp* on page 126
- *How to use SVP Logger* on page 127
- *How to use SVP Manager* on page 128
- *How to use SVP Editor to convert an SVP file to .asvp format* on page 131
- *How to modify and load a sound speed profile into SIS* on page 132

### Parameter references

- *Sound speed for EM 1002* on page 246

### Related topics


- *SVP Editor* on page 318
- *SVP Effects* on page 324
- *SmartTalk (SVP)* on page 327

### 8.4.1 Running the program

This program is an interface program for handling the Morse and AML SVP sensor.

For setting up the communication parameters for the probe, please refer to *External sensors* on page 295

## 8.4.2 Using the program



The main user interface holds the following:

**File to log raw data to...:** Select the raw data destination file for the data from the SVP sensor.

**SVP file to write...:** Set the filename the SVP will be written to. This file should end with .asvp.

**AML-format instead of Morse:** If the button AML-format is enabled and not Morse, AML and Valeport formats are accepted instead. Then this program can be used to create sound speed profiles from these sensors as well.

**Input format is meters not Bar:** If the input format is meters, enable the checkbox **Input format is meters, not dBar**. This will disable the conversion from dBar to meters. You have to know in which format your sensor has been set up.

**Send profile to SVP Editor:** When you press **Send profile to SVP Editor**, SVP Editor will load the .asvp file if the SVP Editor is up and running. Note that pressing this button twice will NOT reload the file in the SVP Editor. If you want to send it again, you have to close the file in the SVP Editor first and then press this button again.

**Latitude in degrees:** Enter the latitude in degrees. It is used to calculate the correct depth.

**Surface pressure in bars:** Enter the surface pressure in bars. It is used to calculate the correct depth.

When you press **Start**, the values from the COM port will be displayed in the SVP window. When you press **Stop**, the contents of the .asvp file is shown.

Note

---

*The .asvp file should be edited afterwards. The time and the location in the header is not correct and must be corrected.*

*You must also make sure that the profile contains a values at exactly 0.0 and at 12,000 meters depth.*

*If the file contains a great number of values, you should consider thinning the values.*

---

## 8.5 SeaCal

SeaCal is a program used to compute the calibration values of the multibeam echo sounder.

### Related operational procedures

- *How to determine calibration values using SeaCal automatic calibration* on page 156

### Related topics


- *AutoCalib Wizard* on page 305
- *SeaCal results* on page 306
- *Seacal auto calibration* on page 214

### 8.5.1 What it does

Reliable data from the multibeam echo sounder can only be acquired after proper calibration of the static offsets in system parameters such as roll, pitch, heading, eccentricity of the transducer relative the antenna of the positioning system in x and y etc.

This calibration method is based on global match of the calibration lines. It does not presume that we have information about the true relief of the seafloor. The method computes the calibration parameters from least squares adjustment, and it offers a broad range of static offset parameters to be computed and the derivation of the correlation between them. The program computes calibration parameters from parallel or crossing lines. The calibration lines must follow straight lines, i.e., curved calibration lines are not allowed. The number and the length of the lines are limited by the amount of computer memory and the speed of the computer processor. The figure below shows the coordinate axes used.

Figure 20 Definition of the coordinate axes



### 8.5.2 Calibration parameters

SeaCal is able to compute several kinds of calibration parameters. The two main groups of parameters are those common and individual for the lines. The following calibration parameters are defined:

	Symbol	Definition
Roll	$\Delta\Phi$	$\Phi' = \Delta\Phi + \Phi$
Pitch	$\Delta\omega$	$\omega' = \Delta\omega + \omega$
Heading	$\Delta\kappa$	$\kappa' = \Delta\kappa + \kappa$
Translation in x	$\Delta x$	$x_0' = \Delta x + x_0$
Translation in y	$\Delta y$	$y_0' = \Delta y + y_0$
Relative tide correction	$\Delta h_0$	$h_0' = \Delta h + h_0$
Roll scale factor	$m_\Phi$	$\Phi' = m_\Phi \Phi$
Horizontal scale factor	$m_y$	$y' = m_y y$

x is measured along the line and y is perpendicular to x, so y is measured in the swath direction.


Factor  $m_\Phi$  is a kind of parameter related to the inner calibration of the multibeam echo sounder, but it can also be explained by uncertain computation of the refraction of the beams, i.e., the accuracy of the sound speed profile. Parameter  $m_y$  is a horizontal scale factor in the swath direction. It is motivated from the influence of errors in the sound speed.

### 8.5.3 Design of the calibration lines

The accuracy of the calibration depends on the topography of the seafloor, and the configuration of the calibration lines. Therefore, the calibration lines should be located in an area with satisfactory relief and they should follow a certain pattern, i.e., a configuration that allows the computation of the parameters.

The **Effect of offset** figure below illustrates the effect of offsets in the calibration parameters. From the figure we observe that calibration for heading and the two scale factors require lines with parallel displacement. Offsets in roll, pitch, x and y are best computed from lines in opposite directions which overlap each other 100%.

Figure 21 Effect of offsets in the calibration parameters



Roll and roll scale have a vertical and a horizontal component. Their vertical component makes it possible to calibrate them even in a flat area.

The horizontal component of  $\Delta\Phi$  has very similar influence on the measured depth values as  $\Delta y$ . This correlation is not a problem in field calibration, since the vertical component of  $\Delta\Phi$  separates it from  $\Delta y$ .

Offsets in pitch and x have also very similar error patterns. Therefore, the two parameters are often highly correlated. Their separation depends on the relief of the seafloor. They can be separated if the seafloor has satisfactory depth variation.

Pitch, heading and x calibration require that the lines run in the direction of the terrain slope, whereas y and Y-scale calibration require terrain slope across the run direction.

Based on the geometric interpretation of the **Effect of offset** figure above, we can conclude that we need at least three calibration lines in order to compute all the parameters, i.e., two 100% overlapping lines for the computation of  $\Delta\Phi$ ,  $\Delta\omega$ ,  $\Delta x$  and  $\Delta y$ , and a third line for  $\Delta\kappa$ ,  $m_\phi$  and  $m_y$ .


Since the random measurement errors of the multibeam echo sounder and the relief of the seafloor have great impact on the accuracy of the parameters, calibration lines in addition to the minimum required will strengthen the calibration. For example, we can apply four, eight or twelve lines as illustrated in the **Configurations** figure below. How many lines to measure, depends on the relief of the seafloor, the period of time available for the calibration etc., but as a rule eight crossing lines is recommended. Eight crossing lines balance the requirement of accuracy and the cost of running the calibration lines.

#### **8.5.4 How to run SeaCal**

There are several ways to run SeaCal, but to get a safe and fast verification of the calibration parameters, the following procedure is recommended.

- 1 Apply eight crossing calibration lines as defined in the Configurations figure below.
- 2 Run the calibration with all parameters
- 3 Run the reliability computation
- 4 Introduce the calibration values with green reliability factor into the multibeam system
- 5 Run a new calibration to verify the new settings

*Figure 22 Different configurations of calibration lines*



### 8.5.5 Resolution

The resolution of the grid model applied in the calculation affects the computing time. The option `auto` asks SeaCal to compute the resolution, but you can also define the resolution manually.

### 8.5.6 Maximum number of iterations

Usually, SeaCal needs two or more iterations to compute the calibration. You can define the maximum number of iterations manually, or you select `auto`, i.e., SeaCal iterates until the solution is stable.

### 8.5.7 More on the field calibration method

A strength of our approach is that all the survey lines are utilized in an optimal way, i.e., survey lines which cannot determine a parameter, will have minor influence on the computation. For a thorough description of the method see [2].

Often the eccentricity of the transducer is measured by land surveying methods. Since our calibration method considers the horizontal offsets in x and y, it can control that the horizontal eccentricity values are loaded correctly into the multibeam system.

SeaCal computes calibration parameters based on least-squares adjustment as:

$$V = \left( A^T P_1 A \right)^{-1} A^T P_1 L_1 \quad (1.1)$$

where V is a vector of the unknown parameters, A a coefficient matrix, P<sub>1</sub> a weight matrix and L<sub>1</sub> a vector of observations.

Since the stability of the system of equations depends on the relief of the seafloor and the configuration of the calibration lines, restrictions are put on the unknown parameters by:

$$V = \left( A^T P_1 A + P_2 \right)^{-1} \left( A^T P_1 L_1 + P_2 L_2 \right) \quad (1.2)$$

where P<sub>2</sub> is a weight matrix of the unknown parameters and L<sub>2</sub> a vector of a priori parameter value.

The variance-covariance matrix of the unknowns are computed from:

$$Q_V = \left( A^T P_1 A + P_2 \right)^{-1} \quad (1.3)$$

Here, the diagonal elements define the variance of the parameters and the other elements their covariance. Therefore, the variance  $\sigma_{v_i}^2$  of parameter V<sub>i</sub> is derived as:

$$\sigma_{v_i}^2 = Q_{v_{ii}}$$

and the covariance  $\sigma_{v_i v_j}$  of the two parameters V<sub>i</sub> and V<sub>j</sub> is computed as:

$$\sigma_{v_i v_j} = Q_{v_{ij}}$$

The correlation coefficient  $\sigma_{v_i v_j}$  measures how separable two parameters V<sub>i</sub> and V<sub>j</sub> are and is derived from Q<sub>V</sub> as:

$$\rho_{v_i v_j} = \frac{\sigma_{v_i v_j}}{\sigma_{v_i} \sigma_{v_j}} \quad (1.4)$$

In multibeam echo sounder calibration we usually have limited knowledge of the stochastic properties of the observations. Therefore, the standard deviation of the parameters we compute

from (1.3), will be too optimistic. For this reason, we define a reliability factor  $R$  which measures the ability of the geometry to determine the calibration parameters.

The computation of  $R$  is done in a simulation procedure. In the first round the calibration  $V'$  is computed. Thereafter, the measurements are corrected according to vector  $\epsilon$  of offset values and a new calibration  $V''$  is computed with  $\epsilon$  as the start value of the computation. Ideally,  $V'$  and  $V''$  should be equal, but due to many error sources, the two may be different. The reliability factor for parameter  $v$  is computed as:

$$R = \begin{cases} 1 - \left| \frac{v' - v''}{\epsilon_v} \right| & \text{for } |v' - v''| < |\epsilon_v| \\ 0 & \text{Otherwise} \end{cases} \quad (1.5)$$

From the definition we recognize that  $R$  is defined on the interval  $[0,1]$ . Factor 1.0 means that the simulated offset is completely determined, but from the factor value considered, we cannot draw the conclusion that the parameter is computed with no uncertainty. The maximal factor value only tells us that we have a strong geometry. In general, we can say that for low values of the reliability factor we should supplement the configuration with additional calibration lines.

The interpretation of  $R$  must also consider the weight of the parameters. If  $R \approx 1$ , it may happen that the parameter is given high weight. This is the case if the parameter is to be fixed to its initial value.

The reliability test is very important since it gives a comprehensive control of the calibration. Generally, it is hard to prove that a computer program works as it should, but the reliability test covers both the implementation of the calibration procedure as well as the configuration of the calibration lines.

The calibration lines must follow straight lines, i.e., curved calibration lines are not allowed. The number and the length of the lines are limited by the amount of computer memory and the speed of the computer processor.

## 8.5.8 Bibliography

[1]

Jan Terje Bjørke. En metode for feltkalibrering av systemparametere i et multistråleekkolodd-system (Eng. A method for field calibration of system parameters in a multibeam echo sounder system. Norwegian patent no. 315766, Norwegian Patent Office, PO Box 8160 Dep. 0033, Oslo, Norway, 2004.

[2]

Jan Terje Bjørke. Optimal method for field calibration of multibeam echo sounders. Submitted IEEE Journal of Oceanic Engineering, 2004

## 8.6 SIS Objects

This section describes how to operate **SIS Objects**. **SIS Objects** is a tool for adding points, lines, images, text, polygons, video and html into the map in SIS.

### Related topics

- *Geographical – Display options* on page 170
- *Geographical – KSGPL edit mode* on page 182

### 8.6.1 How to use SIS Objects

#### Basic concepts

SIS Objects must be configured before use. You must define your object types first. An object type is based on one of the following basic types: line (2D), line (2.5D), i.e. depth contours, area (polygon), point (2D), point (3D), image, video or HTML.

From one of the basic types, you create a new object type with a name and a definition describing how that object type shall be drawn in the map. As an example, a new object type can be coastline, which will be based on line (2D), and it may be drawn as a solid green line two pixels wide.


Once all the object types have been defined, they can be written to a file. This file can then be imported later. This means that you only have to define your object types once, later you simply import them.

You can in the **Geographical view** use the **Option** button and select **KSGPL** in the left hand tree structure to turn on/off object types to display. you can turn on/off all objects or choose which types to see.

You can add, delete and select objects in the **Geographical view** by turning the **KSGPL** objects on, and then enabling the **K** button in the frame toolbar. The **K** button turns the **Geographical view** into **KSGPL** mode and allows you to edit the objects.

#### Starting SIS objects

**SIS Objects** is started from the **Tools** menu in SIS. Select **Tools→Custom...→Objects** The following window will appear:



**SIS Objects** will automatically try to connect to current active echo sounder and the **Geographical frame**. If depths or positions are not received from the echo sounder, the buttons **DPT** and **POS** to the lower left in above figure will be red, whilst they are green when depths and positions are received. Connection to the **Geographical frame** shown by red or green button labelled **SIS**. The **SIS** button is green when connection is established. It will go red if there is no activity in the **Geographical frame** for a while, but will turn green again as soon as the view changes.

**SIS Objects** uses a server application to talk to the **Geographical view**. This server must be running. The button **CNT** will be green when the server is alive and well, red when it's not. If the **CNT** button is red, restart **SIS Objects**.

### Adding objects

- 1 Select the **Geographical view**.
- 2 Click the **Option** button from the toolbar.
- 3 Select KSGPL in the left hand side tree structure.
- 4 Make sure that KSGPL is enabled.
- 5 Select the object types you want to see by checking the appropriate check boxes in the dialog on the right hand side.
- 6 Press the **K** button from the toolbar of the **Geographical frame** to add objects

This puts the **Geographical view** into **KSGPL** mode where you can edit objects.

- 7 Use **Right Mouse** button to pop up a menu in the **Geographical view** where you add line or point objects.
- 8 Use **Ctrl+Left Mouse** button to create the point or the line.
- 9 Press **Right Mouse** button to accept or cancel your point or line.

## Lines


Once the object is created **SIS Objects** dialog will appear. If you added a line, see procedure above. There you can select which line type you want your line to be, i.e. coastline, depth contour, dryfall etc. If you know you are going to be working with the same object type for some time, like when you are adding a lot of coastlines, you can check the button **Use this type as default for all new lines** and you will not see **SIS Objects** dialog again as it will assume that all lines are of the selected type.

If the line is a 2.5D line (i.e. depth contour), you can set the depth for the line in the text field.

Press **Apply** to accept the changes.

## Points

If you added a point, **SIS Objects** will look like this:



This works the same way as for lines.

- 1 Choose the point type you want to add
- 2 Make it the default for all later points if you want to add many points of the same type
- 3 Set the depth if the point type is 3D

The point type can always be **Text**. You may enter a text in the text field at the bottom of the dialog and that text will appear where you added the point in the **Geographical view**.

If the type is of **HTML** or **Video** type, the complete path to the HTML or video must be entered into the text field.

### Note

---


*Remember to put “ ” around if the path name contains spaces.*

---

Press **Apply** to accept the changes.

## Markers

You can use **Markers** if an echo sounder is attached and operational.



- 1 Select the tab named Markers and the above dialog will appear.
- 2 choose which **marker type** you want the marker to be.  
It can be any point type except for Text.

If the type is a 2D point, only the position will be used, 3D point types use the depth below the waterline to find the z value. All these markers store the time from the position together with the data so it is possible to later correct for tide, if necessary.

When you press **MARK NOW!** the current position and the current depth will be used to create an object of the selected type, and the object will appear in the Geographical view


## Info/Select

You can select object in the **Geographical View**.

- 1 Enable the **K** button.
- 2 Move the mouse over the object and press right mouse button.

The selected objects will be sent to **SIS Objects**.

You can then see the selected objects in the tab labelled **Info/Select**.



You may choose to delete the selected objects from this dialog.

### Import and export of objects

You can import objects from file by pressing **File→Read from file....** Then you select the file with the data and the objects will appear in **SIS Objects**.

Note that this requires some synchronization with the object types in the database. Also note that if you have added objects, they may be lost if the objects in the file have the same id as your objects.

Objects can be exported to file by pressing **File→Write to file....** You then choose the name of the file you want to write to.


### Additional information

Sometimes it may be necessary to resend all the object definitions to SIS. You do this by pressing **View→Update SIS with object types**. This is necessary if the object types do not appear in the **Option→KSGPL** list in the **Geographical View**.

## 8.6.2 Configuration of SIS Objects

In SIS Objects, select **View→Advanced settings** and two more tabs will appear.

## Settings




Here you can select the host where the database server is running. Note that this database is different from the one SIS uses.

The selected objects are always passed on to the host:port defined here.

If an object of video type is selected, the video file will be passed as the first argument to the video player application listed here. Note that “ ” are needed to avoid confusion with spaces in the filename.

Objects of HTML type are likewise sent to the HTML viewer listed here.

## Database




The tab named **Database** is where you define your object types.

- 1 Define the main object type in the menu **Select object type**.  
Choose from Line (2D), Line (2.5D), Area, Point 2D, Point 3D and Image.
- 2 Give the object type a name, e.g. Coastline, Manual Depth, etc.
- 3 Press the **KSGPL...** button to set the parameters for how to display objects of this type.
- 4 Press **OK** to save the object type.


**Different parameters which controls the display of object types:**

- Line (2D) and Line (2.5D)




Line type can be either solid or dotted. The colour can be chosen from a palette that appears when pressing Color....

- Area




Transparency sets the transparency of the area. The fill colour is chosen, and the line type, width and colour for the surrounding polygon are also set.

- **Point 2D and Point 3D**



The colour and the point size in pixels are defined for 2D and 3D points.

- **Image**




An image type is defined by which image it displays. Note that the file type is \*.sgi, i.e. Silicon Graphics File Format.

- Two more types, **HTML** and **Video** can also be defined. The KSGPL for these types is the same as for a 2D point.

Object types can be saved to file by pressing **Save object definitions to file...**. Then select the filename and the object definitions are stored.

Object types can be read from file by pressing **Read object definitions from file...**. Then select the file name and the object types are loaded into the database. Note that existing object types with the same name as one in the file, will be deleted and the definition in the file will be used.

It is also possible to delete and edit object types. Note that deleting an object type, automatically deletes all objects of that type as well.



Press **Delete** object type to delete the object type. Note that the objects will still be displayed in the Geographical View until SIS is restarted. Press **KSGPL** to change the way the object type is displayed; line type solid/dotted, line with, point type, etc.

### 8.6.3 Technical references

**SIS Objects** cannot be used if some other application is using KSGPL at the same time.

#### Selected object datagram format

When the operator selects an object in SIS GeoView, SIS Objects will send information about the selected object to the UDP host:port defined. The format is:

```
0 27 MyPoint 59.32114415 18.10475915 2008-04-11T15:01:08
```

- First item in the message is the basic type (see the database definition file below), then the database id, then the name of the type as defined by the operator. The rest is depended upon the basic type. For 0 above, the position (latitude in degrees and longitude in degrees) and time is given as shown.

```
1 6 Kaidybde 59.32112343 18.08118750 33.00000000 2008-04-11T09:29:29
```

- 3D points also have the depth after the position.

```
8 23 Nyheter "usatoday.com" 59.32681627 18.08416633
```

- HTML objects have the web-address before the position.

```
7 9 MyVideo "C:/12angrymen_trailer.mov" 59.32295218 18.08355627
```

- Video objects have the path to the video. Note that the directory separator is /, not \.

```
5 8 bilde 59.32028155 18.09755164
```

- An image

```
4 7 59.32223918 18.08571897 Survey this area with EM3002
```

- Text object

```
2 3 TopasTracline -999999.000000 2008-04-15T12:46:50 -9 -9 59.33072
```

- A 2D line has -999999.000000 as depth, and -9 -9 after the timestamp. The positions are latitude and longitude in degrees.

```
3 33 Dybdekurve 55.800000 2008-04-16T12:34:06 -9 -9 59.31115771 18
```

- A 2.5D line has a depth different from -999999.000000

Right before or right after a line/polygon object, this message is sent:

```
PICKED_POS 59.18845234 18.23549827 PICKED_POS_DONE
```

This message contains the exact position where the operator pressed the mouse when he selected the line. This can be used for accurate positioning within the selected line.

### 8.6.4 File formats

There are two file formats used by SIS Objects. The files are ascii XML files, and the XML format is defined using XML schemas, aka.xsd files.

These are the schema definitions:

- **Objects:** TBA
- **Object type definitions:** TBA
- **Database definition:** Here is the sql file used to define the database used by SIS Objects. The connection to the database is assumed to be an ODBC-connection named KSGPLDB where the database name is KSGPLDB. The user is KSGPL and the password is simrad0. If objects are added to the database outside of SIS Objects, i.e. by an external application, a datagram can be sent to force SIS Objects to redraw all objects so that also the new object can be seen. Then send this datagram on UDP to  
localhost:5688 \$KSSIS,8802\n\r

## 8.7 C-MAP CM-93/3

### Related topics

- *C-MAP detail level* on page 37
- *C-MAP – Licence administration* on page 304
- *Geographical – C-MAP manipulation mode* on page 183

### 8.7.1 What it does

The C-MAP CM-93/3 Professional is a global chart database intended for use on advanced electronic charting and navigation systems.

CM-93/3 supports all the new object classes and attributes defined by S-57 Ed. 3.0, as well as the S-57 data model and updating mechanism.

Note

---

*The information in this chapter originates from C-MAP technical documentation.*

---

### 8.7.2 Specification of minimum performance

The C-MAP CM-93/3 Software Development Kits (version 3.0) have been designed to allow manufacturers to implement the various C-MAP CM-93/3 chart databases into their navigation and land based systems. In order to ensure that the CM-93/3 cartography is used and displayed correctly within manufacturers systems, the Specification of Minimum Performance document to which we will run a system audit on completion of the software development.

### 8.7.3 C-MAP S-57 Verifier and CM-93/3 Compiler


#### Installation



The S-57 verifier and CM-93/3 compiler (hereafter called the compiler) is installed together with the software distributed by the manufacturer. When this software is installed you should ensure that the eToken (part number: CM-eToken-S57) is inserted into one of the available USB

sockets. This eToken is used to unlock the compiler and to license CM-93/3 charts. Once the software is installed clicking on the icon will start the compiler.

The compiler main screen looks approximately as follows:



### Using the compiler

Browse to the location of the stored S-57/3 charts in the left hand window (normally in an ENC\_ROOT directory), and enter the issuing Hydrographic Office at the top of the right hand window. The issuing Hydrographic Office code is always the same as the first two letters of the file name. For example a Norwegian ENC may read something like “NO2B0412.000” and therefore the issuing HO code is “NO”.

Enter the destination path for the compiled database. This should be an existing directory on the hard disk (for example C:\ENC).

Click on Execute to compile the S-57/3 charts to CM-93/3. If the S-57/3 is fully compliant with the IHO specification, the charts will be compiled into a local CM-93/3 database and automatically registered in the database administrator. They can then be viewed on the screen by either setting the ENC database as default or by opening the application and go to the Add Database option to add the recently imported S-57/3 into the current view.

During the verification phase it may become evident that the S-57 files being imported are not fully compliant with the S-57/3.1 specification. If this is the case then one or more warnings or errors will be displayed and the user will be given the choice

to CONTINUE (in which case the compiler will continue verification but not compile the database), to SKIP (the database will be compiled but may contain serious errors) or to CANCEL. In general warning messages will not stop the compilation process but errors may cause the database to be incorrect or even the system displaying them to crash.

## **8.7.4 The C-MAP Cartographic Service**

### **Overview**

The system that you are now using has the capability of using and displaying the latest C-MAP CM-93/3 worldwide vector chart database. These charts are fully compliant with the latest IHO S-57 3.1 specifications and, when using the CM-93/3 ENC database in an approved ECDIS, are considered equivalent to the navigational charts required by the SOLAS (Safety Of Life At Sea) convention.

In order to prepare the system for use with the C-MAP CM-93/3 database, there are a number of things that will first need to be carried out: -

### **Registration of the system at C-MAP Norway**

When a system is installed that has the capability to use the CM-93/3 database, it is required that an Aladdin eToken supplied by C-MAP is connected to the system (if the system has and supports USB). The eToken provides the system with a unique System ID that enables C-MAP to issue correct licenses. The actual System ID can be found on the eToken itself, on the back of the installation CD box or on a sticker placed on the equipment. This ID must be quoted on all chart orders, either by email (license@c-map.no) or by fax +47 51 46 47 01.

When a system does not have a USB port or does not have support for the eToken, a file called USER.USR will be automatically created during initial installation (normally in the Program Files\CM93v3 SDK directory). This file contains the Company ID and System ID assigned to the ECDIS/ECS system when it is installed. These ID's can be found on the back of the installation CD box or on a sticker placed on the equipment. This file must always be sent to C-MAP Norway by email (license@c-map.no) when installing the software. Licenses can only be generated once this file has been received and registered by C-MAP. It is important to note that the software may need to be reinstalled and reinitialised if the operating system or hardware is upgraded (see the troubleshooting section).

Please note that in some cases the manufacturer of the system will have already pre-registered the system by sending the USER.USR file to C-MAP.

If during installation you do not know your Company ID or System ID, please contact C-MAP Norway before continuing installation of the software.

### **Ordering charts**

A chart order may be sent together with the registration of the system as described above. It is essential that the required information is sent to C-MAP when ordering charts for a system. C-MAP has issued order forms specifying the information that is required, and contains vital information that will allow us to monitor and maintain your licenses throughout the lifetime of the system. Charts can be ordered by Zone, Area or Cell and these can be seen on Internet pages at [www.c-map.no](http://www.c-map.no) or by downloading the Chart Product Catalogue also available on the web site. Price quotations can be obtained via your chart dealer or direct from your local C-MAP office. Once the license order has been prepared it should be emailed to [license@c-map.no](mailto:license@c-map.no) or faxed to C-MAP Norway AS (+47 51 46 47 01).

### **Applying licenses**

Once the order has been received at C-MAP, a license will be generated and transmitted back to the user. This may be in the form of a single alphanumerical string (16 characters), or in the form of a file called PASSWORD.USR. Once this license has been received it should be input using the License Administrator software designed and supplied by the ECDIS/ECS manufacturer. There are two types of licenses, purchase and subscription. Purchase licenses are valid indefinitely while subscription licenses need to be renewed each 12 months from the start of the subscription. Failure to renew a subscription will result in the charts becoming unavailable.

### **Troubleshooting**

If you are having problems installing your software or charts please check the following before calling C-MAP: -

- You are installing on Windows NT, Windows 2000 or Windows 98 second edition. The system will not normally run under Windows 95 or Windows 98 first edition.
- That you have registered the WORLD database in the GDBADMIN application.
- That the registered WORLD database is available. If you are running the database from the CD drive, the CD-ROM must be loaded.
- That you have correctly typed the license string.

- That you have not reinstalled Windows or any major hardware components. If you have done this you will probably need to reinstall your software (only required for systems that are not using eToken).

### **Contact Information**

For information or help please call your nearest C-MAP Office (details can be found on the reverse side of the C-MAP chart CD box) or contact C-MAP Norway: -

C-MAP Norway AS  
Post Box 212 Hovlandsveien  
5243 79 Egersund Norway  
Tel: +47 51464700 Fax: +47  
51464701 [technical@c-map.no](mailto:technical@c-map.no)

## 8.8 Global event marker

The Global Event Marker system consists of two programs:

- One server that runs on an Operator Station (for example the HWS) connected to a multibeam echo sounder (EM) Processing Unit (PU)
- One or more clients on Windows PCs in the network

The Global Event Marker Handler (GEMH) needs two inputs; position datagrams from an EM PU, and events from Global Event Marker clients on the network.


Note that the position datagrams needed by GEMH must be subscribed to using the **Request datagrams from an echosounder** utility found in **Tools→Custom→Datagram distributions**. See *Request datagrams from an echo sounder* on page 442

Use the IP address of the GEMH HWS and a free port address. This port address must be used in the GEMH options setting (see below).

The PU will send position datagrams to GEMH even when the EM is not pinging.

GEMH will send events to other SIS installations on the network, including Helmsman Displays. The IP addresses of these installations must be set in GEMH.

GEMH will also send CS datagrams to single beam echo sounders (EA). CS datagrams are sent as broadcasts on the network, so only the UDP port must be set in GEMH.




All events are logged to a file, normally **events.ksgpl**. In the File menu you can open any file. When the file is opened, all events in that file is sent to all SIS installations.

You can also at any time resend all events to all SIS installations from the View menu.

The last event is displayed in the textfield together with the IP address of the sender.

Options in GEMH are found in the File menu. The first lines set the UDP port where events arrive. This port number must be the same as the port number in the file **Events.ini** used by the Global Event Marker clients (see below).



The Options dialog box contains the following settings:

Events are read from UDP port:	8212
Events are sent to IP (xxx.xxx.xxx.xxx:port,xxx.xxx.xxx.xxx:port):	127.0.0.1:4004
Read positions from UDP port	8771
CS datagrams to EA, broadcast UDP port:	10183
Reply to sender, broadcast UDP port	8989

Buttons: OK, Cancel

Events are sent to a list of SIS programs. The format of this list is xxx.xxx.xxx.xxx:nn,xxx.xxx.xxx.xxx:nn,...

xxx.xxx.xxx.xxx is the IP address and nn is the UDP port number, normally 4012. Remember to use a comma (,) to separate the addresses.

Positions are read from a UDP port. The port is the same as set when the position datagram subscription is defined (see above.)

EAs listen for CS datagrams on a port, normally 10183.

The last event is also sent as broadcast to all Global Event Marker Clients (GEM). All of them will then display the time the event arrived and the associated text.



The Event Generator dialog box contains the following elements:

- Event Text: A text input field.
- Received: A text input field.
- Create Event: A button.

The GEM can be installed on any Windows PC in the network. Simply copy the files Events.exe and Events.ini to a directory and run Events.exe from that directory. The file Events.ini can be used to set the parameters and texts for this window. Note that the IP address in Events.ini is the IP address of the PC running GEMH.

You can then send an event to GEMH simply by pressing the button. A text is optional and can be sent together with the event.

The last event on the network is displayed in the textfield below, together with the IP address of the sender and the time the event occurred.

## 8.9 PU simulator and playback

The PU Simulator is a replay program using logged raw data from EM multibeam echo sounders. The program is launched from the menu **Tools→Custom→PU Simulator**.

The PU Simulator is launched in the background and then waits for command signals.



The **PU Control** holds the following parameters:

- **Hostname** is the host name of the machine where simulator is running.
- By pressing the **Start** button a directory selection box is opened where you select the directory where the **.all** raw data files are located. This directory is written in the textfield next to the button.
- Press **Pause** to pause the output of datagrams from the selected raw data file.
- Press **Stop** to terminate the PU Simulator
- **Help** will open the online help
- **No looping**: This is required for replay of data with GKG positions. The date and time in the original datagram are then not replaced by current time during replay.
- **Reduce speed**: Choose between **None**, **Some**, **More** and **Most** to set the update rate of the play-back from as fast as possible (depending on your PC) to slower speed in order to be able to better identify data details. By default set to **None**.

The PU simulator will read all the **.all** files in the directory over and over again, and send out the datagrams as if they were sent from an EM echo sounder. However, there are some differences:

- The time in the header of all datagrams will be set to the current time in UTC. Also the time in the GGA text string in the position datagrams will be set to this time.


- The simulator will not broadcast datagrams to SIS before it has received the information about which directory to read from. Therefore SIS must be started after pressing **Start** in the simulator.
- Other data in the datagrams will not change. This means that the Numerical display in SIS will display the original time information from the datagrams.
- The PU Sensor status frame will not contain any information during play-back.
- The Installation parameters frame and the Runtime Parameters frame have no effect if the user tries to change any parameters.

### **Related operational procedures**

- *How to run the PU simulator* on page 164

## 8.10 Create terrain models from ASCII files

This tool can be used to create terrain models in SIS from ASCII files.



The format of the ASCII file is as the following example.

```
*** Neptune Ascii file from Kongsberg Simrad A/S ***
Survey name: EM710_Blucher_2005_02_23
Processing operator name: tp
Datum: WGS84
Half axis: 6378137.0000000
Flattening: 1/298.25722356300
Coordinate system: Lat/Long
Latitude min.: 59.66354720
Longitude min.: 10.59076500
Latitude max.: 59.70350375
Longitude max.: 10.62006250
Latitude cell size: 5.00 meter
Longitude cell size: 5.00 meter
Median depth of each cell

10.6148669 59.6635847 40.14
10.6149773 59.6635844 45.31
10.6150679 59.6635841 50.54
```

The first lines defines the header. The first empty line ends the header, and the header must always be present. This means that the data in latitude, longitude, depth must follow after an empty line. Latitude and longitude are in decimal degrees and the depth is in meters.

The file format can be created by Neptune (BinStat) to output geographic coordinates in ASCII format. Normally the median value for the grid cell is written in this format, which makes it faster to generate the grid in SIS. If the grid cell size in BinStat is e.g. 2 meters, 400 cm can be used as the grid cell size in SIS.

### Import grid to SIS parameters

The following parameters must be set to create a terrain model in SIS from ASCII files:

- **Select existing projection in directory...** opens up a directory selection box where the you can choose the projection file to use. This projection file must be located in the selected directory. Normally select the directory where the most recent survey is located. This will ensure that the projections are the same in the new survey and the created grid.
- **Grid size in meters** should normally be twice as big as the grid cell size in BinStat if median files are used
- **Number of cells in processing grid** should normally be the same as the number used in new surveys
- **Select grid output directory** selects the directory where to store the grid. Note that this directory must exist and be accessible for writing (common error on Linux).
- **Grid name** is the name of the grid
- **Select ascii input files** opens a file selection dialog where you can choose the files import
- **Remove files in list** removes the selected files from the list
- **OK** runs the process.

Note \_\_\_\_\_

*The GridEngine must be running for this program to work.*

---

Note \_\_\_\_\_

*If the process causes GridEngine to stop you may have to kill the Import from the process manager and restart the GridEngine.*

---

## 8.11 KSGPL

The **Kongsberg SIS Graphical Programming Language (KSGPL)** is a powerful extension to SIS allowing the user to display geographical information in the Geographical window.

### Related topics

- *Geographical – Display options* on page 170
- *Geographical – KSGPL edit mode* on page 182
- *Geographical – Load background data* on page 183

### 8.11.1 Overview

The KSGPL protocol defines a set of ASCII datagrams that are sent between a user programmed application and the Geographical window in SIS. The user application opens a network connection (UDP) to the Geographical window and writes ASCII text string to this connection. These KSGPL strings can be used to send lines, points and pictures to the Geographical window, and to define the position of an earlier defined object such as a ship. These objects will then be drawn in the Geographical window. A lot of attributes can be set by the operator and the user application to control these objects, both at the time they are sent to the Geographical window and afterwards.

You may edit objects sent to the Geographical window. You can split, join, add, delete and move lines, as well as add, delete and move points. The user's actions are sent back to the user application, which then can decide what to do next.

The user application is responsible for storing the data. This allows the programmer to decide where the data is stored, in a file or in any database system already in use. The user application can also decide to add its own user interface so that more information can be added to the objects added by the operator. KSGPL is used to add background data to the Geographical window. This background data can not be edited.

### 8.11.2 KSGPL language reference

The following datagrams are sent from the outside to the Geographical window.

```

OBJECT <id>
  POSITIONTYPE <GEO| SCREEN | RELATIVE>
  [TYPE <number>]
  [INFO <text>]
  [LINE [ [WIDTH <number>] [SOLID|DOTTED] [COLOR <number>]
    [TRANS <0-100>] ] <POS2D|POS3D> <positions>]
  [POLYGON [ [BORDERWIDTH <number>] [SOLIDBORDER|DOTTEDBORDER]
    [BORDERCOLOR <number>] [BODYCOLOR <number>]
    [SHOWBORDER|NOSHOWBORDER] [SHOWBODY|NOSHOWBODY]
    [trans <0-100>] ] <POS2D|POS3D> <positions>]
  [POINT [ [SIZE <size>] [COLOR <number>] [TRANS <0-100>] ]
    <POS2D|POS3D> <position>]
  [TEXT <text> [ [SIZE <number>] [COLOR <number>]
    [ORIENTATION <0.0-360-0>] [TRANS <0-100>] ] <POS2D|POS3D>
    <position>] [IMAGE <file> [ [GRAVITYPOINT<0-100> <0-100>]]
    <POS2D|POS3D> <position>]
OBJECT END
OBJECT <id> DELETE OBJECT _END

```

The two tables below show the internal datagram descriptions

Datagram	Description	Required
POSITIONTYPE <GEO>	Use geographical coordinates	Yes, either GEO, Screen or RELATIVE
POSITIONTYPE <SCREEN>	Centimeters on the screen (float) relative to the lower left corner of the Geographical window. This object will always stay in its position on the screen	
POSITIONTYPE <RELATIVE>	Meters relative to origo (0.0m, 0.0m) in the world	
INFO <text>	Name or description of this object	No
TYPE <number>	The id of the type this object belongs to	No
LINE [[WIDTH <number>]]	Width of the line in pixels	No. Default is 1.
LINE [[SOLID DOTTED]]	Solid or dotted line	No. Default is SOLID.
LINE [[COLOR <number>]]	Colour of the line	No. Default is black.
POLYGON [[BORDERWIDTH <number>]]	Width of the border in pixels	No. Default is 1.
POLYGON [[SOLIDBORDER DOTTEDBORDER]]	Solid or dotted border	No. Default is SOLIDBORDER.
POLYGON [[BORDERCOLOR <number>]]	Colour of the border	No. Default is black.
POLYGON [[BODYCOLOR <number>]]	Colour of the polygon border	No. Default is red.
POLYGON [[SHOWBORDER NOSHOWBORDER]]	Show the border or not	No. Default is SHOWBORDER
POLYGON [[SHOWBODY NOSHOWBODY]]	Show the body of the polygon or not	No. Default is NOSHOWBODY.
POINT [[SIZE <number>]]	Size of the point in pixels	No. Default is 1.

Datagram	Description	Required
POINT [[COLOR <number>]]	Colour of the point	No. Default is red.
TEXT [[SIZE <number>]]*	Font size	No. Default is 9.
TEXT [[COLOR <number>]]	Colour of the text	No. Default is red.
TEXT [[ORIENTATION<0.0—360.0>]] *	Orientation of the screen aligned text in degrees. Positive value is counter clockwise	No. Default is horizontally aligned
IMAGE [[GRAVITYPOINT <0–100> <0–100>]] *	Gravity point of the picture in percent (i.e. where on the picture the coordinate is given). Horizontal and vertical values	No. Default is lower left corner.

Datagram common for all objects	Description	Required
OBJECT <id>	A unique identifier. The old object will be deleted if the corresponding identifier already exists in the system.	Yes.
<TYPE> <id>	What kind of type this object is.	No
<POS2D POS3D> <position>	Position(s) of the object. POS2D = (x,y) POS3D = (x,y,z)	Yes
[[TRANS <0–100>]]	Transparency of the object.	No, Default is 0. (No transparency at all.) The polygon border will not be affected by the transparency setting.  <b>Note</b> _____ <i>Transparency is disabled for images.</i>
OBJECT_END	Datagram end.	Yes

Note \_\_\_\_\_

\* — *Not yet supported.*

If the object sent into the system is missing required fields, the object is disregarded. No output is given.

An object has always an identifier that must be unique within the application. If an object with the same id exists in the Geographical window, that object is deleted (no message given as output) and the new object is put in. The object may consist of one or more instances of lines, polygons, points, texts and images.

A position has either two or three floating-point numbers and is enclosed in parentheses like: (1.1 2.2 3.3). Comma and semi-colon may be used to separate the tokens, i.e.: (1.1;2.2;3.3;t) to make the file more readable.

An object may be of a type. Object without types will be entered into the system in a default container. An object of a nonexistent type (if given) will be ignored.

Objects may be deleted from the Geographical window by the DELETE datagram. The corresponding id will be deleted.

### 8.11.3 KSGPL output from the Geographical window

The Geographical window will have line and point editing capabilities on objects that consists of one line only or one point only. Composite objects consisting of several lines and/or points cannot be edited. When the user has edited data that have been put in via KSGPL, the Geographical window will output these KSGPL datagrams:

```
ACK <status> ACK_END
OBJECT <id>
MARKED OBJECT_END
OBJECT <id> MARKED OBJECT_END
OBJECT <id> DELETED OBJECT_END
OBJECT <id> CREATED OTYPE <type_id> POINT <POS2DT|POS3DT> <position>
OBJECT_END
OBJECT <id> CREATED OTYPE <type_id> LINE <POS2DT|POS3DT><positions>
OBJECT_END
OBJECT <id> EDITED POINT <POS2DT|POS3DT> <position> OBJECT_END
OBJECT <id> EDITED LINE <POS2DT|POS3DT> <positions> OBJECT_END
OBJECT <id> JOINED_LINES <second_line_id> <POS2D|POS3D>
<positions> <POS2D|POS3D> <positions> OBJECT_END
OBJECT <id> SPLIT_LINES <POS2D|POS3D> <positions>
<POS2D1POS3D> <positions> OBJECT_END
```

The table below shows the external datagram descriptions:

Datagram	Description
ACK <status> ACK_END	An acknowledge message sent whenever a datagram has been received by the Internal KSGPL Handler. 'status' is an integer informing about status of the datagram just received.  – 1 = Datagram failed to be recognized 0 = Reserved 1 = Datagram successfully recognized
OBJECT <id>	A unique identifier. This will be 0 for new (CREATED) objects
POS2D <position(s)> POS3D <position(s)> POS2DT <position(s)> POS3DT <position(s)>	Position(s) of the object: POS2D = (x,y) POS3D = (x,y,z) POS2DT = (x,y,t) POS3DT = (x,y,z,t)

MARKED	The object has been marked by the user. No changes are done to the graphics. The External KSGPL Handler can now take proper customized action(s).
DELETED	The object has been deleted by the user and removed from the scene.
CREATED OTYPE <type_id> <POINT LINE>	The user has created a new point or line of a given type. The object has been removed from the scene.
EDITED POINT LINE	The user has edited the given point or line. The object has been removed from the scene.
JOINED LINES <second_line_id> <POS2D POS3D> <positions_of_line_one> <POS2D POS3D> <positions_of_line_two>	The user has joined two lines into one. The preceding OBJECT <id> is the ID of the first line. <second_line> is the ID of the second line. The lines are connected together between the last vertex in the first line and the first vertex in the second line.
SPLIT_LINE <POS2D POS3D> <positions_of_line_one> <POS2D POS3D> <positions_of_line_two>	The user has split an existing line into two line segments. The preceding OBJECT <id> is the ID of the original line before being split.  <b>Note</b>  <i>The user has removed one vertex in the original line (and not only deleted a sub line segment).</i>
OBJECT_END	Datagram end.

A position has either two or three floating-point numbers and a time field enclosed in parentheses like: (1.1 2.2 3.3). POS2DT or POS3DT positions also have a time field 't' which is given in the format: yyyyMMddhhmmSS.sss (year, month, day, hour, minute, seconds and decimal seconds.) POS2DT or POS3DT are only used when the user has EDITED or CREATED something in the scene. If the user has EDITED e.g. an existing POS2D line by moving one of the vertices, the unmoved vertices will have the time field set to '00000000000000.000' when sent out. POS3D(T) are only sent if the original object was inserted into the system using POS3D coordinates. Respectively the same with POS2D(T).

Objects are assumed to be sent to an external program and deleted from the Geographical window as soon as they are CREATED or EDITED and then sent back to the Geographical window. After that, line objects may be split (SPLIT\_LINES) or joined (JOINED\_LINES). These operations are then only allowed on lines that have been put into the Geographical window from an external source

Selected objects remain in the Geographical window, but CREATED, EDITED, JOINED\_LINES and SPLIT\_LINE are deleted from the Geographical window when these datagrams have been written to socket. It is assumed that the receiving program will handle the necessary storage of the changed items

and then send them back to the Geographical window to be redrawn in a new state. This will assure the user that the data have been successfully stored.


For an edited line or point the position(s) are the new, changed position(s). A line may also get new vertices inserted into the line (both at the ends of the line and between vertices in the line) and have vertices deleted. The output will be written when the user has completed the editing of the line, not while he is editing.

New objects will have id=0. For a split line the id will be the id of the original line.

## 8.12 How to use SIS on an AUV/ROV

This section explains how to use SIS on an Autonomous Underwater Vehicle (AUV) or on a Remotely Operated Vehicle (ROV), where an EM 2000/EM 3000 echo sounder is installed.

The EM 2000/EM 3000 on board an AUV is controlled via Ethernet communication as indicated in figure below. When SIS starts up, it will search for all echo sounders on the network, and the EM 2000 or EM 3000 will broadcast its existence, detected by the SIS.



### How to set up the EM 2000/EM 3000 on the AUV from SIS

- 1 Attach the internal disk in the EM 2000 / EM 3000.  
Refer to document “Datagram Formats” (reg. no. 850-164602) under PU Setup Command, on how to do this.
- 2 Open SIS
- 3 Open the **Installation Parameters**
- 4 Enable PU logging to local disk as described in *How to enable PU logging to local disk* on page 372
- 5 Set PU parameters as described in *Default or current settings at PU startup* on page 373
- 6 In Installation Parameters there are four UDP port numbers, labelled UDP 1-4. When using EM 2000/EM 3000 logging to internal disk, UDP4 is renamed to PU Logging. Note the UDP port number in use by UDP2; this is the port number where the third party software shall listen for data.
- 7 Shut down SIS
- 8 Restart the EM 2000/EM 3000

When the EM 2000/EM 3000 is powered on again, it will start with the installation parameters set. Datagrams will be sent to the UDP ports as defined, and any software can be used to read these datagrams.


- 9 Send datagram P10 to port 2012 to the PU To turn logging on

The P10 datagram is described in the document “Datagram Formats” (reg. no. 850-164602) under Remote control command to PU.

- 10 Send P02 to stop logging.

In the figure below it is shown how the EM 2000 is set up after above procedure has been carried out. P10 and P02 control datagrams are used to start and stop the logging to disk.

*Figure 23 How the EM 2000 on and AUV/ROV is set up*



### How to enable PU logging to local disk

Note

---

*This feature is only available for EM 2000 and EM 3000.*

---

- 1 The SIS user can turn logging on and off by using a simple tick button in the **Installation parameters**→**Output Setup** frame. When this tick button is set, the **Host UDP4** port entry in the **UDP Host Port** combo box is substituted with a **PU Logging** port. By selecting the **PU Logging** port it is possible to select which datagrams to log to the PU hard disk. Initially a default datagram selection is presented, but it is modifiable as indicated.
- 2 When PU logging is set the port number displayed is 2999. This is just a dummy number signifying that the PU is logging to disk.

- 3 The selected PU logging setup is activated (i.e. PU logging turned on or off) when the **OK** button is pressed.

Note \_\_\_\_\_

*When the PU is logging to disk it will not send ANY datagrams out on the Host UDP4 port.*

*When the PU logging feature is turned off (i.e. tick button deselected) the normally configured settings for Host UDP4 will be used again. Remember to press the **OK** button to activate the new setting.*

---

### **Default or current settings at PU startup**

Note \_\_\_\_\_

*This feature is only available for EM 2000 and EM 3000.*

---

When the PU is turned on, this feature will enable the PU to use a standard (factory) parameter setup or a setup previously configured and installed in the PU by SIS.

In the latter case the PU may subsequently be started independently, without SIS connected. This capability will allow an AUV/ROV operator to use SIS to initialize the PU with a specific setup before disconnecting SIS and launching the AUV/ROV into the water.

You can control this feature by a radio buttons found in the Installation parameters, ROV Specific frame: **Installation Parametes→Sensor Setup→ROV Specific**. The radio buttons are labelled **Use default settings at PU startup** and **Use current settings at PU startup** respectively.

The procedure for setting the PU to use the current parameter setting is as follows:

- 1 The PU must have been started by SIS
- 2 Configure the required installation and runtime parameters as required using the normal configuration procedure

Note \_\_\_\_\_

*Make sure to press the **OK** button in the **Installation Parameters** frame.*

---

- 3 In the Installation parameters, ROV Specific frame press the **Use current settings at PU startup** radio button.

The PU is now configured and the current setting stored for use when the PU is turned on again.

### **How to set the PU to use default parameters**

The procedure for setting the PU to use the default (factory) parameter setting is as follows:

- 1 The PU must have been started by SIS
- 2 In the **Installation parameters**→**ROV Specific** frame press the **Use default settings at PU startup** radio button

The PU will now use the default (factory) settings when it is turned on the next time and it will normally require that SIS is connected to initialize and control it.

---

#### **Note**

*When the radio buttons are pressed a signal is sent directly to the PU without the need to press the OK button (as for normal installation parameters). Therefore, when the **Use current settings at PU startup** radio button is pressed the required setup must already be present in the PU using the procedure above.*

---

#### **Note**

*Note that after the **Use current settings at PU startup** radio button has been pressed, the PU parameter setup at that time is remembered and used during next startup. If further installations and runtime configurations are performed, without pressing the radio buttons, the changed configuration will be used until the PU is turned off and on again.*

---

### **Fetch and delete data from the internal harddisk**

FTP can be used to fetch and delete data from the internal hard disk, or replace the disk with another and insert it in another PC to read the data.

## 8.13 CUBE

The CUBE (Combined Uncertainty and Bathymetry Estimator) algorithm is developed at The Centre for Coastal and Ocean Mapping (C-COM)/Joint Hydrographic Centre (JHC) at University of New Hampshire. The algorithm is available as a library and is used inside a separate module in SIS. The CUBE algorithm can be used as an alternative data gridding and data cleaning method in SIS. The gridding and data cleaning is a default process done by the GridEngine.

### Related topics

- *Create CUBE grid* on page 292

### 8.13.1 About the implementation of CUBE in SIS

CUBE is not available when logging data. CUBE grids are created by importing raw data files in the Kongsberg Maritime .all-format. Already gridded surveys can be reimported at a later time.

The CUBE module in SIS receives ping data on UDP where depth and angle gate are applied to the data. The horizontal and vertical error estimate for each beam is calculated using the Kongsberg Maritime error model and not the error models included in CUBE. The default processing parameters for the CUBE algorithm are used.

The GridEngine holds both a processing grid and a display grid. The display grid is split up in six levels of details, LODs, to speed up the display in the geographical view when features as automatic update or ship in centre are turned on. In CUBE it is the processing grid that is displayed and an automatic update or ship in centre can give slow response when updating the geographical view.

The implementation of LOD in the GridEngine also results in less sensitivity to the grid cell size when displaying grids - see the next four figures. With a small grid cell size a lot of nodes get no depth value assigned.

SIS must chose between either GridEngine or CUBE grids. This selection is done from the **Tools→Custom→Set parameters→Logging** menu.

Figure 24 GridEngine, LOD3




Figure 25 GridEngine, LOD1




Figure 26 CUBE, grid cell size 10 m





Figure 27 CUBE, grid cell size 2.5 m



CUBE also need some amount of data density to do the gridding. The grid in the next figure is from one survey line. The grid width is measured to 19 metres. With one more survey line the same distance is measured to 32 metres.

Figure 28 Grid width 19 m





Figure 29 Grid width 32 m



In SIS only depth are extracted from the CUBE processed data. In addition to the depth, CUBE can return uncertainty, number of hypothesis and hypothesis strength in each grid node.

### 8.13.2 User interface differences when CUBE is used

Only the differences in the user interface between CUBE and the GridEngine is treated hereafter.

#### Import raw data

Please refer to *Import/Export* on page 278 for details.

The parameters for the gridding is entered in the window at the bottom of the **File→Import/Export...→Raw Data Files** user interface.

Figure 30 Raw data import - CUBE parameters

The screenshot shows a window titled "Cube parameters". Inside, there are several input fields with labels to their left and units to their right:

- Depth variable:** A dropdown menu with "Z" selected.
- Origin North:** A text box followed by "deg.decimal degree".
- Origin East:** A text box followed by "deg.decimal degree".
- Width:** A text box followed by "km".
- Height:** A text box followed by "km".
- Grid cell size:** A text box followed by "meter".

CUBE needs to know the geographical coordinates of the survey area before any processing can start. The centre location for the grid width, height and cell size must be given. Western or southern values have to be entered as a negative value.

A large survey area requires a coarser grid cell size. You are notified if the grid size is too small for the requested survey area. In that case the grid size has to be increased or the survey area has to be reduced.

#### Export CUBE Survey data

GridEngine surveys can be exported to ASCII-files, which can be imported in Neptune. This feature is not supported for CUBE generated grids.

The CUBE grids are however stored as GUTM-files on disc.

See

<http://www.ccom.unh.edu/vislabs/GeoZui3D/FileFormats.html#GUTM>

for a specification for the file format.

Figure 31 CUBE Export options





Figure 32 GridEngine Export options





### CUBE Geographical window

The **Geographical** window in CUBE mode differs slightly from that of the GridEngine mode. Instead of the Option button as used in GridEngine mode, the Geographical options in CUBE mode are set using the **Show/Hide** button.

The main menu in CUBE mode also holds a **Geographical menu** which is not found when in GridEngine mode.

The **Show/Hide** button together with the **Geographical menu** in CUBE mode give the same options as found in the **Geographical Option** button in GridEngine mode. However, CUBE holds less options as fewer features are supported.

#### Show/Hide button



#### Geographical menu

The Geographical menu holds the following parameters:

- **Light Source:** To set the light source for the geographical display
- **Grid:** To set parameters for how to present the CUBE grid, i.e.
  - Drawstyle (points, triangles, filled, text and text overlay)
  - Shading (on/off)
  - Triangulation (centre or true point)
  - Smoothing (Level 0 to Level 3)

#### Level of detail

The GridEngine has six **Levels Of Details, LOD**, in its display grid. For CUBE only the processing grid is available for display and the choice is removed from the user interface.

#### Dynamic colors

For CUBE grids, only depth can be used as a colour map for the **dynamic colours**.

#### **Related topics**

- *Geographical view* on page 52
- *Main menu* on page 91

#### **Other functions not supported by CUBE**

##### Calibration

This is not available when using CUBE. The GridEngine must be run to calibrate the echo sounder.

##### Projection

CUBE grids in SIS can only hold UTM projected data.

#### **Related topics**

- *Calibration view* on page 88
- *Projection and datum parameters* on page 308

## 9 TECHNICAL REFERENCES

This chapter provides basic reference information useful to understand settings and parameters used throughout the SIS system. The chapter is intended for users who would like a deeper knowledge of the technical background for and the data flow inside SIS.


### Topics

- *SIS architecture* on page 384
- *Real time data cleaning* on page 389
- *The vessel coordinate system* on page 393
- *Timing* on page 395
- *Sound speed formulas* on page 399
- *Implementation of absorption coefficients* on page 401
- *Artefacts causing errors and variations in the sea floor depth detections* on page 407
- *The absorption coefficient equation* on page 410
- *Projections* on page 411
- *Geoid* on page 414
- *Tide* on page 417
- *Javad and Trimble details* on page 419
- *Dead reckoning and position jump filter* on page 424

## 9.1 SIS architecture

### 9.1.1 SIS processes

Figure 33 SIS main architecture



SIS contains six main processes. This is the start-up sequence:

- 1 The GUI is the main application, and is started first.
- 2 The CCU is started by the GUI. When the EM Processing Unit power is turned on it starts broadcasting messages on the network. The CCU will pick up these messages and display the EM availability in a list in the main GUI.
- 3 The operator chooses which echo sounders to start from the list in the main GUI.
- 4 The CCU will be informed which echo sounders to start, and then launch one DDS and one HDDS for each of the echo sounders.
  - The DDS reads datagrams received from the Processing Unit sockets and stores them as raw data on disk
  - The HDDS reads raw data from disk and generates xyz data that is sent to the GridEngine
- 5 The GridEngine receives xyz-data from the HDDS and generates a real time terrain model
- 6 The main GUI with the Geographical Display will now receive xyz-points from all echo sounders, and it will request the GridEngine for a terrain model to display.

### 9.1.2 Main GUI (Graphical User Interface)

The main application is called SIS and it contains the main graphical user interface (GUI).

There are three main tasks for the Main GUI:

- 1 To display the terrain model with quality information and provide a geographical view of the surveyed data
- 2 To display status information about the echo sounder
- 3 To control the echo sounder

### **Display and quality information in the Geographical view**

The Geographical window gets xyz-data from the HDDS process. It will then display all these xyz-depths as they appear, but only the last pings will be shown. They will appear as a tail of soundings behind the ship.

The Geographical window also reads the terrain model generated by the GridEngine. The GridEngine contains five depth values for each observed depth. The user can choose which reference level to display.

The GridEngine also generates several levels of display detail, making it possible for the Geographical window to always display the most suitable level of details based on the current scale.

#### **Note**

---

*The HDDS process reads data from the disk, meaning that the data displayed by Geographical window is just a subset of the raw data that remains safely stored on disk by the DDS process.*

---

### **Status of the echo sounder**

The Status windows get data directly from the echo sounders. This means that Status windows such as the Beam intensity window and Sound speed profile window all get the data directly. Hence the Status windows will be active when the echo sounder is active, and can always be used to monitor the current status of the echo sounder.

### **Controlling the echo sounder**

Controlling and setting up the echo sounder is done by the Installation parameter window and the Runtime parameter window. Also Pinging, Logging and Line Counting will invoke the control of the echo sounder. Messages are not sent from the main GUI directly, but to the CCU process. The CCU is then responsible for sending the messages to the right echo sounder (remember that the CCU can control several echo sounders). See *CCU (Central Command Unit)* on page 386.

Messages concerning the system operation (errors, warnings, information) are stored in SISDB, and the main GUI provides a window where you can see all messages as they appear.

### 9.1.3 CCU (Central Command Unit)

The CCU process is responsible for detecting all echo sounders on the network, and to make sure that the communication is established between the different processes. Also, if a new echo sounder is found during rescan, the GUI will be informed.

### 9.1.4 DDS (Data Distribution System)

The DDS process is responsible for logging all the datagrams sent by the echo sounder. The CCU will tell the DDS where to store the data (complete filename). The DDS can also distribute datagrams to other processes on the network, both to SIS processes and to external processes. In SISDB you can define what datagrams to receive from the DDS process, and when to receive them (every time they come or with a certain time interval between).

### 9.1.5 HDDS (Handle Data Distribution System)

The HDDS process is informed by the CCU process where the DDS process stores its files. The HDDS will read the raw data files and create xyz-data. For every depth observation the HDDS process will try to generate five depth types:

- Z: Depth, sea surface to seafloor distance
- Zt: Tide file corrected depth, vertical datum to seafloor distance
- Zv: Geoid and RTK corrected depth, vertical datum to seafloor distance
- Zg: Seafloor to geoid distance
- Zr: Seafloor to ellipsoid distance
- The depth measured by the echo sounder (waterline to seabed).

#### Note

---

*If a tide file is available, look up the tide in that file and create a tide corrected depth.*

*If heights are available from a Real Time Kinematic GPS, and a geoid model is available, then the distance from the vertical reference to the sea floor will be generated. In addition, the distance from the sea floor to the geoid and the distance from the sea floor to the ellipsoid will be generated.*

---

These depths will be sent to the GridEngine.

The HDDS will also read all the sidescan data from the echo sounder and make geo-referenced sidescan data (x, y, reflectivity). This is also sent to the GridEngine.

The HDDS process will do wild point editing of the positions (removing position jumps). Every position is converted from geographical coordinates to projection coordinates before it is sent to the GridEngine.

### **9.1.6 GridEngine**

The GridEngine will receive data from both single beam echo sounders (EA) and multibeam echo sounders (EM). The data format is different in these cases. EA data is strictly xyz. This makes it possible for the GridEngine to read many kinds of xyz-data, and they may be from different sources such as ASCII-files. EM data is five depths for each measured depth, and optional sidescan data.

The GridEngine uses two different grids, one called Processing grid and the other is called Display grid. The Processing grid has a user defined resolution of its grid cells, and the user must define how many cells to keep in memory at one time. This is done by specifying the number of grid cells in x and y direction for the Processing grid. A maximum of four Processing grids can be stored in memory at any time.

The Processing grid will contain a lot of data: all the xyz-points and every xyz consists of five z-values. It will also contain all the sidescan data for all lines in that area, and it will keep track of which lines having data inside the area.

The Display grid is what the user actually sees. The Display grid is organized in a hierarchical tree structure called levels. The grid cell size of Level 0 of the Display grid is the same as the grid cell size of the Processing grid, so Level 0 Display grid will display everything from the Processing grid.

Level 1 in the Display grid is computed from four grid cells of Level 0, Level 2 is created from four cells of Level 1 and so on. All this is taken care of by the GridEngine.

The Processing grid is used in the Real Time Data Cleaning module, and the result is an updated Display grid. The Geographical window will calculate the maximum resolution necessary to display the data, based on the current map scale selected by the operator. In a very large scale (close view) Level 0 will be used, whilst in a smaller scale a higher Level of Detail will be used.

This means that the Geographical window will display only the necessary amount of data at any time, which again means that the rendering will be faster. The zoom and pan operations will also benefit, as the Geographical window will always get a pre-processed dataset to display.

The GridEngine is written entirely in Java and is run as a servlet inside the Jetty web server.

### **9.1.7 SISDB**

To store parameter settings used in SIS a database called SISDB is created. The database server is PostgreSQL. Logged data is not stored in the database, only parameters settings and system messages.


This makes it possible to exchange data between different applications that use database, and to use standard applications and tools to browse the contents of the database.

## 9.2 Real time data cleaning

When data arrives the GridEngine, it may be cleaned in real time. Depths may be flagged out, but never deleted. Their status can always be changed if necessary. The Real Time Data Cleaning (RTDC) module operates in two steps:

- 1 As the data arrives, it will be organized as pings in an array. Then some processing will be carried out to these pings in the array. This is known as Line Based Data Cleaning (LBDC) because the processing only looks at data from current line. LBDC is not sufficient for proper data cleaning because errors caused by i.e. sound speed profiles will not be found. However, LBDC can be used for flagging out gross errors (spikes).
- 2 After LBDC the data will be put into the Processing grid. If you later return to the same survey area, the data from the previous lines will be read back and reprocessed together with the new data. This is called Area Based Data Cleaning (ABDC) because all data from the same area is processed together. ABDC makes it possible to find errors in e.g. sound speed profiles and installation angles.


Before starting the ABDC routine, the GridEngine will try to split and merge the processing cells into Cell Processing Units, which is used to create a surface. If a processing grid cell has very few points, it will be tried to merging it with its neighbour cells to create a bigger area with enough points. If there are too many points, the cell is split. The figure below shows examples of cells that are empty and cells that contain enough points. On the edge of the processing area there are some cells with too few points to do a good processing. The user can choose to automatically delete all points inside such cells.

*Figure 34 Process grid split into processing units*

The first thing to do in ABDC is to create a most likely reference surface in each processing unit. Traditionally this has been simply the mean depth value for the cell which means that the reference surface always will be a flat surface. In SIS the GridEngine constructs a much more reliable surface that will model the terrain much better. The surface is curved and constructed by using a first, second or third degree polynomial.

The method used to construct the reference surface is called Iterated Reweighted Least Squares (IRLS). The surface is created to be as close as possible to most of the points (best fit).

Figure 35 Best fit surface




Each point is initially considered to be equally important. The algorithm assigns a weight to each point. All points get the same weight. Then a polynomial surface is created. The distance from each depth to this surface is called the residual. Then the sum of all the residuals is calculated. Since all points have the same weight, this sum is only the sum of the residuals.

Now the Tukey estimator kicks in. Rather than giving each point the same weight, each point gets a new weight based on how far away from the surface it is. Points far away from the surface get lower weight than the ones close to the surface. The parameter Tukey constant controls how fast points lose their weight. Below are some examples.

Note that the “r” in the figure below is the median residue in the Cell Processing Unit. As the “c” (Tukey constant) changes, the curve gets broader as “c” increases and narrower as “c” decreases. This means that points lose weight faster when the Tukey constant is small. The effect of losing weight fast is that points are not used in the construction of the surface the next time the algorithm is run.

Figure 36 Tukey algorithm



This algorithm will run several times and every time new weights are given to each point. There are two ways this algorithm will stop; Either it has tried Max. iteration of time to create a surface, or the change from previous run is very small. If this happens, the algorithm is said to converge, which means that the best possible result has been found. The parameter Conv. criterion controls when the algorithm converges.

To summarize, the algorithm for the Iterated Reweighted Least Squares (IRLS) method is given as follows:

- 1 Start with equal weights for all points
- 2 Loop until convergence or maximum iterations
  - a Fit the surface using weighted least squares
  - b Calculate residuals
  - c Check for convergence
  - d Adjust the Tukey estimator
  - e Evaluate new weights

When the polynomial surface has been successfully created, various rules can be applied to flag out depths.

### Related topics


- *Data cleaning* on page 253

### 9.3 The vessel coordinate system

In order to relate the GPS antenna position to the seabed observations SIS needs to know the relative positions of the various sensors in use. This includes position sensors, attitude sensors and transducer heads.

The location of each sensor must be referred to a chosen reference point for the vessel. A cartesian right-handed coordinate system - as shown in the figure below - must be defined with its origin in the reference point. The location of this reference point has no physical significance - it may be anywhere on the vessel. The placement of the various instruments must be identified with forward, starboard and downward coordinates in this coordinate system.


*Figure 37 The vessel coordinate system*



- A Downward position** is defined on the Z-axis (refer to the illustration above). Locations below the reference point are positive
- B Starboard position:** If a sensor location is on the starboard side of the reference point, the Y value will be positive.
- C Forward position** is defined on the X-axis (refer to the illustration below). Locations further forward than the reference point are positive.

The forward axis (X) must be parallel to the vessel keel, and the downward axis (Z) must be vertical when the vessel is trimmed normally. The plane defined by the forward and starboard axes will then be horizontal, and the attitude sensor should then, if properly installed and calibrated, measure zero roll and pitch with a normally trimmed vessel lying still.

Figure 38 Example of sensor locations



- A Transducer (+Z, +X)
- B Motion sensor (-X, -Z)
- C GPS antenna (-Z, -X)
- D Draft (-Z)
- E Waterline (-Z)
- F Reference point

## 9.4 Timing

### Topics

- *Introduction* on page 395
- *Internal clock* on page 395
- *Time stamping* on page 396
- *Time difference PU-ZDA and PU-POS indications* on page 397

### 9.4.1 Introduction

Time synchronization between the echo sounder, the motion sensors and the positioning system is vital in order to achieve the best possible accuracy. The requirement for time synchronization accuracy is better than 5 ms for attitude, with roll being the most critical parameter. For the positioning, the required timing accuracy depends upon required position accuracy and the vessel's speed.

Example: With a vessel speed of 10 knots or 5 m/s, 100 ms timing accuracy is required for 0.5 m position accuracy.

### 9.4.2 Internal clock

An internal clock in the PU is used to time stamp all time critical data. It is a software clock with 1 millisecond resolution, and it is synchronized to an internal hardware counter. An interrupt is generated in the PU at each ping as a reference for the time of ping, and the clock is read at the reception of external sensor data. The internal clock is stable and jitter free, excepting a long-term drift of the hardware counter (typically a few seconds per 24 hours), and possible 1-2 millisecond jumps due to the internal counter not operating at exactly 1 kHz.

The software clock may be synchronized to an external 1PPS (one pulse per second) signal. This signal is normally available from a GPS receiver, and this is the preferred method to synchronize the echo sounder to an external clock. At the reception of a 1PPS pulse the millisecond field of the internal clock is set to zero. If it was larger than 200 ms, the second is incremented (with a possible incrementation of time and date if required). Note that this method of synchronization implies that loss of a few 1PPS pulses has no significance. However, spurious noise recognized as 1PPS pulses will offset the clock forward, 1 second for every spurious signal accepted.

The internal clock's time and date is adjustable to that given by an external clock, the positioning system or the operator station. However, this is only possible if the system is not logging data. Adjustment of the internal clock during data logging is not allowed as it would cause loss of synchronization between depth and attitude data.

If an external clock is connected on a serial line the input data is time stamped and logged as any other external sensor data. This allows a continuous estimation of any drifts between the two clocks. The setting of the internal clock will be to the time and date from the source, including milliseconds as available. Note that the GGA positioning datagram does not contain any date entry. Setting from the operator station allows a manual setting of the clock.

### **9.4.3 Time stamping**

For each datagram of attitudes (roll, pitch, heave and possibly heading), a time stamp is generated at the reception of the first byte of the datagram. As the attitude data may be delayed due to processing time in the motion sensor, an adjustable time delay may be applied. The attitude data are applied to the acquired ranges and beam angles to derive xyz coordinates of the soundings after bottom detection.

The only significant uncertainty in the time synchronization of attitude and depths will thus be due to possible variations in the time delay or a wrong estimation of it. However, with most motion sensors the risk of errors are small. The manufacturer's estimate of delay should be used, and a possible prediction facility in the sensor should not be used. As the attitude data may be logged as a continuous time record, it is possible to post process the data to determine and correct for any error in applied time delay.

As for the attitude data, a time stamp is generated at the reception of the first byte of each position datagram, and an adjustable time delay may be applied to this time stamp. If the real variation in this time delay is sufficiently small with respect to the position accuracy and vessel speed, the internal time stamp will give sufficiently accurate time synchronization. Time delay must of course be determined to a sufficient accuracy which is done by comparing data from survey lines run at different vessel speeds in the same direction up or down bottom slopes or over significantly distinctive bottom features. Any necessary correction of the applied time delay may be done in post processing.

If the variation in the time delay of the positions is too large with respect to the desired accuracy, even after position filtering during post processing, an alternative satisfactory solution will require two things: that the positioning system's own time stamp in the position datagram has a sufficient accuracy; and that the clocks of the echo sounder and the positioning system are synchronized. When post-processing, the positioning system's time stamp must be used, which is possible as both time stamps are retained in the logged data. If the positioning time stamp is not good enough,

the positions will have to be filtered during post processing to diminish the effect of the variable timing. The inertia of the vessel will set the limit of accuracy achievable by such filtering.

The absolute setting of time in the echo sounder is usually not critical with respect to other sensors. It is recommended to synchronize the echo sounder to a 1PPS signal, if available. It is also recommended not to reset the echo sounder clock, except for at the start of a survey. This will ensure that any time delays remain constant during a survey. If an external clock is additionally connected and logged, this will allow a check of clock consistency during post processing, but this is usually not worth the effort.

The conclusion and recommendations are as follows:

- It is recommended to synchronize the echo sounder to a 1PPS signal if available
- The delay in the data from the motion sensor must be constant and known to within 5 ms
- If the delay in the position data is known within an accuracy commensurate with the position accuracy and vessel speed, no synchronization of clocks is required.
- If the delay in the position data is variable and cannot be filtered to a sufficient accuracy in post processing, or the positioning is required to also be accurate for realtime displays, the echo sounder and positioning system clocks must be synchronized.

The synchronization of the two clocks must be done from a common 1PPS signal (which may be contained in the positioning system). The echo sounder must be set up to use the positioning system time stamp (datagram time) to which any position time delay will be applied. The post processing system must also be set up to use the positioning system time stamp (a time delay may have to be applied to either the position or depth data).

#### **9.4.4 Time difference PU-ZDA and PU-POS indications**

The **Numerical** display can be set to monitor the PU-ZDA and PU-POS time differences. The colour indications used are based on the **1PPS** setting, the **Time to use** setting and the **clock source** selection. All these parameters are set in the **Installation parameter** frame.

See *Installation parameters* on page 226.

In most situations the acceptable time difference is +/- 1 sec, but with 1PPS off and time tag from the system the acceptable time difference is considerably larger.

The time delay limitations are system parameters and can not be changed by the operator.

	1FPS On	1FPS Off
D		
A	Timediff +/- 1 sec:	Timediff +/- 1 sec:
T	RED in 'FU-ZDA' field when Ext. clock	RED in 'FU-ZDA' field when Ext. clock
A	RED in 'FU-FOS' field when Active pos.	RED in 'FU-FOS' field when Active pos.
G	RED in 'FU-FOS'* field when Operator st.	RED in 'FU-FOS'* field when Operator st.
R		
A		
M		
S		
Y	Timediff +/- 1 sec:	Timediff +/- 30 sec.
S	RED in 'FU-ZDA' field when Ext. clock.	YELLOW in affected field.
T	RED in 'FU-FOS' field when Active pos.	
E	RED in 'FU-FOS'* field when Operator st.	Timediff +/- 600 sec.
M		RED in affected field.

\* Conceptually not correct, but not able to compare with operator

**Related topics**

- *Numerical display* on page 62
- *Installation parameters* on page 226

## 9.5 Sound speed formulas

The echo sounder computes bottom depth, taking full account of the ray bending caused by the variation of sound speed in the water column. The Sound speed profile is entered manually, automatically from a sound speed profile probe, from an external computer, or by a combination of these methods.

If measured sound speed values are not available, they may be derived from tables, or, if the temperature and salinity profiles are known or estimated or calculated from a formula. While many formulae exist, the one from UNESCO Technical Paper in Marine Science, No. 44, is usually regarded as being authoritative. However, it is cumbersome and recent experiments showed that it has errors in the 1000-4000 m depth range. Therefore, a simpler formula with adequate accuracy is as follows (from Coppens, JASA March 1981, with a modified very deep water correction which follows the recent experimental data).

- For the surface:

$$c(0, T, S) = 1449.05 + T(4.57 - T(0.0521 - 0.00023T)) + (1.333 - T(0.0126 - 0.00009T))(S - 35)$$

where:

- T is temperature in °C
- S is salinity in ppt
- For depths to 200 m in fresh water and 1000 m in the ocean:

$$c(Z, T, S) = c(0, T, S) + 16.5Z$$

where

- T is temperature in °C
- S is salinity in ppt
- Z is depth in km
- For depths to 2000 m in fresh water and to 11000 m in the ocean (assuming that the water is very cold at great depths):

$$c(Z, T, S) = c(0, T, S) + Z \left( 16.3 + Z \left( 0.22 - 0.003Z\sqrt{T+2} \right) \right)$$

where

- T is temperature in °C
- S is salinity in ppt
- Z is depth in km

- For depths greater than 5000 m, a latitude correction should be applied:

$$c(Z, T, S) = c(0, T, S) + Z' \left( 16.3 + Z \left( 0.22 - 0.003Z\sqrt{T+2} \right) \right)$$

where

- $Z' = Z(1 - 0.0026 \cos 2\Phi)$
- $\Phi$  is latitude in degrees
- $T$  is temperature in °C
- $S$  is salinity in ppt
- $Z$  is depth in km

## 9.6 Implementation of absorption coefficients

### 9.6.1 Overview

The absorption coefficients in SIS may be set using three different sources:

- Salinity
- CTD profile
- Manual

In principle SIS can handle several echo sounders, each with its own source setting.

As a consequence SIS must maintain and control two different sets of profiles: One based on the currently set salinity value and one based on the CTD (Conductivity, Temperature and Depth) information received in an SSP datagram. The third alternative, Manual, results in the user entered absorption coefficient values being used immediately.

Absorption coefficients are dependent on the used frequency. All profile sets must therefore contain one absorption coefficient file for each frequency used by the multibeam echo sounders.

Today the required range of frequencies for the complete range of multibeam echo sounders are 12, 32, 60, 70, 80, 90, 95, 100, 200 and 300\* kHz. (\* used to calculate for 297 and 307 kHz internally in EM 3000 and EM 3002 Processing Units).

#### Parameter references

- *Filter and gains for EM 1002* on page 250

#### Related topics

- *Handling of SSP datagrams* on page 431

### 9.6.2 Salinity based absorption coefficient profiles

This type of absorption coefficient profiles are based on a depth and sound speed profile and the currently set salinity value. The depth and sound speed profiles can be obtained from two sources:

- 1 Reception of an SSP datagram of format S00 or S10 from the network. (All SSP datagrams results in the generation of an .asvp file which contains the necessary profile.)
- 2 The operator may select an ordinary SVP from **Runtime parameter**→**Sound Speed Profile**.

In both cases a set of absorption coefficient files are generated. All files in a set use the same naming convention: In case of a SSP datagram, the date and time contained in the datagram becomes first part of the file name. In case of an operator selected

SVP file the original file name is used instead. Next, the currently set salinity is included together with the frequency for which the file is valid. See example sets below

Note that there is an **.asvp** file in each file set containing the depth and sound speed data used in the calculations. This file is named the same as the rest of the set of files, except that the frequency part is absent. This file is constructed based on the SSP input or the user selected SVP. In the latter case the file contains exactly the same data as the original SVP file, e.g. 'Horten20050304.asvp' and 'Horten20050304\_salinity\_03900.asvp' contains exactly the same data. See example below. The duplication and renaming of the original user selected **.asvp** file is done so that it is simple to retrieve a complete file set including the **.asvp** file using only the basic file name as key.

#### Note

---

*The absorption coefficient file with frequency 32 kHz is actually for the 31.5 kHz system (EM 300).*

---

#### Example of salinity file set based on SSP datagram:

```
20051230_183344_salinity_03900.asvp
20051230_183344_salinity_03900_12kHz.abs
20051230_183344_salinity_03900_32kHz.abs
20051230_183344_salinity_03900_60kHz.abs
20051230_183344_salinity_03900_70kHz.abs
20051230_183344_salinity_03900_80kHz.abs
20051230_183344_salinity_03900_90kHz.abs
20051230_183344_salinity_03900_95kHz.abs
20051230_183344_salinity_03900_100kHz.abs
20051230_183344_salinity_03900_200kHz.abs
20051230_183344_salinity_03900_300kHz.abs
```

#### Example of salinity file set based on user selected SVP called 'Horten20050304.asvp':

```
Horten20050304_salinity_03900.asvp
Horten20050304_salinity_03900_12kHz.abs
Horten20050304_salinity_03900_32kHz.abs
Horten20050304_salinity_03900_60kHz.abs
Horten20050304_salinity_03900_70kHz.abs
Horten20050304_salinity_03900_80kHz.abs
Horten20050304_salinity_03900_90kHz.abs
Horten20050304_salinity_03900_95kHz.abs
Horten20050304_salinity_03900_100kHz.abs
Horten20050304_salinity_03900_200kHz.abs
Horten20050304_salinity_03900_300kHz.abs
```

A new salinity based absorption coefficient file set is generated in the following instances:

- When a new SSP datagram for immediate use (S00 – S06) is received from the network.
- When the user selects a new SVP from the runtime parameter Sound Speed Profile interface.

- When the Source is Salinity and the salinity value is changed and no existing file set is found for the new salinity.
- When the user selects Salinity as Source and no existing file set is found for the currently set salinity value.

### Parameter references

- *Sound speed for EM 1002* on page 246

### Related topics

- *Handling of SSP datagrams* on page 431

## 9.6.3 CTD based absorption coefficient profiles

CTD based absorption coefficient profiles are only generated based on SSP datagrams with formats other than S00 and S10. These other datagrams may contain the absorption coefficient directly (with appropriate frequency listed) or they contain the necessary CTD data to calculate the absorption coefficient profiles for all frequencies.

- See *Handling of SSP datagrams* on page 431

Note that when the SSP datagram contains the absorption coefficient directly (datagrams S13, S23, S33, S43, S53) this datagram is valid for one frequency only. To be able to generate a full set of absorption coefficient files one SSP datagram of the same type for each used frequency must be received. The interval between the reception of individual datagrams must be max 10 sec. (currently). The internal date and time in the SSP datagrams must be the same for all in the received set.

Note again that the requirement is that one such SPP datagram must be received for each of the frequencies 12, 32, 60, 70, 80, 90, 95, 100, 200 and 300 kHz.

When received by SIS, the SSP datagrams S01, S02, S03, S04, S05 and S06 will result in an automatic and immediate use of the confined information. Therefore it is not necessary for the operator to make a manual selection for the associated SVP.

The name of CTD based absorption coefficient file sets is constructed in the same way as for S00/S10 based sets without the salinity part.

Example of a CTD file set, based on SSP datagrams different from S00 and S10:

```
20051230_183344.asvp
20051230_183344_12kHz.abs
20051230_183344_32kHz.abs
20051230_183344_60kHz.abs
20051230_183344_70kHz.abs
20051230_183344_80kHz.abs
```

```
20051230_183344_90kHz.abs
20051230_183344_95kHz.abs
20051230_183344_100kHz.abs
20051230_183344_200kHz.abs
20051230_183344_300kHz.abs
```

The CTD file set also contains an **.asvp** file. This file is generated (directly or calculated) based on the contents in the SSP datagrams.

Note that when selecting an SVP from the runtime parameter Sound Speed Profile interface it is regarded as a CTD file set only if the file name does not contain salinity and all frequency files are present.

In all circumstances a new salinity based file set is also generated from the selected SVP and current salinity. That is when a CTD based file set is used immediately (S01, S02, S03, S04, S05, S06) selected or a corresponding file set for the currently selected salinity is also made.

### 9.6.4 Mode of operation

When the system is initialized the first time a system provided default file set is used both for the salinity based and the CTD based absorption coefficients. It is therefore important that realistic file sets are generated and selected as soon as possible when using SIS. However the current salinity and CTD based file sets will always be remembered and used e.g. after a restart.

When new file sets are generated upon reception of SSP datagrams the information about the new file set is sent to the SVP Editor. This editor may be used to modify the data contents of the file set (e.g. thinning). The operator may subsequently select the modified file set using the runtime parameter Sound Speed Profile interface.

- See *SVP Editor* on page 318

A file set that has been thinned, using the SVP editor, will contain 'thinned' in the file name, e.g.

```
20051230_183344_thinned_03900.asvp
20051230_183344_thinned_12kHz.abs
20051230_183344_thinned_32kHz.abs
20051230_183344_thinned_60kHz.abs
20051230_183344_thinned_70kHz.abs
20051230_183344_thinned_80kHz.abs
20051230_183344_thinned_90kHz.abs
20051230_183344_thinned_95kHz.abs
20051230_183344_thinned_100kHz.abs
20051230_183344_thinned_200kHz.abs
20051230_183344_thinned_300kHz.abs
```

The PUs are updated with new absorption coefficients according to the following principles:

- The depth measured by each echo sounder is received by the CCU (which handles the core functionality of the absorption coefficient system), currently every 15 sec.
- If the current selected **Source** is **Salinity** or **CTD-profile** an absorption coefficient deviation value is calculated for each frequency used by the echo sounder. This deviation value is based on the previous and current absorption coefficient for each frequency and a max range estimated from the received depth. If the found deviation for any frequency is greater than a preset limit (currently 0.2 dB) the new absorption coefficient for each frequency are sent to the PU.
- When calculating the absorption coefficients the current Source selection determines if the Salinity based file set or the CTD based file set is used.

In any case, when a new set of absorption coefficients are sent to the PU the values for each frequency used by the PUs are displayed in the runtime parameter's **Filter and Gains** frame.

Also, the currently used salinity and CTD-based absorption coefficient file sets are displayed in the runtime parameter **Sound Speed Profile** interface.

---

#### Note

*Initially SIS is configured to use and store the Salinity and CTD based absorption coefficient file sets in one pre-defined directory. This can be changed by selecting a Salinity or CTD based file set from another location by using the runtime parameter 'Sound Speed Profile' interface. All new (i.e. generated) file sets of the specific type selected above (Salinity or CTD) will be stored in this new location. Thus, Salinity and CTD based file sets can be stored in different locations.*

---



---

#### Note

*When using an external removable storage media like a USB stick to carry an .asvp profile or a CTD-file set etc. the files must be copied to a local HWS directory before selecting them for usage (Runtime parameters > Sound speed). Never select a file for use directly from a removable medium.*

---



---

#### Note

*SIS will never remove any absorption coefficient file set from it's storage location(s). If any clean-up/removal is performed by the operator, care must be taken not to remove the currently used Salinity or CTD based file set as listed in the display.*

---

Note

---

*The system provided default absorption coefficient file set, called 'default' must never be deleted or moved from its original position.*

---

## **9.7 Artefacts causing errors and variations in the sea floor depth detections**

### **9.7.1 Introduction**

Sound waves need a compressible medium (like water) for propagation. Sudden changes in this medium (i.e. changes in the sound speed or changes in the acoustic impedance) bends or reflects the sound waves. Changes like these are present in the transition (or boundary) between water and the sea bottom, and are necessary for depth detection when using an echo sounder.

When the boundary is smeared or stretched out, the sounder may have problems determining the accurate numeric value representing the sea depth. These conditions vary with frequency.

While bedrock gives a distinct echo for most frequencies, the situation is more complicated for sedimentary seabed. E.g. Sometimes the upper part of the seabed consists of a liquid like layer, changing to more solid with depth. The boundary between this layer and water can be indistinct for sufficient registration at certain frequencies.


Low frequency sonars (like 12 kHz) can penetrate the boundary of this layer with almost no reflections, whilst higher frequencies, (say 100 kHz and above) usually give reflections sufficient for detection. The result is differences in the numerical depth readings when different frequencies are used.

The registration of the sea floor may also vary with the incidence angle of the sound beam, specially when the sounders are using different frequencies.

### **9.7.2 Sea bottom penetration**

The seabed is an interface between water and earth, i.e. a transition between liquid and solid materials. Usually, on the accuracy scale to which the depths are to be measured, the interface is sufficiently clearly defined. However, in some cases this is not so, usually because the interface is not distinct enough with the top sediment being partly solid and partly water. Then the echo reflected back to the sounder is a combination of echoes both from the seabed and reflectors beneath the seabed. The echo sounder might then have problems distinguishing where the bottom really is, causing too deep and hence erroneous detections, as is not unusually observed on dual frequency single beam echo sounders.

Figure 39 The echogram from an EA 600 single beam sounder



The seabed reflects a part of an incoming sound wave due to the change of the acoustic impedance, between the sea bottom and water. Most of the sound energy not going into the bottom will be reflected away as a specular reflection (i.e. as if the bottom is a mirror), but some of the energy will be scattered in other directions (hopefully with some backscattering to the echo sounder). The angular response of the seabed will depend upon its material and its smoothness (in relation to the sound wavelength). A smooth bottom (such as silt or mud) will have a narrow specular region of a few degrees with a very weak signal reflected in other directions. On a rough bottom (such as gravel), the specular peak will be quite wide and not very strong, and the reflected signal in other directions will not be much weaker. Reflected signal strength will however always decrease with increasing angle away from the specular direction.

Penetration will usually be a bigger problem on soft bottoms than on hard, due to the impedance contrast being less. Sound penetrating into the bottom may be reflected from objects such as large rocks or from layers of different material energy will just dissipate away due to bottom losses. The absorption coefficient of soft sediments has been shown experimentally to usually increase approximately linearly with frequency. Typical values at for example 12 kHz is in the range of 1-5 dB/m with the lowest values encountered when the bottom has a very high porosity (> 65%) which implies a very small particle size (< 10 mm). Assuming that signals attenuated more than 20 dB within the

seabed, will not affect the bottom detection, penetration of up to about 10 m could be possible at 12 kHz and up to 30 cm at 300 kHz.

When there is a problem with penetration, it will mainly affect the centre of the swath. In the outer parts of the swath the penetration range may be of the same order as for the centre, but the depth is lessened due to the incidence angle. In the specular region, usually at or very close to the vertical, the degree of penetration might not be problematic due to the strong specular reflection, but this might not be consistent over a large survey area. It might also be noted that when the sub-bottom of fine particles, penetration and hence too deep detections may happen all over the swath, fairly independent of beam pointing angle, although probably more often the erroneous detections will be concentrated to the centre.

The bottom detection process is aimed at avoiding false detections and only providing correct ones. However, when the bottom is such that the echoes received from the sub-bottom are stronger than those from the seabed surface, too deep detections may invariably occur. Usually this will mostly only happen on fairly smooth bottoms, which could be handled in post-processing by filtering, but unfortunately only by removal of any fine bottom features or object from the data. If this is not acceptable, the only possible alternative in an area where penetration is problematic, is to see whether any parts of the swath are less affected by others, and to only use data from these parts in the processing. The disadvantage of this procedure is of course the unavoidable large penalty in extra surveying time required

## 9.8 The absorption coefficient equation

The mean absorption coefficient of the water column is used in the gain setting in the receiver.

The absorption coefficient is important in determining the correct backscattering strength of the seabed used in the seabed imaging. Setting a correct value is therefore always recommended if the backscatter data are to be used, especially if the results are to be compared with those from other areas. The absorption coefficient  $\alpha$  is given by the following equation:

$$\alpha = \frac{A_1 f_1 f^2}{f^2 + f_1^2} + \frac{A_2 P_2 f_2 f^2}{f^2 + f_2^2} + A_3 P_3 f^2$$

where

$$\begin{aligned} A_1 &= \frac{8.86 \times 10^{(0.78pH-5)}}{c} \\ A_2 &= \frac{21.44S(1 + 0.025T)}{c} \\ A_3 &= 4.937 \times 10^{-4} \\ &\quad -T(2.59 \times 10^{-5} - T(9.11 \times 10^{-7} - 1.5 \times 10^{-8} \times T)), \\ &\quad T \leq 20^\circ C \\ A_3 &= 3.964 \times 10^{-4} \\ &\quad -T(1.146 \times 10^{-5} - T(1.45 \times 10^{-7} - 6.5 \times 10^{-10} \times T)), \\ &\quad T \geq 20^\circ C \\ P_2 &= 1 - Z(0.137 - 0.0062Z) \\ P_3 &= 1 - Z(0.0383 - 4.9 \times 10^{-4}Z) \\ f_1 &= 2.8 \sqrt{\frac{S}{35}} \times 10^{[4 - \frac{1245}{273+T}]} \\ f_2 &= \frac{8.17 \times 10^{[8 - \frac{1990}{273+T}]}}{1 + 0.0018(S - 35)} \end{aligned}$$

Here,  $\alpha$  is given in dB/km, the sound speed  $c$  in m/s, the temperature  $T$  in  $^\circ C$ , the depth  $Z$  in km, the salinity  $S$  in ppt, and the frequency  $f$  in kHz. The  $pH$  of the ocean is in the order of 7.6-8.2.

The mean values are the mean absorption coefficient from the surface to the depth indicated, and is the value to be entered in the menu.

The absorption coefficient equation is from R. E. Francois and G. R. Garrison, "Sound absorption based on ocean measurements: Part II: Boric acid contribution and equation for total absorption," J. of Acoust. Soc. Am. 72(6), Dec. 1982, p 1886.

## 9.9 Projections

### 9.9.1 Scope

This section gives in-depth information on the Projection component. The purpose with the section is to describe how to program a projection and how a projection can be defined using the projection library.

### 9.9.2 Programming a projection

On the Installation CD there is a directory called **UserSrc**. This directory contains a template for programming your own projections. On a Windows system use **usersrc.dsp** and program the projection in Microsoft Studio. On a Linux system, simply program the projection and compile using the Makefile.

On a Windows PC the output is a dynamic link library, **userProj.dll**. Copy this file to the location where SIS is installed and replace the existing file.

On a Linux system, the output is a shared library **libuserproj.so**. Copy this file to the location where SIS is installed and replace the existing file.

You create your own projection in the file **userProj.cpp**. Follow the example in the file:

- 1 Create the routines you want to use. You have to define three routines, one for initialization of the projection, one for the projection and one for the inverse projection. It is important that the parameters are correct, see the example.
- 2 Edit the routine **InitUserProjection**. In the switch statement add a number and call your initialization routine. The number is important. You must choose a number larger than 1000 as SIS is already using the numbers below 1000. Each projection must have a unique number.
- 3 Edit the routine **ForwardProjection**. In the switch statement call your forward projection.
- 4 Edit the routine **InverseProjection**. In the switch statement call your inverse projection.
- 5 Compile and install the shared library.
- 6 Start SIS. Open the **Survey templates** window and find the tab where you define the projection. Then choose **Create new projection** and this program starts.
- 7 Choose **New...** and give the new projection a proper name.
- 8 Choose the projection type to be **User defined**. The number you enter must be the same as the one you just programmed.

You have now created your own projection.

## Note

---

*If you later reinstall SIS, this projection will be lost. You have to save the shared library file and install it after you install or upgrade SIS.*

---

### 9.9.3 Using PROJ.4

You can also define a projection using the projection library PROJ.4. A 7-parameter datum transformation is already available in SIS.

The following text file defines a PROJ.4 projection:

```
<MyProjection>
ellps=WGS84
proj=utm
zone=32
units=cm
```

The parameter ellps must be defined, and units=cm must be used.

To add a 7-parameter datum transformation, the setup is like this:

```
<MyProjection>
ellps_from=Bessel
rotXrad=0.0000001
rotYrad=0.0000002
rotZrad=0.0000003
dXm=150.0
dYm=160.0
dZm=170.0
scale=0.9998
ellps=WGS84
proj=utm
zone=32
units=cm
```

Note that rotXrad, rotYrad and rotZrad are expressed in radians, and that dXm, dYm and dZm are expressed in meters. The primary ellipsoid is defined after ellps\_from and the secondary ellipsoid will be defined by ellps.

The to and from definition of the ellipsoids are the names of the ellipsoids found in the list of ellipsoids. You see this list when you define the projection.

The transformation parameters themselves must be entered by the operator.

The operator must save this setup in a text file. He can then define a PROJ.4 projection as described above. In the text field where he types the PROJ.4 projection, type something like this:

```
+init=/mydir/somefile.txt:my_projection
```

This means that the projection is named my\_projection and is defined in the file \mydir\somefile.txt.

For PROJ.4 details see the doc directory.

Windows:

C:\Program Files\Kongsberg Maritime\SIS\doc

Linux:


use/local/SIS/doc

## 9.10 Geoid

If high accuracy antenna heights (e.g. RTK GPS or other high accuracy position systems) are extracted, predefined geoid models can be used to obtain the distance from the sea floor to your vertical reference plane (e.g. Mean Sea Surface).

The figure below shows the various distances used in the calculating the depth to the seafloor relative to the vertical reference.

*Figure 40 Computation principles*



- A** Distance from the echo sounder to the sea floor
- B** Distance from the antenna to the ellipsoid
- C** Motion corrected distance (depth) from water surface to sea floor

The measured distance from the echo sounder to the sea floor is corrected for transducer offset and motion (heading, roll, pitch and heave) to obtain the distance from the water surface to the sea floor.

Because the heave sensor only reacts to fast changes, the water surface is in reality defined by the 0-level of the heave sensor.

- D** Motion corrected distance (height) from water surface to ellipsoid

The position system gives the distance from the antenna to the ellipsoid **B**. This distance is corrected for antenna offset and motion to give **D**, which is the distance from the sea surface to the ellipsoid

Note that both the corrected echo sounder depth **C** and the GPS based height above the ellipsoid **D** is now referred to the same vertical level, the sea surface.

- E** Distance from the sea surface to the vertical reference (tide)

The tide **E** is computed as  $E = D - F - G$ .

- F** Distance from the ellipsoid to the geoid (geoid undulation), positive if the geoid is above the ellipsoid.

This value is given by the geoid model.

- G** Distance from the geoid to the vertical reference, positive if the vertical reference is above the geoid.

This value is given by the geoid model.


- H** is the distance from the vertical reference to the sea floor and can be computed as  $H = C - E$

- I** is the distance from the sea floor to the geoid and is computed as  $I = G - H$

### The geoid file

The geoid file **geoidmodel.geoid** must be stored together with the background data. See *Survey parameters* on page 216.

The next figure shows the layout of the geoid file. This layout is chosen to fit to rivers where the geoid undulation and vertical reference is known at cross profiles along the river (the vertical lines are the riverbanks). It is possible to define several “rivers” in one file thus allowing general areas to be defined.



The file format is as follows:

- 1 latitude(degrees) longitude(degrees) F(meters) G(meters)
- 2 latitude(degrees) longitude(degrees) F(meters) G(meters)
- 3 latitude(degrees) longitude(degrees) F(meters) G(meters)

where **F** is distance from the ellipsoid to the geoid and **G** is distance from the geoid to the vertical reference.

The line starting with 2 is optional. The cross profile may be defined using two or three points, the first point with id 1 and the last point id 3. If there is a middle point, it has the id 2. Latitude and longitude are positive north of the Equator and east of Greenwich, negative on the other side.

An area is defined between two cross profiles. A model (river) must always have at least two cross profiles. Several models (rivers) in the same file must be separated by an empty line.

The geoid undulation F and the vertical reference G is interpolated using straight lines between cross profiles.

## 9.11 Tide

Tide input to SIS can be of two types: Real time tide or predicted tide.

### Realtime tide

Realtime tide is sent to SIS as discrete tide datagrams using a serial link or by the network using UDP port 4001. The format of the tide datagram is as follows:

```
$ATIDE,20040512073406,1.74*00
```

The header is always \$ATIDE. Next comes the time YYYYMMDDhhmmss, and then the tide in meters.

The checksum is currently not used, but must be present.

#### Note

*The tide is added to the depths.*

The tide input using a serial line is set up in **Tools→External sensors**. See *External sensors* on page 295

#### Note

*The file **realtime.tide** will be created every time SIS is restarted.*

### Predicted tide

A tide file with the name **predictedtide.tide** can be stored together with the background data for the survey, see *Survey parameters* on page 216.

The format is like this:

```
(Tide)
20040512073655 1.74
20040512073755 3.42
20040512073855 5.00
20040512073955 6.43
20040512074055 7.66
20040512074155 8.66
20040512074255 9.39
20040512074355 9.85
20040512074455 10.00
20040512074555 9.85
20040512074655 9.40
20040512074755 8.67
20040512074855 7.67
20040512074955 6.44
20040512075055 5.01
20040512075155 3.43
20040512075255 1.75
20040512075355 0.02
20040512075455 -1.72
20040512075555 -3.40
20040512075655 -4.98
```

```
20040512075755 -6.41
20040512075855 -7.65
20040512075955 -8.65
20040512080055 -9.39
20040512080155 -9.84
20040512080255 -10.00
20040512080355 -9.85
20040512080455 -9.41
20040512080555 -8.67
```

The first line is a header enclosed in parenthesis. The first word must be **Tide**.

Next comes the tide data. The time format is YYYYMMDDhhmmss and the tide is in meters.

Note that the tide is ADDED to the depths.

## 9.12 Javad and Trimble details

You have to start the necessary modules to enable logging from a Javad or Trimble GPS receiver. Each module is described in sub-sections, after the following manual start-up procedures.

### Note

---

*The “(space)” remark indicates space key in the start-up commands; the letters are not a part of the commands.*

*Fill in the constituent data file or port number between the brackets <...>.*

---

### Mean Sea level module

- Windows:  

```
sisMSL -d "C:\Program Files\Kongsberg Maritime\SIS\bin" -i 9044 -o 9041
```
- LINUX:  

```
./sisMSL -d /usr/local/sis/bin -i 9044 -o 904128
```

### Real time tide module

```
sisTide -f<constituent data> F tide5.dat -i 1 -p(space) 9041 -p 4001
```

Here the Mean Sea level module is set up to receives GGA messages from the Javad receiver and the Real time tide module sends data to the gpsraw module logging data from the Javad receiver.

### Javad GPS receiver

- ```
RStoUDP -com <port number>,19200,8,0,1 -udpin(space) 9049 -udpout localhost,9050 -bin
```
- ```
gpsraw -p 1 -t JAVAD -i 9050 -u 9049 -c 9041 -e(space) 4002 -n 4002 -g 9044
```

### Trimble GPS receiver

- ```
RStoUDP -com <port number>,19200,8,0,1 -udpin(space) 9038 -udpout localhost,9039 -bin
```
- ```
gpsraw -p 2 -t TR4000SSE -i 9039 -u 9038 -c 9041(space) -e 4002 -n 4002 -g 9033
```

#### 9.12.1 Raw GPS data logging module

The raw GPS data logging module enables the user to log raw GPS measurements from a high quality GPS receiver, thus enabling the user to post process the data using any available tool, for example AbsPos (available autumn 2005 from Terratec AS).

At the moment, two different GPS receivers are supported, Javad and Trimble 4000 series (tested with Trimble 4000 SSE).

Starting the programme with the option -h (i.e. `gpsraw -h`) gives the following output, which should be self explanatory:

```
gpsraw $Revision: 1.4 $
Usage gpsraw [options]

-p <1-3>                Set positioning system number
-t <gps receiver type>  (JAVAD or TR4000SSE)
-i <portnum>            Reads data from this port [in]
-c <portnum>            Control port [in]
-e <portnum>            Port for error messages [out]
-u <portnum>            Port for messages to gps receiver [out]
-g <portnum>            Port to receive GGA NMEA messages [out]
-n <portnum>            Port to receive all NMEA messages [out]
-d                      Show debug messages
-v                      Show version and exit
-h                      Show this help
```

This programme reads raw gps data from one UDP port, interprets and logs the data to a file, extracts NMEA messages which may be distributed to other programs. It may control the GPS receiver by writing control datagrams to the gps receiver. It reads control datagrams which may start or stop logging to file, or set fixed height (if supported by the receiver).

NMEA messages may be distributed to multiple ports, by repeating the options -g and/or -n.

For output ports the port may be given as port, name:port or ip:port. A control port (-c) and an inport (-i) are required options.

The control datagrams that are understood are:

\$KSSIS,102,dirname,ON	Start logging in given directory
\$KSSIS,102,dirname,OFF	Stop logging
\$KSSIS,103,ON	Set fixed height
\$KSSIS,103,OFF	Reset fixed height
\$KSSIS,105,23.45	Geoidal separation in meters
\$ATIDE,20051225123022,2.45	Time and tide value [meters]
<Installation datagram>	To get antenna height

The error messages which may be returned to the port given by -e have the form:

- \$KSSIS,104, ; message text which may be long...

### 9.12.2 Mean Sea level module

The mean sea level module calculates the Mean Sea Level (in many places almost the same as Geoid) from a set of input files and interpolates accordingly to a position received as a GGA message on an input (UDP) port. It sends the MSL value in the given position to those who need it, in particular the raw GPS logging module, which needs it for calculating antennae height when too few satellites are visible.

The programme is started from a command file or from a terminal window and using the -h option gives the following information:

Usage `sisMSL <options>`

Where options are:

-h	Prints this help
-d <directory>	Where to search for data files (required)
-p <pattern>	Pattern used in search. Default: .grid
-i <portnum>	Where to receive GGA messages from (required)
-o <portnum>	Where to send geoid separation (Can be repeated. At least one is required)
-D	Prints debug information

This programme reads geoid separation files from a directory and interpolates in the files from a position received on a port with NMEA GGA messages. The ports can be given as either `hostnum:port`, `ip:port` or just `port`.

### 9.12.3 Real time tide module

The real time tide module calculates the tide from a set of input files. One normally called **tide5.dat**, can be generated, and the other contains the constituents for the nearest harbour. The programme can calculate the tide using phase and amplitude offsets as well as correcting for the current air pressure (given that the correct tide is known). The internal clock of the computer must be correct for this real time module to work correctly.

The programme has also the capability to make a prediction file, using other options.

A typical usage for the programme, with typical options which gives the tide corrected to LAT are:

```
sisTide -f stavanger.xdo -F tide5.dat -p 4001 -s 1.1(space)
-t 12 -l 0.05 -z 0.65 -i 10
```

By using the -h option the following help message is returned:

```
use sisTide [options]
```

-h	Show this message and return
-v	Show version and return
-c	Show copyright notice
-q	Show file formats and return
-f <filename>	Read constituent data from this file
-F <filename>	Read Foreman data from this file
-i <number>	Interval for sending or calculating data [min] (default 60)

The following two options are for sending real time predictions:

p <portnum>	Send to port (default localhost:4001)
-------------	---------------------------------------

The following two options are for generating predictions for a date:

-D<YYYYMMDD>	Start date for predictions
-d <number of days>	Number of days to give predictions for (default 1)

#### Note

---

*If -D is given, -p ignored.*

---

Options for changing the calculations:

-a	Amplitude factor (default 1.0) Multiply the result with this factor.
-t	Secondary harbour time correction [min] (default 0) Added to time before calculating tide (delaying tide)
-l	Level correction [m] default 0.0 Add to tide after calculations
-z	Use this level (positive number) [m] for Z0 (default 0.0) Add to tide after calculations

#### Note

---

*Z0 value from file is never used.*

---

Constituent (-f) and Foreman (-F) files must always be given.

#### Note

---

*Predicted tides are always referring to UTC (GMT). This can be changed using -t option (-t60 gives MET).*

*Environment variable TZ must be correctly set to get correct real time predictions. (e.g. TZ = MET - 1METDST).*

*Predicted tides are calculated relative to mean sea level unless Z0 (-z) and/or level corrections (-l) are given.*

*The results are negated so ADDING the results to measured depths should give tide-corrected depths.*

---

### 9.12.4 RStoUDP

The RStoUDP module makes it possible to control/receive data on UDP from equipment attached to RS232 serial lines:

```
Usage RStoUDP -com
<prt>,<baud>,<databit>,<parity>,<stopbit>
  -udpin <port> -udpport<ip,port> -udpout[1-4]<ip,port>
  -ts -distudp -log <logfile> -confsock <port>
  -bin <buf size> -t <timeout(usec)>
```

Legal values for parity is 0=none, 1=odd and 2=even, where:

- -com (Comm port to use)
- -udpout (Port nr. for incoming data)
- -ts (Add timestamp to ASCII data)
- -udpout[n] (Additional output sockets)
- -distudp (Distribute incoming udp data to all udp out sockets)
- -confsock (Socket for incoming config messages)
- -bin <size> (Binary mode and buffer size)
- -t (Timeout value when reading binary data)

Example: RStoUDP -com 4,9600,8,0,1 -udpout(space) localhost, 2020 -log log.dat

## 9.13 Dead reckoning and position jump filter

The Dead reckoning calculation and Position jump filter functionality described here, are used to avoid temporary stops and position jumps when updating the ship symbol in the Geographical view.

Missing positions and unstable position input will typically occur when the positioning system antenna(s) is obstructed by e.g. bridges or other structures.

Both Dead reckoning and Position Jump filter can be enabled/disabled independently using the **Tools→Customs→Set parameters→Positions** menu.

### Note

---

*Position jump filtering is also performed in another context. It is used for gridding purposes and the objective is to avoid erroneous data being used in the gridding operation and subsequently displayed in the gridded data in the Geographical View. This operation is automatic, but the parameters to use can be changed using the **Tools→Customs→Set parameters→Positions** menu.*

---

### 9.13.1 Dead Reckoning

If the position input stops for more than 0.5 second, SIS will predict all subsequent missing positions for a set period of time, currently 30 sec. The prediction is based on the last two good positions which are used to calculate the speed. In addition the last good heading is used in the calculations to determine the direction.

When the set prediction period expires, or if a new good position is received, the prediction stops.

### Note

---

*If the position update frequency is 1 Hz, the current setting will imply that a predicted position is generated 0.5 seconds (approximately) after a real position, giving an update frequency of the boat symbol of 2 Hz.*

---

### 9.13.2 Position jumps

A position filter is used to remove excessive jumps in position. If a jump is detected, a predicted position is calculated and used instead. The criteria for a position jump is that the speed exceeds a set limit, currently 30 m/sec. Also, a position jump is assumed if the heading calculated from the last two positions exceeds a  $\pm 20$  degree corridor scaled according to the position quality.

**Note**

---

*The position jump filter only removes one erroneous position (the first) if several consecutive erroneous positions are received.*

*The predicted positions (from Dead Reckoning calculations or Position jump filter) are never logged. They are used to update the boat symbol in the Geographical View. The predicted position datagrams are not distributed to external recipients that have subscribed to position datagrams.*

*Missing position input will be indicated in the **PU sensor status display** and in the **PU status lamp** in **Main menu bar**. A message is also logged in the **Message service** when positions are missing.*

---

**Related topics**

- *Request datagrams from an echo sounder on page 442*
- *PU sensor status view on page 77*
- *Main toolbar on page 29*
- *Message service view on page 62*

## 10 DATAGRAM AND FILE FORMATS

This chapter provides a description of some of the datagram and file formats used by SIS.

### Topics

- *Export formats* on page 427
- *Survey plan file format* on page 430
- *Handling of SSP datagrams* on page 431
- *Sound speed profile format* on page 434
- *Sound speed and density profile format* on page 437
- *External datagram (C+T) format* on page 439
- *Changing behaviour of notification messages* on page 440
- *Request datagrams from an echo sounder* on page 442
- *Request datagrams – manual set-up* on page 444
- *Data distribution* on page 450
- *Remote datagrams* on page 451
- *Notification of SIS pinging and logging activity* on page 453
- *Difference in log file formats* on page 456
- *Barometer input* on page 457

## 10.1 Export formats

When data is exported from SIS, different export formats can be chosen.

The ASCII output contains an entry describing the file contents. Note that positions are in projection coordinates and in centimetres. Depths are also in centimetres. Time is in milliseconds since epoch 0 UTC 1 January 1970.

The binary output also contains this information. The following is an example code of how to read the binary files:

```
//h+//////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////
/*!
// \file readSISBinaryOutput
//
// \brief Example of how to read the binary output from SIS
// \author Terje Pedersen
//
// \date 10-OCT-2003
//
// \par Copyright:
//
// Copyright by Kongsberg Simrad
//
//
// \par Revision History:
//
// \par 01 10-OCT-2003 tp
//
// Original Version.
//
//
*/
//h-//////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////
#include <stdio.h>
#include <stdlib.h>
#include <time.h>
#include <string.h>

//! Little endian cell data
#ifdef WIN32
typedef __int64 i64;
#else
typedef long long i64;
#endif
typedef struct {
    int m_lEastCm, m_lNorthCm;
    int m_iDepthCm;
    int m_iFlag;
    int m_iResidualCm;
} SLittleEPointRec, *SLittleEPointPnt;

typedef struct {
    int m_lEastCm, m_lNorthCm;
    i64 m_lDate;// millisec. since epoch
    int m_iPingno, m_iBeamno;
    int m_iDepthCm;
```

```

        int m_iFlag;
        int m_iResidualCm;
    }SLittleEPointExtraRec, *SLittleEPointExtraPnt;

//f+//////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////
//
// *!
// \brief Convert milliseconds since epoch to date
//
// \param mtime, milliseconds since epoch
// \param year, month, day, hour, min, sec, millisec
//
// \return void
//
// \author Terje Pedersen
//
// \date 10-OCT-2003
//
// \note
//
//f-//////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////

/void convertMsecToDate(i64 mtime, int *year, int *month, int
*day, int *hour, int *min, int *sec, int *msec)
{
    i64 t;
    time_t nt;
    struct tm stm, *ptm;
    if (year == NULL || month == NULL || day == NULL ||
        hour == NULL || min == NULL || sec == NULL ||
        msec == NULL) return;
    t = mtime/1000;
    *msec = (int)(mtime - (t*1000));
    nt = (time_t)t;
    ptm = localtime(&nt);
    if (ptm == NULL) return;
    memcpy(&stm,ptm,sizeof(stm));
    *year = stm.tm_year+1900;
    *month = stm.tm_mon+1;
    *day = stm.tm_mday;
    *hour = stm.tm_hour;
    *min = stm.tm_min;
    *sec = stm.tm_min;
}

//f+//////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////////
//
// *!
// \brief Read the binary output from SIS
//
// \param type, what type of file to read
// \param filename, name of file to read
//
// \return void
//
// \author Terje Pedersen
//
// \date 10-OCT-2003

```

```

//
// \note
*/
//f-////////////////////////////////////

int readSISBinaryOutput(int type, char *filename)
{
    FILE *fd;
    SLittleEPointRec le;
    SLittleEPointExtraRec lex;

    if (type < 1 || type > 2) return -1;
    //printf("%d %d\n", sizeof(le), sizeof(lex));

    fd = fopen(filename, "rb");
    if (fd == NULL) {
        fprintf(stderr, "Cannot open file: %s\n", filename);
        return -1;
    }

    if (type == 1) { // Little endian point data
        while (fread(&le, 1, sizeof(le), fd)) {
            printf("East %d cm, North %d cm, Depth %d cm, Flag %d,
                Residual %d cm\n", le.m_lEastCm, le.m_lNorthCm,
                le.m_iDepthCm, le.m_iFlag, le.m_iResidualCm); //while
        } //if type == 1
    }
    if (type == 2) { // Little endian point data with extras
        int year, month, day, hour, min, sec, msec;
        while (fread(&lex, 1, sizeof(lex), fd)) {
            convertMsecToDate(lex.m_lDate, &year, &month, &day,
                &hour, &min, &sec, &msec);
            printf("East %d cm, North %d cm,
                Date %I64d %04d%02d%02d %02d%02d%02d.%d,
                Ping no. %d, Beam no. %d, Depth %d cm, Flag %d,
                Residual %d cm\n", lex.m_lEastCm, lex.m_lNorthCm,
                lex.m_lDate, year, month, day, hour, min, sec, msec,
                lex.m_iPingno, lex.m_iBeamno, lex.m_iDepthCm,
                lex.m_iFlag, lex.m_iResidualCm);
        } //while
    } //if type == 2
    return 0;
}

int main(int argc, char*argv[])
{
    if (argc != 3) {
        printf("\n\nUsage: %s<type><filename>\n\n", argv[0]);
        printf("Types:\n!");
        printf("1: little endian point data without time.\n");
        printf("2: little endian point data with time.\n");
        printf("Long must be 8 bytes, it is %d bytes\n", sizeof(i64));
        printf("\n\n");
    } //if

    return readSISBinaryOutput(atoi(argv[1]), argv[2]);
}

```

## 10.2 Survey plan file format

The survey plan file can be stored as a binary file with extension **\*.sisplan** or as ASCII files in the existing Neptune format.

The first line gives information about the Latitude/Longitude format used in the file. There are four different options:

**DEG** – Degrees, decimal degrees

**MIN** – Degrees, minutes and decimal minutes

**SEC** – Degrees, minutes and seconds

**PROJECTION** – Projection coordinates

The next line is a comment or text that follows the job.

The following is an example of the format to define a planned line:

```
LINE <Line Name> <Line Number> <Time of creation>
<Flag><N><E><N><E>' <Comment>
```

The time of creation is the HWS time given in the following format:

YYYYMMDDhhmmss

where:

- **YYYY** – The Year
- **MM** – The month of the year
- **DD** – The day of the month
- **hh** – The hour of the day
- **mm** – The minutes in the hour
- **ss** – The second of the minute

The polygon has a similar format, except:

- Starts with **\_POLYGON**
- The name is always polygon
- The line number is always 0
- The flag is always 0
- It is not possible to attach information to a polygon

## 10.3 Handling of SSP datagrams

### Topics

- *Overview* on page 431
- *Usage* on page 432

### 10.3.1 Overview

The SSP datagram format is used for input of depth or pressure profiles containing:

- Sound speed (m/s)
- Temperature (°C)
- Salinity (parts per thousand)
- Absorption coefficient

SSP datagrams are sent to the HWS on port 4001.

The SSP format is a generic format and the actual type of information conveyed is defined by an identifier. Currently the following are defined:

Identifier	Input data	Data to be used	Comment
S00	D,c	D,c	Same as S10, but used immediately
S01	D,c,T,S	D,c,a(D,T,S,L)	Same as S12, but used immediately
S02	D,T,S	D,c(D,T,S,L), a(D,T,S,L)	Same as S22, but used immediately
S03	D,T,C	D,c(D,T,C,L), a(D,T,S,L)	Same as S32, but used immediately
S04	P,T,S	D(P,T,S,L), c(P,T,S,L), a(P,T,S,L)	Same as S42, but used immediately
S05	P,T,C	D(P,T,C,L), c(P,T,C,L), a(P,T,C,L)	Same as S52, but used immediately
S06	D,c,a	D,c,a	Same as S11, but used immediately
S10	D,c	D,c	
S11	D,c,a	D,c,a	

Identifier	Input data	Data to be used	Comment
S12	D,c,T,S	D,c,a(D,T,S,L)	
S13	D,c,a,f	D,c,a	Frequency dependent
S20	D,T,S	D,c(D,T,S,L)c	
S21	D,T,S,a	D,c(D,T,S,L),a	
S22	D,T,S	D,c(D,T,S,L),a(D,T,S,L)	
S23	D,T,S,a,f	D,c(D,T,S,L),a	Frequency dependent
S30	D,T,C	D,c(D,T,C,L)	
S31	D,T,C,a	D,c(D,T,C,L),a	
S32	D,T,C	D,c(D,T,C,L),a(D,T,C,L)	
S33	D,T,C,a,f	D,c(D,T,C,L),ai	Frequency dependent
S40	P,T,S	D(P,T,S,L),c(P,T,S,L)	
S41	P,T,S,a	D(P,T,S,L),c(P,T,S,L),a	
S42	P,T,S	D(P,T,S,L),c(P,T,S,L),a(P,T,S,L)	
S43	P,T,S,a,f	D(P,T,S,L),c(P,T,S,L),a	Frequency dependent
S50	P,T,C	D(P,T,C,L),c(P,T,C,L)	
S51	P,T,C,a	D(P,T,C,L),c(P,T,C,L),a	
S52	P,T,C	D(P,T,C,L),c(P,T,C,L),a(P,T,C,L)	
S53	P,T,C,a,f	D(P,T,C,L),c(P,T,C,L),a	Frequency dependent

### Legend

**a** Absorption coefficient

**c** Sound speed

**C** Conductivity

**D** Depth

**f** frequency

**P** Pressure

**L** Latitude (always present)

**S** Salinity

**T** Temperature

The notation **a(D,T,S,L)** means that the absorption coefficient (i.e. **a**) is calculated from depth, temperature, salinity and latitude.

### 10.3.2 Usage

The use of absorption coefficients from SSP datagrams are available for all types of echo sounders.

Upon reception of SSP datagrams, SIS will always generate a sound velocity profile file (.asvp), either directly (e.g. if S00, S11 is received) or by performing the necessary calculations to determine the sound speed (c) from the supplied data.

An absorption coefficient profile file (.abs), based on the supplied data, will also be generated for all frequencies used by the echo sounders.

There is a special case for the SSP datagrams S13, S23, S33, S43 and S53. These datagrams has been extended to also include a frequency for which the contained data is valid. This makes it possible to specifically set all absorption coefficients to be used for the relevant frequency.

#### Note

---

*When one of these particular datagrams are used SIS will require one datagram for each of the frequencies used by the echo sounders (i.e. 12, 31.5, 60, 70, 80, 90, 95, 100, 200 and 300 kHz). They must be sent within 10 sec. of each other and have the same acquisition date and time.*

---

A subset of the SSP datagrams, specifically S00, S01, S02, S03, S04, S05 and S06, will be used immediately. That is, the corresponding sound velocity profile and absorption coefficients will be sent to the PU(s). The Runtime parameters frame, if displayed, will be updated with the new file set information.

When SSP datagrams are received by SIS, the **SVP Editor** will always be informed. A warning will be given if the SVP Editor is not running .abs files.

If the SVP Editor is not running, it will be started automatically if enabled by the **Tools→Custom→Set Parameters→Sound speed menu**.

You may edit the .asvp and .abs files and store the edited files using the SVP editor. You can use these files by selecting the .asvp file, i.e. sound profile, from the **Runtime parameters→Sound Speed**.

#### Parameter references

- *Sound speed for EM 1002* on page 246

#### Related topics

- *SVP Editor* on page 318

## 10.4 Sound speed profile format

### Note

---

*“Sound speed” is the correct technical term , but “Sound velocity” is used in the file extension (.asvp) and in the file format definition due to historical reasons.*

---

The standard sound speed profile used in SIS has the file extension **.asvp** (ASCII sound velocity profile). The file layout is as follows:

### Header (the first line enclosed in brackets)

```
( SoundVelocity Version Id Time Lat Long Radii  
Valid_from Valid_to Src Hist No_val )
```

### Note

---

*Note the space character after the leading bracket and before the closing bracket.*

---

SoundVelocity:	An identification of the file type (sound speed profile file)
Version:	The file format version number (usually 1.00)
Id:	A possible identifier
Time:	The time of creation for this file (YYYYMMDDhhmm or YYYYMMDDhhmmss)
Lat:	The latitude of the profile location (decimal degree)
Long:	The longitude of the profile generation (decimal degree)
Radii:	The radii around the lat/long position for which this profile is valid (m).
Valid from:	The time interval in the year from which this profile is valid (YYYYMMDDhhmm)
Valid to:	The time interval in the year to which this profile is valid (YYYYMMDDhhmm)
Src:	The source of the profile (e.g. probe name, database name, editors name etc.)
Hist:	The history of modifications on the profile (P=probe, E=edited, M=merged, N=new)
No val:	The number of values that are used in the profile

### Data

Depth:	The water depth (m)
SounVelocity:	The sound speed (m/s) at the corresponding depth

An example:

```
( SoundVelocity 1.00 12 200605290813 22.3452678
  66.4483298 4500 200605290813 200605301210 SVP-16 PE 8 )
0.1 1483.6
5.0 1484.2
7.0 1485.3
12.0 1488.1
20.0 1485.7
25.0 1484.0
40.0 1483.8
12000.0 1509.6
```

Data restrictions:

- Legacy echo sounders (i.e. EM 120, EM 300, EM 1002, EM 2000 and EM 3000,) can handle maximum 570 data entry points.
- The new generation of echo sounders (i.e. EM 122, EM 302, EM 710, ME 70 and EM 3002,) can handle maximum 1000 data entry points.

### Error checking

The sound speed profile selected from **Runtime parameters**→**Sound speed** is checked for possible errors before it is being used. If applicable, an error message is reported to the user for the following errors:

- Sound velocity out of range (legal range [1400-1700] m/s)
- Depth out of range legal range [0-12000] m
- Depth inconsistency, i.e. depth decreasing
- Depth inconsistency, i.e. multiple similar depths
- Depths not extended to 12000 m
- Unknown format in file
- Missing or unknown creation time
- Unknown conversion error

Even though SIS supports several types of sound speed profiles, the checking will be performed to the file after it has been converted to **.asvp** format.

Before the profile is accepted by SIS all reported errors must be corrected for, e.g. using the SVP Editor.

### Related operational procedures

- *How to collect the sound velocity profile* on page 125
- *How to convert your sound velocity profile to SIS format* on page 126
- *How to modify and load a sound speed profile into SIS* on page 132

**Parameter references**

- *Sound speed for EM 1002* on page 246

**Related topics**

- *SVP Editor* on page 318
- *Sound speed and density profile format* on page 437

## 10.5 Sound speed and density profile format

This is a special profile containing water density in addition to the sound speed. It is used in ROV operations where the scaling factor is automatically calculated.

The file extension is **.actd** (Ascii density profile).

The error checking as described in *Sound speed profile format* on page 434 also applies to the **.actd** format.

Note

---

*The **ctd** term in the file extension is not entirely accurate in this case. It is used as a general term to indicate that the file contains additional parameters to depth and sound speed.*

---

The file layout is as follows:

### Header (the first line enclosed in brackets)

```
( ACTD Version Id Time Lat Long Radii  
Valid_from Valid_to Src Hist No_val )
```

Note

---

*Notice the space character after the leading bracket and before the closing bracket.*

---

ACTD:	An identification of the file type.
Version:	The file format version number (usually 1.0)
Id:	A possible identifier
Time:	The time of creation of this file, (YYYYMMDDhhmmss) seconds (i.e. 'ss') are optional
Lat:	The latitude of the profile location (decimal degree).
Long:	The longitude of the profile generation (decimal degree).
Radii:	The radii around the lat/long position for which this profile is valid (m)
Valid from:	The time interval in the year from which this profile is valid (YYYYMMDDhhmm)
Valid to:	The time interval in the year to which this profile is valid (YYYYMMDDhhmm)
Src:	The source of the profile (e.g. probe name, database name, editor's name etc.).
Hist:	The history of modifications on the profile (P=probe, E=edited, M=merged, N=new)
No val:	The number of values (i.e. sample sets) that are used in the profile

## Note

---

*All elements in the header must be represented. The 'Time', 'Lat', 'Long' and 'No val' must always have real valid values.*

---

## Data

This is the file body which consist of **No val** number of sample sets, each sample set is placed on a separate line

Depth:	The water depth (m)
SoundVelocity:	The sound speed (m/s) at the corresponding depth
Density:	The water density (kg/l) at corresponding depth

An example:

```
( ACTD 1.00 12 20060529081355 22.3452678 66.4483298
  4500 200605290813 200605301210 SVP-16 PE 7 )
0.20 1496.18 0.890
6.10 1491.51 0.890
41.97 1474.97 1.02
165.77 1480.02 1.14
271.28 1481.57 1.15
427.28 1484.42 1.15
12000.00 1669.00 1.19
```

## Note

---

*This header will eventually (in later releases) get the same format as the .asvp file type.h*

---

## Note

---

*The same restrictions regarding number of data entry points in the profile applies to the .actd file type as to the .asvp file type.*

---

## Related operational procedures

- *How to collect the sound velocity profile* on page 125
- *How to convert your sound velocity profile to SIS format* on page 126
- *How to modify and load a sound speed profile into SIS* on page 132

## Parameter references

- *Sound speed for EM 1002* on page 246

## Related topics

- *SVP Editor* on page 318
- *Sound speed profile format* on page 434

## 10.6 External datagram (C+T) format

If **Ext. datagrams (C+T)** is selected UDP is used.

The format of the external UDP datagram used with the **Ext. datagrams (C+T)** sensor selection is as follows:

```
$KSSIS,80,c.c,t.t,\n\r
```

where

- **\$KSSIS** specifies that this is a Kongsberg proprietary datagram format
- **80** is the datagram number indicating that this is an external sound speed sample
- **c.c** is the sound speed at transducer represented as an ASCII text string e.g. 1460.95
- **t.t** is the temperature at transducer represented as an ASCII text string e.g. 19.25
- **\n\r** is the closing sequence (linefeed, carriage return)

This datagram must be sent to port 4001 on the HWS computer.

## 10.7 Changing behaviour of notification messages

Notification messages are used in SIS when something is being reported or brought to the attention of the operator. Several levels of notification are available:

- Information
- Warning
- Error

All can be used with or without pop-up and sound. All notification messages results in an entry in the SISDB database, which can be viewed using the **Message Service**. See *Message service view* on page 62.

Notification messages generated in SIS are defined in a file found in the directory where SIS is installed.

For Windows and Linux respectively, the following directories and file names typically defines all messages and the behaviour in SIS as they occur

- For Windows, typically in **C:\Program Files\Kongsberg Maritime\sis\bin** in a file called **messages\_R\_Sy.uni**.
- For Linux in **/use/local/sis/Database** in the file called **pmess.sql**

This file is in UNICODE and must be edited in an editor that supports UNICODE, like WordPad in Windows or Kate on Linux. Here the operator can change both the text message and the type of the message.

The header of this file describes the valid types. Each message has a type field which can be set to the operator's preferences. Simply change the type field for the messages you want and save the file. Make sure you save it as UNICODE.

Then open a terminal window in the directory where you saved this file. Issue the following command in Windows:

```
osql -Usisuser -Psimrad0 -imessages_R_Sy.uni
```

and on Linux:

```
psql -d sis -U sisuser - f pmess.sql
```

SIS will now react to the messages as described in the file.

### Note

---

*These settings may be lost when SIS is upgraded or reinstalled. If you want to make sure you always have these settings, save this file somewhere on your system. Reapply it when SIS is reinstalled.*

---

Note

---

*When SIS is upgraded the settings must be re-entered manually as described above. This is because SIS will use new upgraded database files, and any new content will be lost if the old saved file is reapplied.*

---

## 10.8 Request datagrams from an echo sounder

When an echo sounder is registered on the network in SIS, and started, datagrams can be routed from the echo sounder to selected IP addresses on the network.

The echo sounder must have been configured and started in the normal manner. Then start the Request datagrams program:

**Tools→Custom→Datagram distributions.**

Datagram	IP:Port	Interval
Information	localhost:9004	All
Information	localhost:4002	All
Clock	localhost:4002	All
Depth	localhost:4002	All
Installation	localhost:9004	All
Position	localhost:16138	All
Position	localhost:9004	All
Position	localhost:9009	All
Position	localhost:4002	All
Position	HDPC:5052	All
Runtime	localhost:4002	All
XYZ88	localhost:4002	All
Height	localhost:4002	All
Watercolumn	localhost:16132	All

- 1 Select the echo sounder from the first pull-down menu
- 2 Select datagram from second pull-down menu
- 3 Select the output interval of the datagrams from the third pull-down menu
- 4 Fill out the text field IP:Port with IP address and UDP port number to send the data to  
Remember the colon between the address and the port number
- 5 Press Subscribe
- 6 Repeat for all datagrams required
- 7 Restart SIS for the setting to take effect

When the echo sounder is started again, the requested datagram type(s) will be sent to the specified address(es) at the set interval.

To stop sending datagrams, select the datagram from the list and press **Unsubscribe**.

Note

---

*Never try to “Unsubscribe“ the factory defined datagrams.*

---

### **Sending options**

The options for sending out the datagrams are as follows:

- 1 All – meaning distribution whenever a datagram is received
- 2 Interval – distribution when datagram is received and later with a specified interval (from 1 sec to 1 minute)

Note

---

*It is the latest datagram received in an interval that will be distributed at the end of the interval (i.e. when selecting no 2 above).*

*Also, when the datagram arrival frequency is low and the distribution interval is short the last received datagram may be sent several times. This set-up is normally not appropriate for e.g. Position datagrams, but may serve better for Installation datagrams.*

---

### **Datagram selection**

The majority of the datagrams that can be selected for distribution, are datagrams generated and sent from the echo sounders.

Currently there are three datagrams that are not of this category, these are the remote datagrams R00, R10 and R12. In this case these datagrams are NOT the remote datagrams generated by an external system for the purpose of controlling SIS as described in *Remote datagrams* on page 451.

Rather, these datagrams are generated locally in SIS as a result of the operation of the pinging and logging buttons. Please see description in *Notification of SIS pinging and logging activity* on page 453

The intention is that an external system may be able to follow (i.e. shadow) the SIS pinging and logging operations.

Note

---

*The R-datagrams must always be selected with the “All“ option to avoid multiple retransmissions of the datagrams.*

---

## 10.9 Request datagrams – manual set-up

### Note

*This chapter is intended for advanced users only. It is simpler to subscribe on datagrams by selecting **Tools→Custom→Datagram distribution**. See Request datagrams from an echo sounder on page 442.*

---

### Overview

The subscription setup of datagrams from the DDS can be performed in two ways:

- 1 By using a provided utility (see note above) specifying the relevant echo sounder, datagram and subscriber IP address. These entries are semi permanent i.e. valid until the database is completely rebuilt.
- 2 By updating the database tables manually. These changes will be permanent. Currently this option requires that the database is completely rebuilt.

### Manual update of database tables

The SIS DDS has the ability to distribute (i.e. retransmit) datagrams received from the Processing Unit (and other sources) out to external recipients. This distribution is done according to settings in the SIS database. Therefore, in order for an external recipient to subscribe to a particular datagram, the SIS database must be updated to distribute the datagram.

Note that SIS contains several DDS applications of different types. Each type is adapted to handle a specific type of Processing Unit or equipment. Currently three DDS types are of interest:

- 1 A generic multibeam type (EM 3000, EM 3002, EM 2000, EM 1002, EM 710, EM 300, EM 120)
- 2 A generic NMEA single beam type (receiving NMEA DPT or NMEA DBT, NMEA GGA, NMEA HDT or NMEA HDM)
- 3 A GPS and compass (receiving NMEA GGA, NMEA HDT or NMEA HDM)

### The SIS Database

The SIS database contains several tables which defines the datagram distribution set-up in DDS. These tables can be divided into four categories:

- 1 A category with one table defining the datagrams and the distribution parameters
- 2 A category with one table defining sockets used for sending datagrams


- 3 A category with one table linking the two, i.e. defining which datagram to be sent on which socket
- 4 A category with several tables organizing datagrams and sockets according to type of DDS process

### Table 'dds\_datagrams\_send' (category 1)

This table is used to define all datagrams which can be distributed by a DDS. Each entry (i.e. row) is identified by a datagram id ('id\_datagram') which must be unique.

The **dds\_datagrams\_send** table normally only needs to be updated when new datagrams are defined or new DDS types are added. However, when a datagram subscription is defined it is necessary to know the correct **id\_datagram** value as this value is used in other tables.

Figure 41 Relevant SIS database tables for subscription configuration



### id\_datagram

Note that the datagram identifiers are organized in ranges or sets, one for each type of DDS (i.e. PU or equipment type) - see **user\_pid** below. The generic EM multibeam set currently has an **id\_datagram** range from 36 to 302 (with some holes). NMEA singlebeam has a range from 400 to 475 and the GPS compass type has a range from 500 to 575.

#### datagram\_type

The **datagram\_type** parameter defines the type of datagram (e.g. Depth = 'D' = 68) associated with the specific datagram id. The same datagram type may be used in all ranges, if relevant, but only once in each range.

#### interval, seconds

These parameters are used to define how to distribute the associated datagram. The **interval** parameter may have the following values:

- 0 - Distribute signal when received
- 1 - Distribute signal repeatedly with a set interval defined by the **seconds** parameter.
- 2 - Distribute signal when received and repeat, as above
- 3 - Distribute signal only upon request (currently not implemented).

#### user\_pid

This parameter identifies the DDS type associated with the **id\_datagram** parameter. The correct **user\_pid** value is found in the **process** table as the **pid** parameter (marked with bold in entries below):

- 1 DDS generic multibeam type (EM 3000, EM 3002, EM 2000, EM 1002, EM 710, EM 300, EM 120) is entry: (10,'DDS\_GENERIC\_EM')
- 2 Generic NMEA single beam type is entry: (14,'DDS\_GENERIC\_SINGLEBEAM\_NMEA')
- 3 For GPS and compass is entry: (13,'DDS\_GENERIC\_GPS')

The range scheme and the use of the same datagram type in several ranges allow datagrams to be handled differently for each DDS type (i.e. PU/equipment type).

#### **Table 'dds\_periodic\_datagrams' (category 4)**

This table defines which datagrams, (defined in **dds\_parameters\_send**) belong to which DDS type. Each entry (i.e. row) defines such a relation. The **dds\_periodic\_datagrams** table normally only needs to be updated when new datagrams are defined or new DDS types are added.

#### id\_dds

This parameter identifies the DDS type. The correct value is found in the **process** table as the **pid** parameter (marked with bold in entries below):

- 1 DDS generic multibeam type (EM 3000, EM 3002, EM 2000, EM 1002, EM 710, EM 300, EM 120) is entry: (10,'DDS\_GENERIC\_EM')

- 2 Generic NMEA single beam type is entry:  
(14,'DDS\_GENERIC\_SINGLEBEAM\_NMEA')
- 3 For GPS and compass is entry: (13,'DDS\_GENERIC\_GPS')

id\_datagram

Id of datagram from the correct range in the **dds\_datagrams\_send** table according to DDS type.

**Table sockets (category 2)**

This table defines all sockets in the SIS system including all sockets used by DDS. If a subscription is added or changed it may be necessary to define a new socket or change an existing socket. The socket will be used by DDS for sending the subscribed datagrams to the recipient.

id

Each socket in SIS must have a unique id. This is an integer number. **Before selecting an id for the socket make sure it is below 1000 and not already used** (make a search in the SISDB\_v3.sql and any other SISDB\_vX.sql file with a higher version than X=3).

port, ip

This is the net address for the recipient of the subscribed datagram(s).

udp\_tcp

0 = UDP, 1 = TCP

**The UDP protocol must always be used. This setting shall therefore be 0.**

server\_client

0 = server, 1 = client, 2 = unused

SIS is a server. **This setting shall therefore be 0.**

read\_write

= 0 read, 1 = write, 2 = read and write

The socket is always write. **This setting shall therefore be 1.**

pid

This parameter gives an id to the recipient on the other side of the link. For the purpose of distributing datagram from the DDS to an external recipient the **pid value must be set to 76 - NOTE this value.**

**Table 'process\_socket' (category 4)**

This table defines which sockets, (defined in 'sockets') that belong to which process. Each entry (i.e. row) defines such a relation.

The **process\_socket** table needs to be updated when new datagrams are defined or new DDS types are added.

process\_id

This parameter identifies the process using the socket; in this case that is a DDS type. The correct value is found in the **process** table as the **pid** parameter (marked with bold in entries below):

- 1 DDS generic multibeam type (EM 3000, EM 3002, EM 2000, EM 1002, EM 710, EM 300, EM 120) is entry: (**10**, 'DDS\_GENERIC\_EM')
- 2 Generic NMEA single beam type is entry: (**14**, 'DDS\_GENERIC\_SINGLEBEAM\_NMEA')
- 3 For GPS and compass is entry: (**13**, 'DDS\_GENERIC\_GPS')

socket\_id

Id of the socket used to distribute datagrams to the recipient. The **socket\_id** is found in the **sockets** table as the **id** (see above) of the relevant socket definition.

**Table 'dds\_socket\_send' (category 3)**

The table is used to connect datagrams with sockets, i.e. it tells which datagrams (identified by 'id\_datagram') that should be sent out on which socket.

This is the essential routing information necessary to be able to distribute the datagrams to the correct recipient.

In essence, all the other tables are only help tables necessary to define the datagrams and sockets (and who they belong to), whereas the routing information in **dds\_socket\_send** is what we really want to specify.

id\_datagram

A defined datagram id belonging to a DDS type which is the same as for **id\_socket** below.

id\_socket

A defined socket id belonging to a DDS type which is the same as for **id\_datagram** above.

**When making entries in this table, care must be taken to pair only datagrams and sockets associated with the same DDS type (identified by 'process\_id' in 'the 'process\_socket' table and 'id\_dds' in the 'dds\_periodic\_datagrams' table respectively).**

### Procedure for setting up a datagram subscription

The tables to be modified are located in the **SISDB\_v3.sql** file.

- 1 Check if the datagram to be subscribed exist in **dds\_datagram\_send** table for the relevant DDS type. If not, define it. Remember the **id\_datagram** value.
- 2 Check if the datagram exist in the **dds\_periodic\_datagrams** table for the correct DDS type. If not, define it.
- 3 Make a socket for the recipient, in the **sockets** table using correct IP address. Remember the **id\_socket** value.
- 4 Make an entry in the **process\_socket** table with the new **id\_socket** value and the relevant DDS type.
- 5 Make an entry in the **dds\_socket\_send** table with the correct combination of **id\_datagram** and **id\_socket**. Note that one socket can be used for several datagrams.
- 6 The SIS database must be re-built and SIS restarted.

### Important notes and restrictions

- All entries in the tables described above are currently done with reference to three DDS types. These types are regarded as templates used to instantiate database entries for new echo sounders detected on the network. Instantiation is necessary due to the fact that several echo sounders can not use the same data and the same objects (e.g. sockets.) Each echo sounder will therefore get a separate set of sockets and datagram ids, which mean that the specific values entered in the tables above, are not actually used for any echo sounder.
- However, the IP address for the recipient of a datagram is a value that can not be instantiated. This implies that the DDSes for e.g. EM 3000, EM 3002, EM 2000, EM 1002, EM 710, EM 300, EM 120 will send a datagram to the same recipient if they are detected in the same SIS system.
- **When the changes in the SIS database are performed the database must be re-built and SIS restarted.**
- The settings will be semi permanent, i.e. they will be in effect until the database is completely rebuilt.

# 10.10 Data distribution


The **DataDistrib** program is included with SIS. This is a Windows application that can be used to route or distribute UDP datagrams to various destinations on the local PC or to other networked PCs.

The application has a graphical user interface where you can set up distribution of data from up to 10 different sources. In a grid you set up the incoming sockets from where to listen to data and up to four different destinations for each source. It also possible to store incoming data to a file and later replay that file. If you want to replay data, a file name is entered instead of a source port.

Make sure that you enter a Source port that is not used by any other applications, e.g. rstoudp, as two application cannot use the same port simultaneously.

Only the **DataDistrib.exe** file must be installed on the PCs where the application should run. Settings are stored in **DataDistrib.ini**.

Figure 42 DataDistribution user interface



## 10.11 Remote datagrams

These datagrams allow external systems a minimal amount of control of SIS. The datagrams are received by SIS in port 4001 and 4002, from the connected network using the UDP protocol.

Datagram	Received on port	Description
R00	4002	SIS to stop pingning (and logging if on)
R10	4002	SIS to stop all logging, but continue or start pingning
R12	4002	SIS to start logging on new line
R20	4001	Echosounder to send installation, runtime and sound speed profile (I, <b>R</b> and <b>U</b> ) datagram

---

### Note

*The Rxx datagrams must always contain the sounder type i.e. EMX=dddd . “dddd” is described in Model number – code mapping table on page 455.*

---

SIS supports for the following remote datagrams:

### **R00, R10 and R12**

R00, R10 and R12 closely mimic the use of the logging and ping buttons. There are no restrictions on the sequence in which these datagrams can be sent. The following is typical:

- To start pingning: R10
- To start logging: R12 (Note that it is not necessary to start pingning with R10 first)
- To stop logging: R10 or R00. (Note R00 also stops pingning)
- To stop pingning: R00

When the remote **Rxx** datagrams are received the sounder type indicated in the datagram is made current. The SIS GUI is updated accordingly so that the ping and logging buttons will show the correct status.

The PLL parameter in the **R12** datagram can now be used to set the line number to be logged. The line number must be 4 digits between 0000 and 9999. Any non digit characters in the line number will result in PLL being disregarded. If no specific line number is wanted PLL should be set to empty, i.e. **PLL=**,

---

### Note

*No characters between the equal sign and comma*

---

Note

---

*The relevant echo sounder must have been started for the R00, R10 and R12 datagrams to have any effect. SIS will behave as if the ping and logging buttons have been used, including line counter increment.*

---

**R20**

R20 is used to get an echo sounder (PU) to transmit the setup parameters currently used (i.e. **I**, **U**, **R** datagrams). These parameters are normally distributed by the PU to the external system(s) using its UDP4 port.

Note

---

*The relevant echo sounder must have been started for the R20 datagram to have any effect.*

---

## 10.12 Notification of SIS ping and logging activity

It is possible for an external system to subscribe to the ping and logging status changes in SIS. This makes it possible for the external system to mimic (shadow) these SIS operations.

A simple scheme to notify external systems of the ping/logging status changes is to use the remote R-datagrams as these will give the necessary information:

- R00 System to stop ping (and logging if on)
- R10 System to stop logging (but continue or start ping)
- R12 System to start logging on new line

See *Remote datagrams* on page 451

---

### Note

*The original purpose of the R-datagrams is to be able to remotely control the SIS ping and logging activity. However, using the R-datagrams for status change notification as described in this chapter does not conflict with this purpose.*

---

SIS will prepare and send R-datagrams according to changes in logging and ping status. External systems that require notification of these events must subscribe to these datagrams by using the datagram distribution feature in SIS.

See *Request datagrams from an echo sounder* on page 442

---

### Note

*The “All” send option must be used for the R-datagrams when setting up the parameters.*

---

The use cases below indicate which R-datagrams an external system may receive due to ping/logging status changes in SIS. Note that this is not a complete list.

### **SIS turns logging on**

- Case 1: R12 (logging on)
- Case 2: R10 (pinging on) + R12 (logging on)

### **SIS turns logging off**

- Case 1: R00 (pinging off logging off)
- Case 2: R10 (logging off, pinging still on)

### **SIS logs several consecutive lines (without breaks)**

- Case 1: R12 + R12 + ... + R12 + ...

**Note**

*It is important, in order to get a correct and complete status of the SIS logging activity, that all R-datagrams, including R00, must be subscribed to. R00 will indicate stop of pinging, but as a consequence, logging will also stop.*

The format of the R-datagrams are defined in the Datagram formats document (reg nr 850 – 160692). For simplicity it is shown below, however always refer to the document in mention for a valid format.

Data Description	Format	Valid range	Note
Start identifier = \$	Always 24h	—	—
Talker identifier	aa	Capital letters	—
Datagram identifier	Rxx,	R00 to R20	1
EM model number	EMX=dddd,	—	—
Responsible operator	ROP=a-a,	—	—
Survey identifier	SID=a-a,	—	—
Survey line number	PLN=d..d,	—	—
Survey line identifier (planned line no)	PLL=d-d,	—	—
Comment	COM=a-a	—	—
Optional checksum	*hh	—	—
End of datagram delimiter = \CRLF	5Ch 0Dh 0Ah	—	—

The following parameters are not used in this context, i.e. no values are supplied by SIS for:

- ROP
- PLL

The rest of the parameters are used and contain parameters as described in the format.

Example, for an EM 3002 echo sounder:

```
$KMR12,EMX=3020,ROP=,SID=Fallback_3002_121_1,PLN=0006,PLL=,COM= Serial number: 121*cc\CRLF
```

Where **cc** are two hex characters calculated by XOR'ing all characters between \$ and \*.

The **Talker identifier** will be set to “KM”.

The format description above is inadequate to handle several echo sounders simultaneously, as it has no parameter to list the serial number of an echo sounder. This number has been put in the comment field (COM=) for completeness (e.g. **COM= Serial number: 121** in the example above).

**Model number – code mapping table**

The EM model number “dddd” is coded as follows:

System	Code	Note
EM 120	0120	—
EM 122	0122	—
EM 300	0300	—
EM 302	0302	—
EM 710	0710	—
EM 1002	1002	—
EM 2000	2000	—
EM 3000	3000	—
EM 3002	3020	NB!
ME 70	0850	NB!

**Note**

*The codes for EM 3002 and ME 70 differs from their respective system names.*

**Performance requirements**

The interval between the distributed R-datagrams is undefined, i.e. the datagrams are asynchronous. The initial (startup) status may be assumed to be pinging and logging both off.

**External interface requirements**

The datagram distribution mechanism in SIS uses UDP. Note that SIS, in future releases, may operate several echo sounders in parallel. This implies that SIS can distribute the pinging/logging status from several echo sounders simultaneously (see the remark about the comment field (COM=) above).

In case of several echo sounders the information (i.e. R-datagrams) from each echo sounder can be distributed to separate IP:port address or alternatively all can use the same address. This must be decided before setting up the datagram subscription (i.e. distribution) parameters in SIS.

It is the responsibility of the external operator and the external system to set up and handle the incoming flow of pinging/logging status data from SIS. The EM model number can be used, if necessary, to distinguish between echo sounders using the same IP:port address.

## 10.13 Difference in log file formats

SIS logs various types of datagrams from the echo sounder in a continuous stream. Each time you start a new line, a new survey data file is created which results in a break in the data stream such that a depth datagram may be located at the end of one file with its associated position datagram located at the beginning of the next.

When SIS generates xyz-data from these files, if it encounters a depth datagram at the end of the file for which there is no corresponding position datagram, it looks for the missing position datagram in the next survey file. However, when Neptune generates xyz-data from these files, if it can't find a valid position datagram after the last depth datagram, it will reject the depth datagram resulting in a hole in the data.

Previous versions of the Merlin logging system handled this situation by storing duplicate position datagrams in both survey files, but this is no longer done. Therefore, to eliminate this type of hole when generating xyz-data, Neptune will be updated with a tool that will insert the missing position datagram at the proper location in the survey data files.

## 10.14 Barometer input

### 10.14.1 Preparations for use

If automatic update of the barometer (Offset) parameter is required (used in ROV operation for EM 3002) it is necessary to prepare SIS to receive this information.

The external barometer equipment/system must be connected to a vacant RS232 input port on the SIS HWS. This serial port must be configured: **Tools→External Sensors**

### 10.14.2 Barometer input format

The (current) format of the data received on the serial port is as follows:

```
*ddsspppp.ppp<cr><lf>
```

Where:

*	The format always starts with an asterisk (*)
dd	a two digit destination identifier
ss	a two digit source identifier
pppp.ppp	pressure in mbar. Number of digits before and after the decimal point may vary
<cr><lf>	Terminating carriage return and line feed characters

If this input format needs to be changed it is possible to adapt SIS to the new format without a full SIS upgrade. A separate conversion process is used for this purpose. This process is implemented using Perl, a programming language which can be used with all SIS installations. An editor and knowledge of Perl is all that is needed to adapt the conversion process:

- 1 Stop SIS if running
- 2 Go to the SIS program installation directory (e.g. "C:\Program Files\Kongsberg Maritime\SIS\bin" on Windows). Locate the file **barometerconv.pl** and open it in an editor. Do the necessary changes to adapt to the changed input format.
- 3 Save and close the edited file
- 4 Start SIS

The required output from the conversion process is a string of the following format:

```
$KSSIS,134,ss,dd,pppp.ppp\n\r
```

where the pressure has been converted to decibar of format pppp.ppp, and the number of digits before and after the decimal point may vary.

“\n\r” is linefeed and carriage return.

## **11 INDEX**

## A

About  
this  
manual,  
11  
Absorption  
coefficient,  
401  
Equation,  
410  
actd,  
437  
Advanced  
parameters,  
243  
AHT  
logging,  
261  
Angular  
offsets,  
226  
EM  
1002,  
238  
Annotation  
colours,  
44  
APOS,  
270  
Artefacts  
causing  
errors,  
407  
asvp,  
434  
Auto  
pilot,  
300  
Output  
setup,  
300  
Parameters,  
276  
Autostart,  
134  
AUV/ROV,  
371

## B

Barometer,  
457  
Input  
setup,  
300  
Beam  
intensity,  
56

Buttons,  
57  
Show/Hide,  
185  
Toolbar,  
57  
BIST,  
240  
Built-In  
Self  
Test,  
240  
Buttons,  
31  
Annotation  
colours,  
44  
Beam  
intensity,  
57  
Calibration,  
89  
Colour  
coded  
depth,  
58  
Common  
display  
buttons,  
43  
Cross  
track,  
59  
Dynamic  
colours,  
45  
Geographical,  
52  
Helmsman  
Display,  
64  
Print,  
46  
Scale,  
49  
Scope  
display,  
73  
Seabed  
image,  
61  
Sensor  
layout,  
87  
Sound  
velocity,  
71

Stave  
display,  
74  
Time  
series,  
65  
Water  
column,  
69  
Waterfall,  
66  
Zoom  
and  
view,  
47

## C

C-Map,  
354  
Cartographic  
service,  
356  
CM-93/3  
compiler,  
354  
Detail  
level,  
37  
Licence  
Administration,  
304  
Manipulation  
mode,  
183  
Min  
performance,  
354  
S-57  
verifier,  
354  
What  
it  
does,  
354  
Calibration,  
88  
Area,  
143  
AutoCalib  
Wizard,  
305  
Automatic,  
153  
Buttons,  
89

- 
- Edit
    - mode, 182
  - Heading
    - offset, 148
  - Keyboard, 42
  - Mouse, 42
  - Outer
    - beam angle calibration, 150, 152
  - Parameters, 213
  - Pitch
    - offset, 146
  - Principles, 143
  - Roll
    - offset, 145
  - SeaCal, 335
  - Seacal
    - parameters, 214
  - Seacal
    - results, 306
  - Show/Hide, 214
  - Sound
    - velocity quality inspection, 150
  - Time
    - delay, 146
  - Toolbar, 89
  - Verification, 153
  - Changing
    - behaviour of notification messages, 440
  - Colour
    - coded depth, 57
  - Buttons, 58
  - Show/Hide, 186
  - Toolbar, 58
  - Colour
    - palette, 38
  - Common
    - display buttons, 43
  - Annotation
    - colours, 44
  - Dynamic
    - colours, 45
  - Print, 46
  - Scale, 49
  - Zoom
    - and view, 47
  - Create
    - terrain models, 363
  - Cross
    - track, 58
  - Buttons, 59
  - Display
    - options, 186
  - Modeless
    - operation, 59
  - Toolbar, 59
  - CUBE, 375
    - Create grid, 292
  - Description, 375
  - Export
    - survey data, 379
  - Features
    - not supported, 382
  - Geographical
    - view, 380
  - Import
    - raw data, 379
  - User
    - interface, 379
  - Current
    - echosounder, 33
  - Custom
    - menu, 94
  - D**
  - Data
    - cleaning, 253
    - Reference, 389
  - Data
    - distribution, 450
  - Datagram
    - formats, 426
  - Distribution, 450
  - Remote, 451
  - Request, 442
  - Request
    - manually, 444
  - SIS
    - pinging and logging activity, 453
  - SSP
    - datagrams, 431
  - Datum
    - transformation, 308
  - Dead
    - reckoning, 424
  - Depth
    - below

- keel, 301
  - Display, 21
    - Annotation colours, 44
    - Auto scale once, 49
    - Dynamic colours, 45
    - Fixed scale, 49
    - Pause, 48
    - Print, 46
    - Reset view, 48
    - Scale, 49
    - Zoom, 47
    - Zoom out, 47
    - Zoom reset, 48
  - Display options, 169
    - Beam intensity, 185
    - Calibration, 214
    - Colour coded depth, 186
    - Colour palette, 38
    - Cross track, 186
    - Geographical, 170
    - Helmsman Display, 191
  - Icons, 37
  - Scope display, 200
  - Seabed image, 189
  - Sensor layout, 210
  - Ship definition, 267
  - Sound velocity, 200
  - Stave display, 201
  - SVP Editor, 319
  - Time series, 193
  - Water column, 196
  - Waterfall, 195
  - Dynamic colours, 45
  - Dynamic positioning, 300
- E**
- Echosounder – Not started, 32
  - EM 1002
    - Angular offsets, 238
    - BIST, 242
    - Filter and gains, 250
  - Simulator, 263
- F**
- File
  - Sound speed, 246
  - Sounder main, 243
  - System parameters, 239
  - Error estimates, 268
  - Events, 359
  - Exit, 293
  - Export data, 166
  - Export formats, 427
  - Export survey results, 167
  - External datagram (C+T) format, 439
  - External sensors, 295
    - Heading and position, 121
    - How to, 120
    - Input setup, 296
    - Output setup, 300
    - Sound velocity probe, 120
  - Extract IFF, 306

- 
- Background
    - grid, 284
  - Create
    - CUBE
    - grid, 292
  - Delete
    - settings, 288
  - Export, 278
  - Export
    - data
    - files, 284
  - Export
    - PU
    - parameters, 289
  - Export
    - user
    - settings, 291
  - Import, 278
  - Import
    - PU
    - parameters, 290
  - Import
    - user
    - settings, 292
  - KSGPL, 283
  - Parameters, 278
  - Raw
    - data
    - files, 281
  - Remove
    - survey, 287
  - Save
    - settings, 287
  - Save
    - settings
    - as..., 287
  - Set
    - startup
    - settings, 288
  - xyz
    - file, 286
  - File
    - formats, 426
    - actd
      - format, 437
    - asvp
      - format, 434
  - Barometer
    - input, 457
  - C+T
    - format, 439
  - Difference
    - in
    - log
    - file
    - formats, 456
  - Export
    - formats, 427
  - Notification
    - messages, 440
  - Sound
    - speed
    - and
    - density
    - profile
    - format, 437
  - Sound
    - speed
    - profile
    - format, 434
  - Survey
    - plan, 430
  - File
    - menu, 91
  - Filter
    - and
    - gains, 243
    - EM
      - 1002, 250
  - Frames, 22
  - Beam
    - intensity, 56
  - Calibration, 88
  - Colour
    - coded
    - depth, 57
  - Contents, 51
  - Cross
    - track, 58
  - Geographical, 52
  - Helmsman
    - display, 63
  - Installation
    - parameters, 83
  - Manage
    - windows, 35
  - Message
    - service, 62
  - New
    - survey, 79
  - Numerical
    - display, 62
  - Parameters, 169
  - Planning, 82
  - PU
    - sensor
    - status, 77
  - Runtime
    - parameters, 84
  - Runtime
    - parameters
    - Mini, 85
  - Scope
    - display, 72
  - Seabed
    - image, 60
  - Sensor
    - layout, 87

- Sound
    - velocity profile, 70
  - Stave
    - display, 73
  - Survey
    - administration, 81
  - Time
    - series, 65
  - Toolbar, 31
  - Water
    - column, 67
  - Waterfall, 66
- G**
- Geodimeter, 300
  - Geographical, 52
    - 2D or 3D, 181
  - Buttons, 52
  - C-Map
    - manipulation mode, 183
  - Calibration
    - edit mode, 182
  - Compass, 182
  - CUBE
    - features, 380
  - Display
    - smooth surface, 140
  - Follow
    - ship, 183
  - Grid
    - shading, 181
  - Information
    - field, 183
  - Inspection
    - mode, 181
  - Keyboard, 40
  - KSGPL
    - edit mode, 182
  - Level
    - of detail, 183
  - Load
    - background data, 183
  - Look
    - for artefacts, 140
  - Modeless
    - operation, 54
  - Mouse, 40
  - Options, 170
  - Planning
    - mode, 182
  - Quick
    - menu, 55
  - Seabed
    - imagery display, 138
  - Show
    - depth under cursor, 181
  - Show/Hide, 171
  - Toolbar, 52
  - Zoom
    - to given region, 47
  - Zoom
    - to ship, 48
  - Zoom
    - to world, 47
  - Zooming, 48
  - Geoid, 414
  - Global
    - event marker, 359
  - Graphical, 21
    - Frames, 22
    - The application window, 21
  - Windows, 22
  - Grid, 274
    - Create from ASCII, 363
  - CUBE
    - parameters, 225
  - GridEngine, 387
  - GridEngine
    - parameters, 222
  - Set
    - data cleaning method, 274
- H**
- Heading
    - input, 298
  - Helmsman
    - Display, 63
    - Buttons, 64

- How
  - to, 166
- Show/Hide, 191
- Toolbar, 64
- Help
  - menu, 95
- Hotkeys, 43
- How
  - to, 96
  - Calibration, 153
  - Collect
    - the sound velocity profile, 124
  - Convert
    - format using SVP Editor, 131
  - Convert SVP
    - format, 126
  - csv2asvp, 126
  - Display
    - a smooth surface, 140
  - Display planned lines, 166
  - Display realtime depths, 138
  - Display seabed imagery data, 138
- Exit
  - SIS, 168
- Export
  - data, 166
- Export survey results, 167
- External sensors, 120
- Import
  - a Neptune grid, 135
- Installation
  - parameters, 112
- Interface
  - an EA into SIS, 134
- Interfaces, 120
- Log
  - water column data, 142
- Look
  - for artefacts, 140
- Modify
  - and load a SVP, 132
- Monitor
  - the external sensors, 137
- Monitor the progress, 163
- New survey, 105
- Plan
  - a new job, 162
- Projection
  - and datum, 107
- Retrieve
  - a planned job, 163
- Run
  - the PU simulator, 164
- Run the survey, 163
- Runtime parameters, 117
- Save data, 142
- SeaCal, 156
- SmartTalk, 125
- Start
  - and stop logging, 141
- Start pinging, 136
- Start the echo sounder, 134
- Start the remote helmsman display, 166
- Survey parameters, 102
- SVP
  - Logger, 127
- SVP Manager, 128
- Use
  - SIS

- on
  - AUV/ROV,
    - 371
- Verify
  - the
    - EM
      - main
        - functions,
          - 138
- Hypack
  - ®,
    - 18

## I

- Icons,
  - 37
- Import
  - grids
    - to
      - SIS,
        - 363
- Installation
  - parameters,
    - 226
      - Active
        - sensors
          - parameter
            - settings,
              - 236
    - Angular
      - offsets
        - EM
          - 1002,
            - 238
    - BIST,
      - 240
    - Clock
      - setup,
        - 232
    - COM
      - port
        - parameters,
          - 227
    - Description,
      - 83
    - How
      - to,
        - 112
    - Input
      - setup,
        - 226
    - Location
      - of
        - sensors,
          - 237
    - Motion
      - sensor

- parameter
  - settings,
    - 235
- Network
  - addresses,
    - 227
- Output
  - setup,
    - 230
- Positioning
  - systems
    - parameter
      - settings,
        - 234
- Procedures,
  - 110
- Sensor
  - setup,
    - 233
- System
  - parameters
    - EM
      - 1002,
        - 239
- UDP
  - port
    - parameters,
      - 227
- Instrument
  - combinations,
    - 302
- Interface,
  - 295
    - Auto
      - pilot,
        - 300
  - Barometer,
    - 300
  - Depth
    - below
      - keel,
        - 301
  - Dynamic
    - positioning,
      - 300
  - Geodimeter,
    - 300
  - Heading,
    - 298
  - How
    - to,
      - 120
  - Instrument
    - combinations,
      - 302
  - Position,
    - 299

- Real
  - time
    - tide,
      - 297
- Remove
  - instruments,
    - 303
- Sound
  - velocity,
    - 297
- SVP
  - logger,
    - 299
- Intermediate
  - File
    - Format,
      - 306
- Introduction,
  - 12

## J

- Javad,
  - 261
    - Details,
      - 419

## K

- Keyboard,
  - 40
    - Calibration,
      - 42
    - Geographical,
      - 40
    - Planning,
      - 41
    - Sensor
      - layout,
        - 42
    - Sound
      - velocity
        - profile,
          - 41
    - Waterfall,
      - 42
- KSGPL,
  - 365
    - Edit
      - mode,
        - 182
    - Load
      - background
        - data,
          - 183
    - Object
      - types,
        - 180

- SIS
  - objects, 344
- L**
- Level
  - of detail, 183
- Licences, 13
- Line counter, 34
- Logging, 141
  - Formats, 456
  - How to, 134
  - Notification, 453
  - Sound velocity data, 124
  - To PU disk, 372
  - Water column, 199
- M**
- Main menu, 91
- Manage windows, 35
- Mean sea surface, 414
- Menu, 91
  - Configure, 307
  - Custom menu, 94
  - File menu, 91
- Help, 95
- Main menu, 91
- Tools, 93
- Tools menu, 295
- View, 92
- Message service, 62
- Mouse, 40
  - Calibration, 42
  - Geographical, 40
  - Planning, 41
  - Sensor layout, 42
  - Sound velocity profile, 41
  - Waterfall, 42
- N**
- Neptune, 135
- Network licence, 277
- New survey, 79
  - Background data, 220
  - Basic parameters, 216
  - GridEngine parameters, 222
  - How to, 105
  - Parameters, 216
- Projections, 222
- Storage options, 219
- Notification of pinging and logging, 453
- Numerical display, 62
- O**
- Overview
  - Features, 15
  - Principle drawing, 13
  - System information, 13
  - The application window, 21
- P**
- Parameters, 169
  - Active sensors, 236
  - Angular offsets EM 1002, 238
  - ATH logging, 261
  - BIST, 240
  - Calibration, 213
  - Clock setup, 232
  - COM port, 227
  - Data cleaning, 253

Datum, 308	Simulator EM 1002, 263	Mouse, 41
File menu, 278	SIS parameters, 266	New jobs, 162
Filter and gains EM 1002, 250	Sound speed EM 1002, 246	Object, 203
Frames, 169	Sounder main EM 1002, 243	Remote, 202
Help menu, 314	Survey administration, 216	Retrieve a job, 163
Input setup, 226	Survey information, 265	Playback, 361
Installation, 226	System parameters EM 1002, 239	Position, 271
Javad, 261	Tools menu, 295	Dead reckoning, 424
Motion sensors, 235	Trimble, 261	Input, 299
Network addresses, 227	UDP port, 227	Jump filter, 424
New Survey, 216	Password, 273	Predicted tide file format, 417
Output setup, 230	Pinging, 136	Print, 46
Positioning systems, 234	Notification, 453	Procedures, 96
Projection, 308	Planning, 82	Advanced survey parameters, 103, 106
Projections, 222	Edit mode, 182	Background data, 102
Runtime, 243	File format, 430	Basic survey parameters, 105
Runtime Mini, 85	How to, 159	BIST, 115
Secal, 214	Jobs, 202	Check echo sounder main functions, 137
Sensor locations, 237	Keyboard, 41	Check installation and runtime
Sensor setup, 233		
Ship definition, 267		

- parameters, 110
- Check
  - sensor input, 136
- CUBE
  - parameters, 104
- Data
  - cleaning, 119
- Datum
  - transformation, 107
- Detecting
  - the echo sounder, 98
- Enter
  - a sound velocity profile, 123
- Enter
  - operator parameters, 101
- Enter
  - survey parameters, 101
- Exit
  - SIS, 168
- Export
  - data files, 284
- Export
  - survey results, 167
- External
  - sensor, 119
- Filter
  - and gains, 118
- Heading
  - and position parameters, 121
- Heading
  - offset calibration, 148
- How
  - to collect the sound velocity, 124
- How
  - to configure your survey, 101
- How
  - to convert a profile using SVP Editor, 131
- How
  - to convert the SVP format, 126
- How
  - to define a new projection, 107
- How
  - to display a smooth surface, 140
- How
  - to display planned lines, 166
- How
  - to display realtime
- depths, 138
- How
  - to display seabed imagery data, 138
- How
  - to do a calibration, 153
- How
  - to enter parameters for a new survey, 105
- How
  - to enter survey parameters, 102
- How
  - to export data, 166
- How
  - to export survey results, 167
- How
  - to import a Neptune grid, 135
- How
  - to interface an EA into SIS, 134
- How
  - to

log	parameters,	sensors,
water	116	122
column	How	How
data,	to	to
142	plan	start
How	a	pinging,
to	new	136
look	job,	How
for	162	to
artefacts,	How	start
140	to	SIS,
How	retrieve	100
to	a	How
modify	planned	to
and	job,	start
load	163	the
a	How	echo
SVP,	to	sounder,
132	run	134
How	the	How
to	PU	to
modify	simulator,	start
the	164	the
installation	How	remote
parameters,	to	helmsman
112	run	display,
How	the	166
to	survey,	How
modify	163	to
the	How	use
runtime	to	csv2asvp,
parameters,	save	126
117	data,	How
How	142	to
to	How	use
monitor	to	SeaCal,
the	setup	156
external	enter	How
sensors,	the	to
137	waterline,	use
How	122	SIS
to	How	Calibration,
monitor	to	153
the	setup	How
progress,	the	to
163	input	use
How	from	SIS
to	external	on
open	sensors,	AUV/ROV,
the	120	371
installation	How	How
parameters,	to	to
112	setup	use
How	the	SmartTalk,
to	output	125
open	to	How
the	external	to
runtime		use

start  
and  
stop  
logging,  
141  
How  
to  
use  
SVP  
Logger,  
127  
How  
to  
use  
SVP  
manager,  
128  
How  
to  
verify  
the  
EM  
main  
functions,  
138  
Installation  
parameters  
interface,  
111  
Interface,  
119  
Normal  
operational  
sequence,  
99  
Outer  
beam  
angle  
calibration,  
152  
Perform  
a  
system  
calibration,  
143  
Pitch  
offset  
calibration,  
146  
Plan  
a  
survey,  
159  
Playback,  
164  
Projection  
definition,  
107

PU  
communication,  
112  
Remote  
Helmsman  
display,  
166  
Replay,  
164  
Roll  
offset  
calibration,  
145  
Runtime  
parameters  
interface,  
116  
Sensor  
setup,  
114  
Set  
projection,  
101  
Sound  
speed,  
117  
Sound  
velocity  
interface,  
120  
Sound  
velocity  
quality  
inspection,  
150  
Sonder  
main,  
117  
Storage  
options,  
105  
Survey  
templates  
handling,  
102  
System  
parameters,  
115  
Time  
delay  
calibration,  
146  
User  
handling,  
102  
Projection,  
308

Available  
ellipsoids,  
310  
Available  
projections,  
311  
How  
to,  
107  
Parameters,  
222  
Programming,  
411  
Reference,  
411  
Test,  
309  
Using  
PROJ.4,  
412  
PU,  
77  
Clock  
parameters,  
232  
Export,  
289  
Import,  
290  
Input  
parameters,  
226  
Open,  
290  
Output  
parameters,  
230  
Save,  
289  
Sensor  
status,  
77  
Simulator,  
361

## Q

Qinsy  
®,  
18  
Quick  
menu,  
55  
Quit,  
293

## R

- Real
  - time
  - data
  - cleaning, 389
- Real
  - time
  - tide, 297
  - Datagram
    - format, 417
- Remote
  - datagrams, 451
- Remote Helmsman display, 166
- Remove
  - instruments, 303
- Replay, 361
- Request
  - datagrams, 442
- Request
  - datagrams manually, 444
- Runtime
  - parameters, 243
  - ATH
    - logging, 261
  - Data
    - cleaning, 253
  - Description, 84
  - Filter
    - and gains
    - EM
    - 1002, 250
  - How
    - to, 117
  - Javad
    - and Trimble, 261
  - Procedures, 110

## Simulator

- EM
  - 1002, 263
- Sound
  - speed
  - EM
  - 1002, 246
- Sounder
  - main
  - EM
  - 1002, 243
- Survey
  - information, 265
- Runtime
  - parameters
  - Mini, 85

## S

- Scale, 49
- Scope
  - display, 72
  - Buttons, 73
  - Show/Hide, 200
  - Toolbar, 73
- Seabed
  - image, 60
  - Buttons, 61
  - Show/Hide, 189
  - Toolbar, 61
- Seacal, 335
  - How
    - to, 156
  - Results, 306
  - Wizard, 305
- SeaCal
  - Parameters, 214

## Sensor

- layout, 87
  - Buttons, 87
  - Keyboard, 42
  - Mouse, 42
  - Show/Hide, 210
  - Toolbar, 87
- Set
  - parameters, 266
  - Advanced
    - display options, 269
  - APOS, 270
  - Auto
    - pilot, 276
  - Display, 273
  - Error
    - model, 268
  - Logging, 274
  - Network
    - licence, 277
  - Password, 273
  - Positions, 271
  - Ship, 267
  - Sound
    - speed, 276
  - Turn, 272
- Simulator, 243
  - EM
    - 1002, 263
- SIS, 12
  - About, 316
  - Architecture, 384

- As
    - a controller, 18
  - Build
    - info, 315
  - Central
    - Command Unit, 386
  - Configure, 307
  - Data
    - Distribution System, 386
  - Database, 388
  - Graphical User Interface, 384
  - GridEngine, 387
  - Handle
    - Data Distribution System, 386
  - Help, 315
  - Logging
    - formats, 456
  - Network
    - licence, 277
  - OpenGL, 315
  - Operational principles, 17
  - Password, 273
  - Processes, 384
  - SISDB, 388
  - System
    - information, 13
- SIS
    - Objects, 344
  - SIS
    - parameters, 266
- SmartTalk, 327
    - How to, 125
  - Sound
    - speed, 243
    - EM 1002, 246
  - Sound
    - speed and density format, 437
  - Sound
    - speed profile format, 434
  - Sound
    - velocity, 70
    - Buttons, 71
    - Collect, 124
    - Convert SVP format, 126
    - Editor, 318
    - Formulas, 399
    - How to, 123
    - Keyboard, 41
    - Logging, 124
    - Mouse, 41
    - Procedures, 123
    - Quality inspection, 150
    - Set parameters, 276
    - Show/Hide, 200
    - SmartTalk, 327
- SVP
    - Effects, 324
  - SVP
    - Logger, 332
  - Toolbar, 71
  - Sounder
    - main, 243
    - EM 1002, 243
  - SSP
    - datagrams, 431
  - Status
    - bar, 39
  - Stave
    - display, 73
    - Buttons, 74
    - Show/Hide, 201
    - Toolbar, 74
  - Stop, 293
  - Survey
    - administration, 81
    - CUBE parameters, 225
    - GridEngine parameters, 222
    - Parameters, 216
    - Projections, 222
    - User handling, 224
  - Survey
    - information, 265
  - Survey
    - parameters, 216
    - How to, 102
  - Survey
    - plan

- file
  - format, 430
- SVP
  - Editor, 318
  - Convert
    - a profile, 131
  - Display, 319
  - File
    - menu, 320
  - Modify
    - and load to SIS, 132
  - Tools
    - menu, 321
- SVP
  - Effects, 324
- SVP
  - logger, 299
- SVP
  - Logger, 332
    - How to, 127
- System
  - Features, 15
- System
  - parameters, 226
  - EM
    - 1002, 239

## T

- Technical
  - reference, 383
- Tide, 417
- Time
  - series, 65
  - Buttons, 65

- Clear
  - plot, 194
- Show/Hide, 193
- Toolbar, 65
- Timing, 395
- Toolbar, 29
- Beam
  - intensity, 57
- Calibration, 89
- Colour
  - coded depth, 58
- Cross
  - track, 59
- Current
  - echosounder, 33
- Frame
  - toolbars, 31
- Geographical, 52
- Helmsman
  - Display, 64
- Line
  - counter, 34
- Main
  - toolbar, 29
- Not
  - started, 32
- Scope
  - display, 73
- Seabed
  - image, 61
- Sensor
  - layout, 87
- Sound
  - velocity, 71
- Status
  - bar, 39

- Stave
  - display, 74
- Time
  - series, 65
- Water
  - column, 69
- Waterfall, 66
- Tools
  - menu, 93
- Trimble, 261
  - Details, 419
- Turn
  - parameters, 272

## V

- Vessel
  - coordinate system, 393
- View
  - menu, 92

## W

- Water
  - column, 67
  - Buttons, 69
  - Logging, 199
  - Show/Hide, 196
  - Toolbar, 69
- Waterfall, 66
  - Buttons, 66
  - Keyboard, 42
  - Mouse, 42
  - Show/Hide, 195
  - Toolbar, 66
- Windows, 22

Contents,  
51  
Manage,  
35

**Z**

Zoom,  
47

©2009 Kongsberg Maritime

---

**Kongsberg Maritime AS**

Strandpromenaden 50  
P.O.Box 111  
N-3191 Horten,  
Norway

Telephone: +47 33 02 38 00  
Telefax: +47 33 04 47 53  
**[www.kongsberg.com](http://www.kongsberg.com)**  
[subsea@kongsberg.com](mailto:subsea@kongsberg.com)



**KONGSBERG**



**SIS - Seafloor Information System  
Reference manual for EM 1002**

**SIS - Seafloor Information System  
Reference manual for EM 1002**

**SIS - Seafloor Information System  
Reference manual for EM 1002**